




CDC® PLATO® FLEXIBLE DISK SUBSYSTEM



**HARDWARE MAINTENANCE MANUAL
(SITE AND SUPPORT INFORMATION)**

REVISION RECORD	
REVISION	DESCRIPTION
01 (08-13-80)	Preliminary release.
A (10-03-83)	Final release. Includes changes per ECOs 14165, 14190, 14199, 14203, 14246, 14258, 14317, 14323, and 14328.
B-Interim (12-17-83)	Manual revised to incorporate ECO 14376.
C (01-23-81)	Manual revised to incorporate ECO's 14469, 14468, 14454, 14391, 14329, 14321, and 14279. Incorporates ECO 14376 (B-Interim) in its final form & makes technical corrections/changes.
D (03-02-81)	Manual revised to incorporate ECOs 14514 and 14571.
E-Interim (08-13-81)	Manual revised to incorporate ECO's 14539, 14591, 14582, 14613, 14663, and 14721.
F (10-08-81)	Manual revised to incorporate ECOs 14742, 14774, and 14838. Also includes technical changes to include media update and product name change.
G (01-19-82)	Manual revised to incorporate ECOs 14885, 14985, 14965, 14820, 14778. Also includes change in SAM 3, product name change.
H (11-23-82)	Manual revised to incorporate ECOs 15294, 15351, and 15462. FCC certification information also added.
J (05-11-83)	Manual revised to incorporate ECOs 14663 (Rev B), 14999, 15634, 15675, 15771, 15786, 15812 and 15867.
Publication No.	
62949100	

REVISION LETTERS I, O, Q AND X ARE NOT USED

©1980, 1981, 1982, 1983

by Control Data Corporation
Printed in the United States of America

Address comments concerning
this manual to:

Control Data Corporation
Publications and Graphics Div.
2401 North Fairview Avenue
St. Paul, Minnesota 55113

or use Comment Sheet in
the back of this manual.

REVISION RECORD (CONTD)

REVISION	DESCRIPTION
<p>K (08-16-83)</p>	<p>Manual revised to incorporate ECOs 15917, 15945, 16005 and 16060.</p>
<p>Publication No. 62949100</p>	



MANUAL TO EQUIPMENT LEVEL CORRELATION SHEET

This manual reflects the equipment configurations listed below.

EXPLANATION: Locate the equipment type and series number, as shown on the equipment FCO log, in the list below. Immediately to the right of the series number is an FCO number. If that number and all of the numbers underneath it match all of the numbers on the equipment FCO log, then this manual accurately reflects the equipment.

EQUIPMENT TYPE	SERIES	WITH FCO'S	COMMENTS
FA501-A	01	-	ECOs 14328, 14376, 14454
	01	-	ECO 14165 (S/N 141)
	02	-	ECO 14468 (S/N 274)
	03	14571	S/N 401
	04	-	ECO 14663 (S/N 701)
	05	-	ECO 14985 (S/N 1115)
	06	-	ECO 15771 (S/N 4635)
	07		
FA501-B	01	-	ECOs 14238, 14376, 14454
	01	-	ECO 14165 (S/N 141)
	02	14571	S/N 401
	03	-	ECO 14663 (S/N 701)
	04	-	ECO 14985 (S/N 1115)
	05	-	ECO 15771 (S/N 4635)
	06		
FA501-C	01	-	ECO 14985, 15043
	01	-	ECO 15771 (S/N 4635)
	02		
FA501-D	01	-	ECO 14985
	01	-	ECO 15771 (S/N 4635)
	02		
BR810-A	01	-	ECOs 14240, 14165, 14328, 14403
	01	-	ECO 14468 (S/N 274)
	02		ECO 14985 (S/N 391)
	03		
BR810-B	01	-	ECOs 14240, 14165, 14328
	01		ECO 14985 (S/N 391)
	02		

MANUAL TO EQUIPMENT LEVEL CORRELATION SHEET (CONTD)

EQUIPMENT TYPE	SERIES	WITH FCO'S	COMMENTS
XA243-A	01		
FT116-A	01		

LIST OF EFFECTIVE PAGES

New features, as well as changes, deletions, and additions to information in this manual are indicated by bars in the margins or by a dot near the page number if the entire page is affected. A bar by the page number indicates pagination rather than content has changed.

PAGE	REV	PAGE	REV	PAGE	REV
Cover	-	6A-5	F	Back Cover	-
WARNING		6A-6 thru 6A-8	G		
Title Page	-				
iiia thru iic	K	PROCEDURES			
iii/iv	J	Section 6B			
v/vi	K	6B-1	C		
vii thru xi	G	6B-2	F		
xii	J	6B-3/6B-4	A		
xiii	G	6B-5 thru 6B-9	G		
PLATO HOTLINE	-	6B-10	A		
1-1 thru 1-4	G				
1-5	F	PARTS DATA FOR			
2-1 thru 2-3	G	PREPRODUCTION			
2-4	F	UNITS ONLY			
3-1 thru 3-4	G	7-1/7-2	A		
3-5	K	7-3/7-4	J		
3-6 thru 3-8	G	7-5/7-6	G		
3-9	F	7-7	J		
4-1/4-2	F	7-8	A		
4-3	C	7-9	J		
4-4	A	7-10	A		
4-5	F	7-11 thru 7-16	C		
4-6/4-7	G	7-17 thru 7-20	E		
4-8	A				
4-9	F	PARTS DATA FOR			
4-10/4-11	A	PRODUCTION UNITS			
4-12	F	ONLY			
4-13	C	7-21 thru 7-30	J		
4-14	F	7-31/7-32	G		
4-15	G	7-33 thru 7-38.10	J		
5-1	A	7-39 thru 7-42	J		
5-2 thru 5-16.2	J				
5-17	J	COMMON PARTS DATA			
5-18 thru 5-22	A	APPLICABLE TO BOTH			
5-23 thru 5-25	K	PREPRODUCTION AND			
6-1 thru 6-3	A	PRODUCTION UNITS			
6-4/6-5	F	7-43 thru 7-47	D		
6-6	A	7-48 thru 7-48.12	J		
6-7	F	7-49/7-50	F		
		7-51/7-52	G		
SAMS Section 6A		7-53 thru 7-55	H		
6A-1	A	7-56 thru 7-61	K		
6A-2	F	8-1	A		
6A-3	C	Comment Sheet	K		
6A-4	A	Mailer	-		



PREFACE

This manual provides information to aid in the installation, checkout, and maintenance of the CDC® PLATO® Flexible Disk Subsystem. Information is provided for both on-site and technical support use. The subsystem provides flexible disk storage capability to an Information Systems Terminal (IST-II and IST-III).

Product number correlation for the various subsystem configurations and associated memory options is as follows:

<u>Equipment Number</u>	<u>Description</u>
FA501-A	Primary Flexible Disk Subsystem, 60 Hz, 120 V ac.
BR810-A	Secondary Flexible Disk Drive, 60 Hz, 120 V ac.
FA501-B	Primary Flexible Disk Subsystem, 50 Hz, 220/240 V ac.
BR810-B	Secondary Flexible Disk Drive, 50 Hz, 220/240 V ac.
FA501-C	Control Data 110 Primary FD Subsystem, 60 Hz, 120 V ac.
FA501-D	Control Data 110 Primary FD Subsystem, 50 Hz, 220/240 V ac.
XA243-A	Additional 16K by 8-bit RAM Option (up to three RAM options may be added to the FA501-A/B). The FA501-C/D has 64K RAM standard.
FT116-A	Terminator assembly for IST parallel I/O channel.

Organization of this manual is divided into eight major sections:

- Section 1 - General Description
- Section 2 - Operation
- Section 3 - Installation and Checkout
- Section 4 - Theory of Operation
- Section 5 - Diagrams
- Section 6 - Maintenance
- Section 7 - Parts Data
- Section 8 - Wire Lists

Other manuals providing reference and operator information on the flexible disk subsystem, maintenance information on the flexible disk drive assembly, and maintenance information on the IST terminal are listed as follows. All manuals may be ordered from:

Control Data Corporation
Literature and Distribution Services
308 North Dale Street
St. Paul, Minnesota 55103

<u>Title</u>	<u>Publication Number</u>
PLATO® Flexible Disk Subsystem Operators Guide	62940005
9406 Flexible Disk Drive Assembly Hardware Maintenance Manual	77614903
Information Systems Terminal II Hardware Maintenance Manual (IST-II)	82100083
Information Systems Terminal III Hardware Maintenance Manual (IST-III)	62940007
Engineering Services Diagnostic Disk for PLATO® Flexible Disk Subsystem Operators Manual	62940015
Control Data 110 Microcomputer System Installation and Diagnostics Manual	62940024
Control Data 110 Software Users Manual	62940025

In addition to these publications, an instructional flexible disk and user's installation guide are available as follows:

Micro Plato Instructional Flexible Disk	76773000 A
Micro Plato User's Installation Guide	76368339

The disk and the guide may be ordered, using an Education Order Form, from:

Order Administrator
Education Company
8100 34th Avenue South
P.O. Box 0
Minneapolis, Minnesota 55440

Diagnostic disks to support CD110 and Micro Plato are available as follows:

CD110 Users Diagnostic Flexible Disk	66314929
Engineering Services Diagnostic Disk	76774999

Control Data Corporation
Software Development and Distribution (ARH230)
4201 Lexington Avenue North
Arden Hills, Minnesota 55112

Or telephone:

Gerald J. Ferber, ARH230,
Software Distribution
Phone 612-482-3744
Control Net 235-3747

The IST II and the IST III have been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines. Instructions for fully complying with Part 68, FCC Docket 19528 can be found in the Site and Support manuals that accompany the particular terminal being used.

CONTENTS

1. GENERAL DESCRIPTION

Subsystem Configuration	1-1
Primary Flexible Disk Subsystem	1-2
Control Data 110 Primary Flexible Disk Subsystem	1-2
Secondary Flexible Disk Drive	1-2
RAM Expansion Feature	1-2
ROM Expansion Feature (Future Availability)	1-2
Media	1-3
Equipment Specifications	1-4

2. OPERATION

Voltage Select Switch	2-1
Power On/Off Switch/Circuit Breaker	2-1
Device Address Strap (Primary Units Only)	2-2
Master Reset Switch (Primary Units Only)	2-2
Diagnostic Control Switches (Primary Units Only)	2-2
Switch 20	2-3
Switch 21	2-3
Switch 22	2-3
Switch 23	2-3
Switch 24 and 25	2-3
Switch 26	2-4
Switch 27	2-4
LED Indicators	2-4

3. INSTALLATION AND CHECKOUT

Packaging	3-1
Installation	3-1.1
Subsystem Installation	3-2
RAM Option Installation	3-6
Checkout	3-7

4. THEORY OF OPERATION

AC Power Entry Panel	4-2
Power Supply	4-2
Backplane	4-3
Flexible Disk Drive (FDD) Assembly	4-4
Controller Board (Primary Units Only)	4-6
Z80A Microprocessor	4-8
9517A-4 Direct-Memory-Access (DMA) Controller	4-8
1791A-02 Flexible Disk Controller (FDC)	4-9
2716 Erasable Programmable Read-Only Memory (EPROM)	4-9
Z80 Counter/Timer Circuit (CTC)	4-10
9519 Interrupt Controller	4-11

External Interface Pin Assignments	4-12
Internal Connector Pin Assignments	4-12

5. DIAGRAMS

Schematic Diagram, 9BED	5-2
Schematic Diagram 9BKD (PFDS Power Supply)	5-18
Schematic Diagram (9BMD) (FDD Controller Backplane)	5-21
50/60 Hz A.C. Power Wiring	5-22
Schematic Diagram (1AFD) (PFDS Power Supply)	5-23

6. MAINTENANCE

General Maintenance Information	6-1
Suggested Emergency Maintenance Procedure	6-1
Before Leaving for Customer Site	6-2
Upon Arriving at Customer Site	6-2
Safety Precautions	6-3
Maintenance Tools and Materials	6-3
MOS Circuit-Handling Precautions	6-3
Maintenance Aids	6-4
Location of Major Assemblies	6-4
Diagnostic and Corrective Maintenance	6-4
Diagnostic Self-Test Routines	6-4
LED Test	6-5
Test 0 - ROM Checksum	6-5
Test 1 - RAM Test	6-6
Test 2 - Interrupt Generator	6-6
Test 3 - Flexible Disk Controller	6-6
Test 4 - DMA Test	6-6
Test 5 - I/O Loopback Test	6-6
Test 6 - CTC Test	6-6
Test 7 - Writing and Reading the Disk	6-7
DIAG Flexible Disk Diagnostic Tests	6-7
Explanation of SAM Format	6-7
Organization of SAMs and Procedures	6-7
Procedure 1 - Power Application/Removal	6B-1
Procedure 2 - Flexible Disk Installation/ Removal	6B-2
Procedure 3 - Front Panel and Cabinet Hood Removal/Replacement	6B-4
Procedure 4 - Controller Board Removal/ Replacement	6B-5
Procedure 5 - Power Supply Removal/Replacement	6B-6
Procedure 6 - Disk Drive Unit Removal/ Replacement	6B-8

7. PARTS DATA

(Pre-Production Units Only)

SPL Primary Flexible Disk Subsystem	7-3
SPL Secondary Flexible Disk	7-5
Genealogy Chart Primary Flexible Disk Subsystem 60 Hz	7-7
Genealogy Chart Primary Flexible Disk Drive 60 Hz . .	7-8
Genealogy Chart Primary Flexible Disk Subsystem 50 Hz	7-9
Genealogy Chart Secondary Flexible Disk Drive 50 Hz	7-10
PLATO Flexible Disk (TLA)	7-11
AC Entry Assy, Flex Disk	7-17

(Production Units Only)

SPL FA501A/C (60 Hz Primary)	7-21
SPL FA501B/D (50 Hz Primary)	7-23
SPL BR810A (60 Hz Secondary)	7-25
SPL BR810B (50 Hz Secondary)	7-27
Genealogy Chart (60 Hz Primary)	7-29
Genealogy Chart (50 Hz Primary)	7-30
Genealogy Chart (60 Hz Secondary)	7-31
Genealogy Chart (50 Hz Secondary)	7-32
PLATO Flexible Disk (TLA)	7-33
CD110 Flexible Disk (TLA)	7-38.5
AC Entry Assembly	7-39

(Common Parts Data)

P.C. Card Assembly, 9BED (Disk Controller)	7-43
P.C. Card Assembly, 9BED-3 (Disk Controller)	7-48.4
P.C. Card Assembly, 9BED w/Full Memory	7-48.8
Card Assembly Controller Module w/Full Memory	7-48.10
P.C. Card Assembly, 9BKD	7-48.12
P.C. Card Assembly, 1AFD	7-52
P.C. Card Assembly, 9BMD	7-60

8. WIRE LISTS

8-1

FIGURES

1. GENERAL DESCRIPTION

1-1	PLATO Flexible Disk Subsystem	1-1
1-2	PFDS Primary and Secondary Unit Details	1-3

2. OPERATION

2-1	Control and Indicator Locations	2-1
-----	---	-----

3. INSTALLATION AND CHECKOUT

3-1	Flexible Disk Subsystem Packaging	3-2.1
3-2	Controller Board Switches and Indicators	3-4
3-3	I/O Cable and Terminator Installation	3-5
3-5	Power Supply Voltage Indicators	3-7

4. THEORY OF OPERATION

4-1	Major Elements of Subsystem	4-1
4-2	Subsystem Block Diagram	4-2
4-3	Drive Assembly Functional Block Diagram	4-5
4-4	Controller Board Block Diagram	4-7
4-5	External Wiring of the CTC for Head-Load Timing	4-10
4-6	External Wiring of the CTC for Real-Time Clock	4-11
4-7	Flexible Disk Interrupt Network	4-12
4-8	Internal Connector Pin Assignments	4-15

6. MAINTENANCE

6-1	Location of Assemblies in Subsystem	6-5
6-2	SAM Example	6-8
6B-1	Power On/Off Switch Location	6B-1
6B-2	Disk Installation/Removal	6B-2
6B-3	Front Panel and Cabinet Hood Mounting Details .	6B-4
6B-4	Controller Board Layout	6B-5
6B-5	Power Supply Voltage Adjustments	6B-7
6B-6	Disk Drive Unit Installation	6B-9
6B-7	Drive Pulley Details	6B-10

TABLES

1. GENERAL DESCRIPTION

1-1	Equipment Specifications	1-4
-----	------------------------------------	-----

4. THEORY OF OPERATION

4-1	Parallel I/O Channel Pin Assignments	4-13
4-2	Secondary Drive Unit Channel Pin Assignments .	4-14

7. PARTS DATA

7-1	Explanation of Column Headings on Assembly Parts Lists	7-1
-----	---	-----




Should difficulties be encountered in installing, testing, or running this equipment, you may obtain assistance by contacting your CDC sales representative for the telephone number applicable to your installation. After obtaining the number, write it here for future reference:

TELEPHONE NUMBER _____



This section provides a general description of the PLATO Flexible Disk Subsystem (PFDS) configuration including the related equipment specifications. The PFDS is a Z80 microprocessor-based programmable storage subsystem that is intended for use by an Information Systems Terminal. The subsystem interfaces with the terminal via the PLATO parallel I/O channel. Refer to figure 1-1 for an exterior view of the subsystem.



03892

Figure 1-1. PLATO Flexible Disk Subsystem

SUBSYSTEM CONFIGURATION

The PFDS is configured as two basic versions:

- Primary Flexible Disk Subsystem
- Secondary Flexible Disk Drive

Each version is available as either a 60-Hz or 50-Hz product/equipment. Refer to the preface for product/equipment number correlation.

The subsystem can consist of a single primary unit or a primary unit and one secondary unit. The two units (primary and secondary) are interfaced by attaching the signal lines of both 9406 Disk Drives together via a 50-pin interconnecting I/O cable. The net effect is that the controller logic board of the primary unit is interfaced to both 9406 Disk Drives connected in parallel as shown in figure 1-2.

PRIMARY FLEXIBLE DISK SUBSYSTEM

The Primary Flexible Disk Subsystem contains a CDC 9406 Flexible Disk Drive, a 50-Hz or 60-Hz ac power entry panel, a mother-board backplane, a dc power supply, and a Z80-based controller logic board.

CONTROL DATA 110 PRIMARY FLEXIBLE DISK SUBSYSTEM

The Control Data 110 Primary Flexible Disk Subsystem contains a CDC 9406 Flexible Disk Drive, a 50-Hz or 60-Hz ac power entry panel, a mother-board backplane, a dc power supply, and a Z80-based controller logic board with 64K of RAM.

SECONDARY FLEXIBLE DISK DRIVE

The Secondary Flexible Disk Drive is identical to a primary unit except that the Z80-based controller logic board is removed.


RAM EXPANSION FEATURE

The standard subsystem random-access memory consists of 16K 8-bit words in the FA501-A/B. The RAM size may be expanded to a total of 64K 8-bit words in 16K-word increments. Each 16K RAM option consists of eight 16-pin integrated circuits (ICs). IC sockets are provided on the controller logic board for installation of the RAM chips. The FA501-C/D has 64K as standard.

MEDIA

The recommended media for use in the subsystem is a good commercial flexible disk (double-sided, double-density). These flexible disks have the following characteristics:

- Index - 1
- Sectors - Programmable
- Cylinders - 77
- Tracks per cylinder - 1 for single-sided disk, 2 for double-sided disk.
- Surfaces - 2
- Tracks per inch 48
- Bits per inch - 6816 double density



03798-1

- *The other device could be another Primary Flexible Disk Subsystem, Graphic Printer, etc.
 **These connectors are not used.

Figure 1-2. PFDS Primary and Secondary Unit Details

EQUIPMENT SPECIFICATIONS

Equipment specifications for the subsystem are listed in table 1-1.

TABLE 1-1. EQUIPMENT SPECIFICATIONS

CHARACTERISTIC	SPECIFICATION
Dimensions: Height Width Depth	202.85 mm (7.99 in) 381 mm (14.99 in) 502.5 mm (19.78 in)
Weight: FA501-A/C (60-Hz primary) FA501-B/D (60-Hz primary) BR810-A (60-Hz secondary) BR810-B (50-Hz secondary)	16.78 kg (37 lb) maximum 20.19 kg (44.51 lb) maximum 16.33 kg (36 lb) maximum 19.73 kg (43.5 lb) maximum
Power Requirements: (Nominal) FA501-A/C FA501-B/D BR810-A BR810-B	120 V ac, 60 Hz, 1.4 A, 0.18 kW maximum 220/240 V ac, 50 Hz, 0.8 A, 0.19 kW maximum 120 V ac, 60 Hz, 1.2 A, 0.16 kW maximum 220/240 V ac, 50 Hz, 0.68 A, 0.16 kW maximum
Temperature: Operating Nonoperating Change/h	10°C to 32°C (50°F to 90°F) -34°C to 66°C (-30°F to 150°F) 6.7°C (12°F)
Relative Humidity: Operating Nonoperating Change/h	10% to 80% 5% to 95% 10%
Operating Altitude:	3000 m (9850 ft) maximum
Heat Dissipation (Air):	555 Btu/h (161.3 W) maximum, fan cooled

TABLE 1-1. EQUIPMENT SPECIFICATIONS (CONTD)

CHARACTERISTIC	SPECIFICATION
Disk Storage Capacity:*	<u>Double Density</u>
Bytes/Track	10 416
Bytes/Cylinder**	20 832
Bytes/Surface	802 032
Bytes/Disk**	1 604 064
Bits/Byte	8
Transfer Rate:*	<u>Double Density</u>
	500 k b/s
	62.5 bytes/s
Seek Time:	3 ms
Head Stabilization Time:	20 ms
Head Load Time:	40 ms
Disk Rotation:	360 r/min $\pm 3.5\%$
Latency:	
Maximum	166.7 ms
Average	83.3 ms
Recording Method:	Modified Frequency Modulation (MFM)
<p>*Storage capacity and data transfer rates are a function of the formatting used on the disk and the programming of the controller.</p> <p>**Applies to double-sided disk only.</p>	



This section describes the controls and indicators of the flexible disk subsystem. Locations are shown in figure 2-1. Refer to the Micro Plato user's installation guide and Micro Plato instructional flexible disk or the Control Data 110 Microcomputer System User Installation and Diagnostics Manual for information on associated operating programs (see preface for publication/part numbers).




Figure 2-1. Control and Indicator Locations

VOLTAGE SELECT SWITCH

The voltage select switch is present on 220/240-V, 50-Hz units only. The switch is located on the bottom of the cabinet and selects taps on the transformer primary winding to match the input site voltage available. A metal plug covers the access hole.

POWER ON/OFF SWITCH/CIRCUIT BREAKER

Two versions of the Power On/Off switch/circuit breaker exist. Early units have the switch/circuit breaker mounted toward the

rear of the unit with a connecting rod attached to a push/pull control knob at the front of the unit. Power is applied by pulling the knob forward and power is removed by pressing the knob in. Later units have a rocker switch/circuit breaker mounted on the front of the unit.

A power application initializes all internal control logic circuits, and if bit 27 of the diagnostic control switches is down, initiates the self-test diagnostics.

The circuit breaker provides necessary overload protection for the subsystem.

DEVICE ADDRESS STRAP (PRIMARY UNITS ONLY)

The subsystem device address is wired to position 7 by the device address strap at the front of the controller board. In early units the subsystem device address is established by a 10-position binary-coded-decimal rotary switch at the front of the controller board.

MASTER RESET SWITCH (PRIMARY UNITS ONLY)

Pressing the Master Reset switch reinitializes the operating program. Holding the switch pressed more than three seconds, reinitiates the self-test diagnostics (if selected), and reloads the operating program into RAM memory. The operating program is loaded from the flexible disk if available. If a flexible disk is not present, the flexible disk subsystem tries to load from the PLATO system.

DIAGNOSTIC CONTROL SWITCHES (PRIMARY UNITS ONLY)

There are eight switches on the front of the controller board that provide manual control of the program and self-test diagnostics. Diagnostic test descriptions are provided in section 6. Control functions selected by these switches are as follows:

SWITCH 20 - Not used

SWITCH 21

- Up - Allows result of detailed memory test to be displayed in LEDs per switch 22 setting.
- Down - Bypasses displaying result of detailed memory test selected by switch 22.

SWITCH 22

- Up - Allows failing memory IC within a RAM bank to be displayed in LEDs. Switch 21 must be in up position to view this display. Also note that for subsystems having more than 16K of RAM, failing memory bank must first be determined by having switch 22 down.
- Down - Allows failing memory bank to be displayed in LEDs. Switch 21 must be in up position to view this display.

SWITCH 23

- Up - Bypasses test 7 (write/read on disk) of diagnostics.
- Down - Enables execution of diagnostic test 7.

SWITCH 24 and 25

These switches define what banks of RAM are installed:

<u>Switch 25</u>	<u>Switch 24</u>	<u>RAM BANKS AVAILABLE</u>	<u>ADDRESS RANGE (HEX)</u>
Down	Down	1 (16K)	4000 - 7FFF
Down	Up	1, 2 (32K)	4000 - BFFF
Up	Down	1, 2, 3 (48K)	4000 - FFFF
Up	Up	0, 1, 2, 3 (64K)	0000 - FFFF

All FA501-C/D units have 64K RAM; both switches 24 and 25 must be up.

SWITCH 26

- Up - Allows looping on diagnostic tests.
- Down - Does not loop on diagnostics.

SWITCH 27

- Up - Bypasses diagnostic test execution.
- Down - Enables execution of the diagnostics except when switch 20 is up.

LED INDICATORS

Primary units have four red LED indicators on the controller board that are visible through holes in the front panel. The LEDs are used by the self-test diagnostics to indicate detected errors. LED 23 (leftmost) indicates a diagnostic error and LEDs 20 through 22 identify the failing memory bank or IC as determined by the settings of switch 20, 21, 22, and 27 of the diagnostic control switches.* At successful completion of the diagnostics, LED 20 is assigned as the power-on indicator. These LEDs are also user programmable.**

Both primary and secondary units have four red voltage LEDs on the power supply PC board. The front panel must be removed to view the indicators. These LEDs indicate presence of +24 V, +12 V, +5 V, and -5 V at the power supply outputs. Note that a lit LED does not conclusively indicate that the correct voltage is present, only that there is sufficient voltage to bias the device on.

Two adjustment potentiometers are also on the power supply PC board. These provide for adjusting the +24-V and +5-V power supply outputs.

*LEDs 20 through 22 define which test section has failed. If diagnostic control switch 21 is up and there is a memory error, then LEDs 20 through 22 identify the failing memory bank or IC depending on setting of switch 22.

**After completion of the self-test diagnostics, the operating system uses LED 23 as an Error indicator, LED 22 as a Read indicator, LED 21 as a Write indicator, and LED 20 as a Power-on indicator.

This section provides information on packaging, installation, and checkout of the flexible disk subsystem.

CAUTION

Control Data 110 Terminal Subsystem users must use installation, checkout, and diagnostics procedures described in Control Data 110 Microcomputer System User Installation and Diagnostics Manual.

CAUTION

Observe MOS circuit handling precautions (described in section 6 of this manual) when handling or packaging the controller board.

PACKAGING

The flexible disk subsystem is packaged for shipment using foam-in-place chemicals (figure 3-1). If the subsystem is to be reshipped it must be packaged as it was originally received from the factory. Use the existing packing materials or if not available, order new packing materials from CDC Corporate Traffic. Request pre-formed packing materials for the FA501/BR810 per packing instructions 41039800. Packaging materials may be obtained from:

Control Data Corporation
Corporate Traffic
8100 34th Avenue South
Minneapolis, Minnesota 55440

When returning other assemblies for repair, use the packaging material that the spared assembly was shipped in.

NOTE


When shipping any disk drive be sure to insert the cardboard head-protect flexible disk into the drive unit.

INSTALLATION

This subsection provides information for installing the flexible disk subsystem (primary and secondary units) and for field installation of the RAM options if applicable to the primary unit.

NOTE

Selective FCO CD14283 must be installed if the disk is to be used on an IST-II with a serial number below 3000. This FCO provides a new ROM with a disk loader. The part number for FCO CD14283 is 66202932.



03896-1

Figure 3-1. Flexible Disk Subsystem Packaging

SUBSYSTEM INSTALLATION

Install the flexible disk subsystem per the following. Procedure numbers used in the steps refer to specific procedures contained in section 6B of this manual.

1. Unpackage subsystem (refer to figure 3-1), and move to desired location. Remove cardboard head-protective flexible disk from drive unit and store with subsystem packaging materials. Note that secondary unit may be stacked on top of primary unit or primary unit may be stacked on top of secondary unit or units may be placed side-by-side if desired.
2. Inspect for any shipping damage.
3. For 50-Hz units, verify that Voltage Select switch (bottom of cabinet, metal plug covers access hole) is set



correctly to match site ac primary input voltage as follows:

<u>Switch Position</u>	<u>Voltage Range</u>
120 V	Not Used
220 V	191 V to 235 V
240 V	208 V to 257 V

NOTE

Cover unused voltage designation on ID plate (figure 3-4) with black tape.

4. This step applies to primary flexible disk units only. Remove front panel of unit (procedure 3) and locate switches at front of controller board (figure 3-2).
- Check that device address strap is wired to address 7 as in figure 6B-4. (Set device address switch to address 7 if unit has switch.)
- Set Diagnostic Control Switches as follows:

Switch 2⁰ - Not used

Switch 2¹ - Down (bypasses displaying result of detailed memory test selected by switch 2²).

NOTE

Switch 2¹ must be down to display the failing test number in the LEDs. If a test 1 (memory test) failure is detected, place switch 2¹ up to display the specific memory bank or IC failure as selected by switch 2².

Switch 2² - Down (allows failing memory bank to be displayed in LEDs).

Switch 2³ - Up (disables running test 7 of resident diagnostics).

Switch 2⁴ and 2⁵ - For FA501-C/D set both switches up. For FA501-A/B set to RAM memory size available as follows (each XA243-A option adds 16K of RAM):

<u>Switch 2⁵</u>	<u>Switch 2⁴</u>	<u>RAM Size</u>
Down	Down	16K (Standard)
Down	Up	32K (Option)
Up	Down	48K (Option)
Up	Up	64K (Option)

Switch 26 - Down (does not loop on diagnostics).

Switch 27 - Down (enables running diagnostic tests).




Figure 3-2. Controller Board Switches and Indicators

5. Refer to figure 3-3 and install I/O cable and terminator assembly per the following as applicable:

NOTE

A standard 25-pin RS-232-C compatible cable CANNOT be substituted for the specified I/O cable.

- Primary flexible disk unit - If there are no other devices attached to IST parallel interface channel, connect 25-pin I/O cable (CDC 61408865) from parallel interface channel of IST terminal to either 25-pin I/O connector at rear of flexible disk unit. Connect terminator assembly (type FT116-A) to other 25-pin I/O connector of drive unit. Tighten retaining screws to hold cable connectors in place.

If other devices are already attached to IST parallel interface channel, remove terminator assembly from last device on channel and connect 25-pin I/O cable (CDC 61408865) between last device and either 25-pin connector at rear of flexible disk unit. Install the terminator assembly to other I/O connector of drive unit. Tighten retaining screws to hold cable connectors in place.

- Secondary flexible disk unit - Connect 50-pin I/O cable (CDC 61408976) between 50-pin connectors of primary and secondary flexible disk units. Note that 25-pin I/O connectors are not used on secondary unit.
- Verify that no flexible disk is installed in drive unit(s).




Figure 3-3. I/O Cable and Terminator Installation

6. Connect ac power cord to rear of unit, check that power on/off switch is in off position and plug ac line cord into site outlet.

WARNING

Applying improper voltage to the flexible disk subsystem can damage components. Read label on back of unit for proper voltage and frequency.

RAM OPTION INSTALLATION (Applies to FA501-A/B Only)

Perform the following steps to install a 16K by 8-bit RAM option (XA243-A). Up to three RAM options can be installed in a primary unit to expand the memory size to a total of 64K 8-bit words. Observe MOS circuit handling precautions described in section 6 when installing RAM ICs.

1. Remove controller board from unit.
2. Install RAM ICs in existing sockets on controller board as follows:
 - First RAM option in locations C1, C2A, C2B, C3, C4A, C4B, C5, and C6.
 - Second RAM option in locations D1, D2A, D2B, D3, D4A, D4B, D5, and D6.
 - Third RAM option in locations A1, A2A, A2B, A3, A4A, A4B, A5, and A6.
3. Set Diagnostic Controls Switches 2⁴ and 2⁵ to total RAM size available (see step 4 of Subsystem Installation for required switch settings).
4. Reinstall controller board in unit.
5. Affix FCO log and equipment identification tag to rear of unit as shown in figure 3-4.




Figure 3-4. RAM Option FCO Log and ID Tag Placement

CHECKOUT

Perform the following steps to checkout the operational capability of the flexible disk subsystem including any installed options. If any problems are encountered, refer to the SAM listings in section 6A for corrective action.

1. Apply power to disk subsystem (procedure 1) and verify that four LEDs on power supply are lit (figure 3-5).
2. Observe four LEDs at front of controller board (figure 3-2). Immediately after turning power on (at start of diagnostic test execution) all four LEDs are turned on for a short period of time as an LED test. As the self-test diagnostic executes, the lower three LEDs indicate which test is in process. LED 2³ lit indicates a diagnostic test error. Note that with no flexible disk installed, LEDs 2⁰, 2¹, and 2² should be lit and LED 2³ should be unlit indicating that diagnostic is at test 7 but drive is not ready.




Figure 3-5. Power Supply Voltage Indicators

3. Install Micro Plato instructional flexible disk (CDC part number 76773000 A) in drive unit (procedure 2). This initiates write/read checks of test 7 (last resident diagnostic test). Upon successful completion, LED 2⁰ remains lit and functions as a power-on indicator.
4. Remove Micro Plato instructional flexible disk from drive unit.
5. Verify that power is applied to last peripheral device connected to parallel interface channel. Note that last device must be powered on for correct operation of parallel interface channel as this device provides +5 volts to terminator.
6. Load and execute DIAG Flexible Disk Diagnostics from IST terminal as follows:

NOTE

For FA501-A/B terminals, the DIAG Flexible Disk Diagnostics only work with terminals having a 16K memory option.

NOTE

There are two modes of operation in the flexible disk subsystem that allow the terminal to load information into subsystem memory. One mode is via DMA operations and the other mode is via interrupt routines. Both operating modes are tested by the DIAG Flexible Disk Diagnostics.

For terminal log-in or diagnostic loading problems, refer to the applicable terminal hardware maintenance manual (see preface for publication number).

- a. Log into PLATO system by use of procedures outlined in Information System Terminals II and III manuals (see Preface for publication numbers).
- b. Select the Flexible Disk Diagnostic found under DIAG.
- c. Follow the DIAG instructions for test desired.

7. After successful completion of preceding tests, check that all diagnostic control switches on controller board are set as required and reinstall front panel of unit (procedure 3). If Micro Plato instructional flexible disk (CDC part number 76773000 A) is being used, additional testing can be performed through use of stored programs on this disk. Refer to Micro Plato User's Installation Guide for test information (see preface for publication number).




This section provides a functional description of the five major elements of the flexible disk subsystem:

- AC Power Entry Panel
- Power Supply
- Backplane
- Flexible Disk Drive (FDD) Assembly
- Controller Board (Primary Units Only)

Also provided are the connector pin assignments for the external parallel I/O channel and secondary flexible disk unit interfaces, and the connector pin assignments for the internal signals of the flexible disk subsystem.

Refer to figure 4-1 for location of the major elements within the subsystem and to figure 4-2 for a block diagram of the subsystem configuration.



03927-1

NOTE: COVER AND FRONT
PANEL REMOVED
FOR CLARITY.

Figure 4-1. Major Elements of Subsystem




Figure 4-2. Subsystem Block Diagram

03797

AC POWER ENTRY PANEL

The ac power entry panel contains an RFI line filter and a detachable ac power cord. A separate ac power entry panel is used for the 60-Hz and 50-Hz equipments. The 50-Hz panel also contains a step-down transformer and a 220/240-volt selector switch. Early versions of both the 60-Hz and 50-Hz panels contained the primary power circuit breaker. Later versions have the circuit breaker mounted at the front of the unit.

POWER SUPPLY

The power supply is a switching supply contained on a single PC card. Input voltage is 120 V ac nominal. The 50-Hz units require an external step-down transformer (provided by the 50-Hz ac entry panel) to lower the 220-V/240-V ac input voltage to 120 V. The power supply provides the following nominal dc output voltages and full-load currents:

- +12 V at 0.45 A
- -5 V at 0.1 A
- +5 V at 5 A
- +24 V at 2 A

The power supply is divided into two basic sections, a +24-V section, and a logic voltage section for the +12-V, +5-V, and -5-V output voltages. All dc outputs have over-current protection and are not damaged by short circuits. The +5-V output has an over-voltage sensing circuit that shuts off all outputs when the +5-V output rises between +5.5 V to +6.0 V. No other outputs have over-voltage protection.

The input ac line voltage is full-wave rectified and is chopped at a high-frequency rate (25 to 40 kHz) through the primary of the input transformer by a switching transistor. The transformer steps down the high-frequency ac to the secondary windings. These ac voltages are then rectified and filtered to provide the various power supply outputs.

Voltage control is performed in each power supply section by a regulator IC that compares a sample of the output voltage to an internal reference voltage. A resulting error difference is used to control the conduction time of a switching transistor through an optical coupler. Only the +24-V and +5-V output voltages are sensed to control the switching transistor pulse width in their respective power supply section. All other outputs have 3-pin IC regulators to regulate their output voltages.

The power supply contains four red board-edge LEDs that indicate the presence of the +24-V, +12-V, +5-V, and -5-V outputs. Two adjustment potentiometers are also provided for adjusting the +24-V and +5-V outputs. Test points on the board edge of the controller board are to be used when performing the +5-V alignment procedure. The +12-V, +5-V, and -5-V test points are available on the controller board edge.

BACKPLANE

A printed-circuit mother-board backplane provides the internal signal and power connections for the various modules of the disk subsystem and provides the external I/O channel interface connections.

FLEXIBLE DISK DRIVE (FDD) ASSEMBLY

The flexible disk drive (FDD) assembly is a random-access, data-storage device that writes and reads data from a rotating flexible disk. All input/output data and control operations are performed under microprocessor control from the controller board. The basic function of the drive assembly is to indicate to the controller when it is ready for operation, and respond to controller commands to:

- Receive and generate control signals
- Position the read/write heads to selected tracks
- Write or read data on the flexible disk when selected

Signals received and transmitted by the FDD are shown in figure 4-3. All signals received by the FDD are gated with Unit Select so that no stepping, reading, or writing can be performed on an unselected FDD. Also, all signals generated within the FDD, except the Ready signal, are gated with Unit Select so that no signals can be transmitted from an unselected FDD.


Controller Step and Direction commands initiate a track-seek operation on a selected FDD. The FDD transmits Index pulses as long as it is selected. The selected FDD also transmits a Track 00 signal to the controller whenever the read/write heads are at Track 00.

Positioning of the carriage-mounted read/write heads is accomplished by a band-driven stepper motor. Each step command increments the stepper motor which moves the band. The band increments the read/write heads one track position for each step command.

During a write operation, the selected FDD receives Head Select, Write Enable, Write Data, and Low Current (Track 43 or greater) signals. If a write fault occurs, a Write Fault signal is transmitted to the controller. During a read operation, the selected FDD receives a Head-Load command. The Write Enable line remains high thereby specifying a read operation and the FDD transmits Composite Read Data signals to the controller.

A read or write operation begins by placing the read/write heads in contact with the flexible disk with a Head-Load command at the desired track. To write on the disk, a Write Enable is sent by the controller to condition the write logic. The write current then in the head reverses polarity synchronously with

the low-to-high transitions of the Write-Data pulses from the controller. The current reversals cause magnetic flux reversals on the desired disk track. Erasure of previously recorded data is simultaneously accomplished during the writing operation in addition to a delayed-tunnel erase, which ensures disk interchangeability.



03856-1

Figure 4-3. Drive Assembly Functional Block Diagram

To read from the flexible disk, magnetized bits in the format of the pre-recorded data are sensed by the read/write heads. This signal is amplified, digitized, and transmitted to the controller.

Refer to the 9406 Flexible Disk Drive Assembly Hardware Maintenance manual for additional information (see preface for publication number).

CONTROLLER BOARD (PRIMARY UNITS ONLY)

The controller board is present only in the primary units. A single controller board provides control and directs all operations of both a primary and optional secondary unit. This is accomplished by interfacing the controller board to both 9406 Disk Drive assemblies (primary and secondary) connected in parallel via an external 50-pin signal cable.

Large-scale integrated circuits (LSI) are used in all major areas of the controller's operation. This includes:

- A Z80A microprocessor clocked at 4 MHz.
- A 9517A-4 direct-memory-access (DMA) controller.
- A 1791A-02 flexible-disk controller (FDC).
- Two 2716 (2K by 8-bit) eraseable programmable read-only memories (EPROM).
- A Z80 Counter/timer circuit (CTC).
- A 9519A interrupt controller.
- 16K by 8-bit bytes of random access memory (RAM). IC sockets are available for expansion to 64K by 8-bits for the FA501-A/B.
- 64K by 8-bit bytes of random access memory (RAM) for the FA501-C/D.
- Three 74LS374 8-bit data latches for I/O data, status, and commands.

The controller board also includes eight switches that can be read by the microprocessor for control and option-available information, a device address strap for the PLATO parallel I/O channel, a master reset switch that provides its status to the control program, and four LEDs that provide visual status indications.

A detailed block diagram of the controller board is shown in figure 4-4. The following paragraphs describe the major logic circuits. Refer to the applicable vendor manuals for details of operation as required.




Figure 4-4. Controller Board Block Diagram

Z80A MICROPROCESSOR

A Z80A microprocessor is used as the major control element of the module. The Z80 provides three major buses (16-bit address bus, 8-bit bi-directional data bus, 13-line control bus); 158 different instructions; 208 bits of read/write memory; two sets of data, control, and address registers; an arithmetic and logic unit (ALU); and necessary instruction decode and control logic.

As each instruction is read from memory, it is placed in an instruction register and decoded. The internal control logic performs this function and then generates all the necessary control signals to read/write data from or to the registers, controls the ALU, and provides all required external control signals.

All instructions are executed by stepping through a specific series of basic control operations applicable to a given instruction.

Each basic control operation - such as OP code fetch, memory read, memory write, etc. - takes from three to six clock periods to complete and may be lengthened to synchronize the CPU to the speed of external devices. The additional clock periods are termed wait states and increase the total instruction execution time accordingly. The CPU examines the Wait line during T2 (and every subsequent TW) of each machine cycle and adds in a wait state of one clock period if the Wait signal is active.

Accessing RAM memory on the controller board does not require any addition of wait states. The EPROM memory, used only for the initial power-on diagnostics and autoloading, requires the addition of one wait state for each memory reference. The 1791A flexible disk controller requires one wait state for each reference made to it by the Z80. The Write Fault Reset to the 9406 Flexible Disk Drive assembly requires one wait state.

9517A-4 DIRECT-MEMORY-ACCESS (DMA) CONTROLLER

The 9517A-4 direct-memory-access (DMA) controller is a peripheral interface IC that allows direct memory access to the subsystem RAM. Four independent DMA channels are provided. Each channel is designed to enable an external device to transfer information to or from the subsystem memory. In the flexible disk subsystem design, however, only three channels are wired for external device use. Channels 1 and 3 are both used by the 1791 flexible disk controller IC, and channel 2 is used by the PLATO parallel I/O channel. Channel 0 is not used.

Separate internal registers are provided in each channel for mode control, current address, base address, current word count, and base word count.

1791A-02 FLEXIBLE DISK CONTROLLER (FDC)

The 1791A-02 flexible disk controller (FDC) performs the functions of a flexible disk formatter and controller in a single integrated circuit. The FDC controls both single-density and double-density formatting. The FDC provides a 16-bit cyclic redundancy check (CRC) with the polynomial: $G(X) = X^{16} + X^{12} + X^5 + 1$. The IC is designed for bidirectional one's-complemented data transfers. Therefore, all commands sent to the FDC, and status read from the FDC, must be transmitted and received by the Z80 as one's-complemented data. Data is complemented when written on the flexible disk and complemented when read off the flexible disk. Therefore, true data written to the FDC is also read from the FDC as true data.

It is possible to read and write to/from the FDC on a byte-by-byte basis for single-density storage. However, to operate in double density it is necessary to use the 9517A-02 DMA controller to maintain the proper data rate for flexible disk read/write operations.

2716 ERASABLE PROGRAMMABLE READ-ONLY MEMORY (EPROM)

The 2716 EPROM is a 16 384-bit (2K by 8-bit) ultraviolet erasable and electrically programmable read-only memory. The read access time for the IC is 450 ns. The standard subsystem EPROMs uses memory addresses 0000_{16} through $0FFF_{16}$.

The stored program in the EPROMs provides subsystem diagnostics that include LED testing, ROM checksum, LSI device testing, memory testing, disk read/write testing, autoloader, and initial PLATO parallel I/O channel interfacing with the host terminal.

Z80 COUNTER/TIMER CIRCUIT (CTC)

The Z80 counter/timer circuit is a programmable IC with four 8-bit internal independent channels that provide counting and timing functions under control of the Z80 microprocessor. The Z80 can configure the CTC channels to operate under various modes and conditions as required. In either timer or counter mode, an 8-bit, Z80-readable down-counter indicates the number of counts-to-go until zero. Interrupts can be programmed to occur on the zero count of any channel. The interrupt logic provides automatic interrupt vectoring.

All four of the counter timer circuits have external enables that can be selected by the Z80. Three of the counters have count-zero outputs. Two of the outputs are wired to the inputs of two of the other counters. This provides the ability to cascade the network into two 8-bit counters or essentially one 16-bit counter for each two CTCs used. Each of the CTCs used as an enable to one of the other has an external logic signal wired to its own input (figure 4-5). One external input is the Head-Down-Load (HDL) signal that indicates the disk was instructed to lower its read/write head. The counters can then be programmed to time out the mechanical delay that will take place in the 9406 drive (approximately 40 milliseconds). The zero-count output is sent to the 1791 flexible disk controller IC as a status bit. This status input means that the read/write head should be on the disk surface. This status bit is called Head-Load Timing (HLT).




Figure 4-5. External Wiring of the CTC for Head-Load Timing

The other two CTCs of the integrated circuit are wired to allow them to be used for timing as a real-time clock. There is a circuit in the power supply that generates a pulse for every period of line voltage that occurs. This pulse is wired to the input of one of the CTCs (CTC2). The output of this CTC (CTC2) is wired as the input of the fourth CTC (CTC3). Together, these two CTCs provide a programmable down-counter 16 bits long (figure 4-6).




Figure 4-6. External Wiring of the CTC for Real-Time Clock

Note that it is possible to use the four CTC circuits in the CTC IC as four distinct timers by ignoring the input enables (selected only by program control) and use the four CTCs to count down the 4-MHz clock input to the IC.

9519 INTERRUPT CONTROLLER

The 9519 interrupt controller can manage up to eight maskable interrupt request inputs, resolve priorities, and supply up to four bytes of programmable response for each interrupt. The controller board only uses seven of these interrupts. They are:

- IREQ7 Not Used
- IREQ6 Line Clock
- IREQ5 DMA End of Processes
- IREQ4 1791 FDC Interrupt
- IREQ3 Parallel I/O Data Out (to the terminal)
- IREQ2 Parallel I/O Data In (from the terminal)
- IREQ1 Read Status (to the terminal)
- IREQ0 Write Command (from the terminal)

The interrupt network is shown in block diagram form in figure 4-7.




Figure 4-7. Flexible Disk Interrupt Network

EXTERNAL INTERFACE PIN ASSIGNMENTS

Tables 4-1 and 4-2 list the external interface pin assignments for the parallel I/O channel and secondary drive unit channel, respectively. Both of the interfaces use standard TTL-to-TTL circuits and logic levels. For external signal definitions, refer to the applicable hardware maintenance manual listed in the preface.

INTERNAL CONNECTOR PIN ASSIGNMENTS

Figure 4-8 shows the internal connector pin assignments for the flexible disk subsystem. For signal definitions, refer to the 9406 Flexible Disk Drive Hardware Maintenance Manual (publication number is listed in the preface).

TABLE 4-1. PARALLEL I/O CHANNEL PIN ASSIGNMENTS

Signal	In/Out	Active Level	Pin Number
Data 2 ⁰	Both	High	J6, J7-15
Data 2 ¹	Both	High	J6, J7-16
Data 2 ²	Both	High	J6, J7-17
Data 2 ³	Both	High	J6, J7-18
Data 2 ⁴	Both	High	J6, J7-21
Data 2 ⁵	Both	High	J6, J7-22
Data 2 ⁶	Both	High	J6, J7-23
Data 2 ⁷	Both	High	J6, J7-24
+5 V (Terminator only)			J6, J7-13
Address 2 ⁰	In	High	J6, J7-2
Address 2 ¹	In	High	J6, J7-3
Address 2 ²	In	High	J6, J7-4
Address 2 ³	In	High	J6, J7-5
Address 2 ⁴	In	High	J6, J7-6
Not Used (in this device)			J6, J7-7
Not Used (in this device)			J6, J7-9
-External Write	In	Low	J6, J7-8
-External Read	In	Low	J6, J7-10
-External Interrupt	Out	Low	J6, J7-12
Not Used (in this device)			J6, J7-11
Ground			J6, J7-1
Ground			J6, J7-14
Ground			J6, J7-19
Ground			J6, J7-20
Ground			J6, J7-25

TABLE 4-2. SECONDARY DRIVE UNIT CHANNEL PIN ASSIGNMENTS

Signal	In/Out	Active Level	Pin Number*
-Read Data Composite	In	Low	J5-2
-Head Load	Out	Low	J5-4
-Track 00	In	Low	J5-6
-Index	In	Low	J5-8
-Low Write Current	Out	Low	J5-10
-Step	Out	Low	J5-12
-Direction (Increase)	Out	Low	J5-14
-Write Enable	Out	Low	J5-16
-Write Data	Out	Low	J5-31
-Unit Select 1	Out	Low	J5-33
-Unit Select 2	Out	Low	J5-29
-Unit Ready Status 1	In	Low	J5-50
-Unit Ready Status 2	In	Low	J5-48
-Write Protect	In	Low	J5-42
-Head Select (low = head 1; high = head 0)	Out	Low	J5-40
-Write Fault	In	Low	J5-38
-Write Fault Reset	Out	Low	J5-36
-Diskette Type (Two Sided)	In	Low	J5-34

*Pins 1, 3, 5, 7, 9, 11, 13, 15, 17, 18, 20, 22, 24, 26, 28, 30, 32, 35, 37, 39, 41, 43, 45, 47, and 49 are at logic ground; pins 19, 21, 23, 25, 27, 44, and 46 are open.





Figure 4-8. Internal Connector Pin Assignments



DIAGRAMS

This section contains logic and schematic diagrams for the controller board (9BED), power supply (9BKD), backplane (9BMD), and ac power wiring of the flexible disk subsystem. For logic diagrams on the drive unit, refer to the 9406 Flexible Disk Drive Hardware Maintenance Manual (publication number is listed in the preface).


REVISION RECORD												
REV	DATE	DESCRIPTION	CO	REV	DATE	DESCRIPTION	CO	REV	DATE	DESCRIPTION	CO	REV
1	10/10/80	RELEASE CLASS	1	2	11/10/80	RELEA = D CLA	1	3	11/10/80	RELEA = D CLA	1	4
5	11/10/80	RELEA = D CLA	1	6	11/10/80	RELEA = D CLA	1	7	11/10/80	RELEA = D CLA	1	8
9	11/10/80	RELEA = D CLA	1	10	11/10/80	RELEA = D CLA	1	11	11/10/80	RELEA = D CLA	1	12
13	11/10/80	RELEA = D CLA	1	14	11/10/80	RELEA = D CLA	1	15	11/10/80	RELEA = D CLA	1	16
17	11/10/80	RELEA = D CLA	1	18	11/10/80	RELEA = D CLA	1	19	11/10/80	RELEA = D CLA	1	20
21	11/10/80	RELEA = D CLA	1	22	11/10/80	RELEA = D CLA	1	23	11/10/80	RELEA = D CLA	1	24
25	11/10/80	RELEA = D CLA	1	26	11/10/80	RELEA = D CLA	1	27	11/10/80	RELEA = D CLA	1	28
29	11/10/80	RELEA = D CLA	1	30	11/10/80	RELEA = D CLA	1	31	11/10/80	RELEA = D CLA	1	32
33	11/10/80	RELEA = D CLA	1	34	11/10/80	RELEA = D CLA	1	35	11/10/80	RELEA = D CLA	1	36
37	11/10/80	RELEA = D CLA	1	38	11/10/80	RELEA = D CLA	1	39	11/10/80	RELEA = D CLA	1	40
41	11/10/80	RELEA = D CLA	1	42	11/10/80	RELEA = D CLA	1	43	11/10/80	RELEA = D CLA	1	44
45	11/10/80	RELEA = D CLA	1	46	11/10/80	RELEA = D CLA	1	47	11/10/80	RELEA = D CLA	1	48
49	11/10/80	RELEA = D CLA	1	50	11/10/80	RELEA = D CLA	1	51	11/10/80	RELEA = D CLA	1	52
53	11/10/80	RELEA = D CLA	1	54	11/10/80	RELEA = D CLA	1	55	11/10/80	RELEA = D CLA	1	56
57	11/10/80	RELEA = D CLA	1	58	11/10/80	RELEA = D CLA	1	59	11/10/80	RELEA = D CLA	1	60
61	11/10/80	RELEA = D CLA	1	62	11/10/80	RELEA = D CLA	1	63	11/10/80	RELEA = D CLA	1	64
65	11/10/80	RELEA = D CLA	1	66	11/10/80	RELEA = D CLA	1	67	11/10/80	RELEA = D CLA	1	68
69	11/10/80	RELEA = D CLA	1	70	11/10/80	RELEA = D CLA	1	71	11/10/80	RELEA = D CLA	1	72
73	11/10/80	RELEA = D CLA	1	74	11/10/80	RELEA = D CLA	1	75	11/10/80	RELEA = D CLA	1	76
77	11/10/80	RELEA = D CLA	1	78	11/10/80	RELEA = D CLA	1	79	11/10/80	RELEA = D CLA	1	80
81	11/10/80	RELEA = D CLA	1	82	11/10/80	RELEA = D CLA	1	83	11/10/80	RELEA = D CLA	1	84
85	11/10/80	RELEA = D CLA	1	86	11/10/80	RELEA = D CLA	1	87	11/10/80	RELEA = D CLA	1	88
89	11/10/80	RELEA = D CLA	1	90	11/10/80	RELEA = D CLA	1	91	11/10/80	RELEA = D CLA	1	92
93	11/10/80	RELEA = D CLA	1	94	11/10/80	RELEA = D CLA	1	95	11/10/80	RELEA = D CLA	1	96
97	11/10/80	RELEA = D CLA	1	98	11/10/80	RELEA = D CLA	1	99	11/10/80	RELEA = D CLA	1	100



NOTES:


- OPTIONAL RAM EXPANSION IS STANDARD ON FA501 C/D.
UNLESS OTHERWISE SPECIFIED POWER AND GROUND PINS OF
INTEGRATED CIRCUITS ARE AS LISTED BELOW.
14 PIN INTEGRATED CATS. PIN 14 = +5V. PIN 1 = GND.
18 PIN INTEGRATED CATS. PIN 18 = +5V. PIN 9 = GND.
24 PIN INTEGRATED CATS. PIN 24 = +5V. PIN 12 = GND.
- CONTROL BLOCKA INPUTS ARE SHOWN ONLY ONCE. BUT ARE CONNECTED
IDENTICALLY TO MEN LOCATED AT B7 & C7
- CONTROL BLOCKA INPUTS ARE SHOWN ONLY ONCE. BUT ARE CONNECTED
IDENTICALLY TO MEN LOCATED AT A1, A2, A3, A4, A5, & A8
- CONTROL BLOCKA INPUTS ARE SHOWN ONLY ONCE. BUT ARE CONNECTED
IDENTICALLY TO MEN LOCATED AT B1, B2, B3, B4, B5, & B8
- CONTROL BLOCKA INPUTS ARE SHOWN ONLY ONCE. BUT ARE CONNECTED
IDENTICALLY TO MEN LOCATED AT C1, C2, C3, C4, C5, & C8
- CONTROL BLOCKA INPUTS ARE SHOWN ONLY ONCE. BUT ARE CONNECTED
IDENTICALLY TO MEN LOCATED AT D1, D2, D3, D4, D5, & D8
- UNLESS OTHERWISE NOTED ALL LEADS TO BE P M15171201

SPARES



TITLE		SCHEMATIC DIAGRAM, 9BED	
CONTROL DATA		FA501 BR810	
DETAIL	80442231	REST	USED ONCE
ASSY	80442231	DOWN	10/15/80
COMPONENTS, EXCEPT AS NOTED	80442231	CHD	10/15/80
RES	100-20%	ENG	10/15/80
VAL	100-20%	APR	10/15/80
DATE	10/15/80	SCALE	1:1
DRAWING NO		90446258	
CODE INBT		15920	
SCALE		1:1	
SHEET		1 OF 11	







REV	A
DWG NO	90446258
CODE IDENT	15920
CROSS REF NO	005
SHEET	7

SCHEMATIC DIAGRAM, 9BED


LOC
CROSS REF NO 005






REV	1
DWG NO	90446258
CROSS REF NO	008
SHEET	16
CODE INST	15920
SCHEMATIC DIAGRAM, 9BED	
GDD	

LOC
CROSS
REF NO 008




DWG NO		90446258	
CODE IDENT		15920	
CROSS REF NO		011	
SHEET		13	
SCHEMATIC DIAGRAM, 98ED			
LOC			
CROSS REF NO 011			



DWG NO		90446258	
CODE PRINT		15920	
CROSS REF NO		013	
SHEET NO		15	
SCHEMATIC DIAGRAM, 9BED			

LOC
CROSS
REF NO 013




REV	F
DWG NO	90446258
CODE IDENT	15920
CROSS REF NO	014
SHEET	16
SCHEMATIC DIAGRAM, 98ED	
GIB	

LOC
CROSS REF NO 014

2

3

4




NOT USED

J12-7
J8-2
H4-4


REV	F
DWG NO	90446258
CODE IDENT	C
15920	
CROSS REF NO	015
SHEET	17
SCHEMATIC DIAGRAM, 9BED	


LOC	
CROSS REF NO	015



REV F
 DWG NO 90446258
 CODE IDENT 15920
 CROSS REF NO 016
 SHEET 18
 SCHEMATIC DIAGRAM, 9BED
 G9

LOC
 CROSS REF NO 016








REV	1
DWG NO	90446138
CODE IDENT	15920
CROSS REF NO	001
SHEET	2


SCHEMATIC DIAGRAM
9BKD



LOC	
CROSS REF NO	001



REV	
DWG NO	90446138
CODE IDENT	15920
CROSS REF NO	002
SHEET	3
SCHEMATIC DIAGRAM	
98KD	


LOC
CROSS
REF NO 002




[illegible]

1 ALL WIRES ARE 18 GA 600V UNLESS OTHERWISE MARKED

[illegible]



1
2
3
4



REV	E
DWG NO	90446288
CODE IDENT	C 15920
LOC	002
SHEET	3

SCHEMATIC DIAGRAM, IAFD

LOC
CROSS
REF NO 002



This section provides information necessary to perform on-site maintenance on the flexible disk subsystem. The material presented assumes familiarity with the PLATO system and basic maintenance techniques including use of common CE tools and test equipment. The maintenance information covers checks, adjustments, removal, and replacement of the field-replaceable components as directed by the associated structured analysis method (SAM) listings for the subsystem. Information is organized under the following major headings:

- General Maintenance Information
- Diagnostic and Corrective Maintenance

GENERAL MAINTENANCE INFORMATION

The following paragraphs provide information that the customer engineer should be familiar with before performing maintenance on the terminal. Topics discussed are:

- Suggested Emergency Maintenance Procedure
- Safety Precautions
- Maintenance Tools and Materials
- MOS Circuit-Handling Precautions
- Maintenance Aids
- Location of Major Assemblies

SUGGESTED EMERGENCY MAINTENANCE PROCEDURE

The following procedure provides suggested steps for the customer engineer (CE) to follow when responding to a customer request for maintenance on the subsystem.

Before Leaving For Customer Site

Before leaving for the customer site, the CE should call the customer and talk to the person operating the subsystem at the time the malfunction occurred, then:

1. Determine the following:
 - a. Type of symptoms subsystem exhibited to indicate that a malfunction occurred.
 - b. Whether subsystem is operating and what symptoms, if any, are present when an attempt is made to operate.
2. Decide course of action to take, for example:
 - a. Go to customer site and begin troubleshooting.
 - b. Deduce that subsystem itself is probably not at fault and most likely cause of problem is either terminal communication lines or a power reduction or loss. In either case, CE can notify responsible party (common carrier or customer) of problem.
 - c. Decide that an error in operating procedure, rather than equipment failure, is probably cause of malfunction, and notify customer of correct operating procedure.
3. If a site maintenance trip is required, CE should try to determine a probable cause for failure and gather necessary tools, manuals, and spare parts that may be needed.

Upon Arriving At Customer Site

Upon arriving at the customer site, the CE should locate the appropriate supervisory personnel and again talk to the subsystem operator concerning the malfunction, then:

1. Visually inspect subsystem for correct input/output and power cable connections.
2. Verify that a malfunction does exist, and then begin to troubleshoot subsystem.

3. After source of malfunction is corrected, CE should:

- a. Run diagnostic self-test routines and appropriate PLATO DIAG tests to ensure that subsystem is operational.
- b. Demonstrate to customer that subsystem is now operating properly within system.

SAFETY PRECAUTIONS

WARNING

Observe the following safety precautions at all times. Failure to do so may cause equipment damage and/or personal injury.

- Hazardous voltages exist in the subsystem. Do not attempt repair unless qualified to do so.
- Exercise caution any time checks or adjustments are being made to terminal when power is applied.
- Always turn power off and disconnect ac power cord when removing/replacing components or cables.

MAINTENANCE TOOLS AND MATERIALS

The maintenance procedures require the use of metric tools and common CE test equipment. No special materials are required.

MOS CIRCUIT-HANDLING PRECAUTIONS

Special handling procedures are necessary for printed-circuit cards containing metal-oxide semiconductor (MOS) integrated circuits. These ICs are susceptible to damage from static electricity. Observe the following precautions when handling the controller board:

- Turn power off before removing/installing or otherwise connecting/disconnecting any circuits.

- Ensure that any item that comes in contact with card is electrically grounded.
- Touch metal chassis frame to bleed off any accumulated static charge before handling card and continue to touch chassis while removing/installing card.
- Handle card only by a noncircuit portion. Connector pins and circuit paths must not be touched.
- Place card in a special conductive envelope whenever card is removed from chassis.

MAINTENANCE AIDS

There is no scheduled maintenance for the subsystem. In the event of failure, the primary maintenance aids are the voltage LED indicators, self-test routines, and DIAG Flexible Disk Diagnostic tests. These aids in conjunction with the SAM troubleshooting listings are structured to isolate the failure to a field-replaceable component/assembly and to provide a procedure number reference to the applicable maintenance procedure to be used for correcting the malfunction. Refer to the Diagnostic and Corrective Maintenance heading for organization of this material.

LOCATION OF MAJOR ASSEMBLIES

Figure 6-1 shows the location of the major assemblies within the subsystem.

DIAGNOSTIC AND CORRECTIVE MAINTENANCE


The following paragraphs describe routines tests, and procedures used to maintain the subsystem.

- Diagnostic Self-Test Routines
- Engineering Services Diagnostic Disk
- DIAG Flexible Disk Diagnostic Disk Tests
- Explanation of SAM Format
- Organization of SAMs and Procedures

DIAGNOSTIC SELF-TEST ROUTINES

The subsystem contains nine diagnostic tests stored in ROM. The starting address is at 0000₁₆. Diagnostic execution is under control of the diagnostic control switches on the controller

board. Status of the diagnostic tests is indicated by the four LEDs also located on the controller board. Refer to section 2 for a detailed description of the diagnostic control switches and LED indicators. The following paragraphs provide a description of the various test routines.



03927-1

NOTE: COVER AND FRONT
PANEL REMOVED
FOR CLARITY.

Figure 6-1. Location of Assemblies in Subsystem

LED Test

All four LEDs light momentarily following a power application and after a master reset to test the indicators.

Test 0 - ROM Checksum

The ROM checksum routine tests ROM for the correct checksum value of the stored contents.

Test 1 - RAM Test

Test 1 checks RAM memory (as specified by the diagnostic control switches) for correct operation. This test uses the diagnostic control switches and LEDs to isolate to a failing RAM chip. The first level of error detection is to a specific RAM bank, then to the failing chip within that bank.

Test 2 - Interrupt Generator

Test 2 checks for interrupts by performing writes and reads to the available registers in the interrupt controller IC.

Test 3 - Flexible Disk Controller

Test 3 checks the flexible disk controller IC by performing writes and reads to all available registers in the IC.

Test 4 - DMA Test -

Test 4 reads data from the flexible disk controller IC data register to memory using DMA channels 1 and 3.

Test 5 - I/O Loopback Test

Test 5 tests the basic I/O capabilities by interfacing the input/output registers and transferring data via the I/O data bus and checking status.

Test 6 - CTC Test

Test 6 checks the counter/timer circuit by loading a count value and determining that the proper interrupt is generated at count 0.

Test 7 - Writing and Reading the Disk

Test 7 checks for a ready disk drive, then seeks side 1, track 76, last sector and executes writes and reads using the disk DMA channel. This surface area is reserved on all disks; therefore, no alteration is made to stored disk data.

ENGINEERING SERVICES DIAGNOSTIC DISK

This disk provides off-line testing that is similar to the diagnostics found in DIAG. For additional information on diagnostics and where to order the disks, refer to manual titled Engineering Services Diagnostics Disk for PLATO Disk (see Preface for publication number).

DIAG FLEXIBLE DISK DIAGNOSTIC TESTS

Testing can be performed using downline-loaded diagnostics from the PLATO system. Use lesson DIAG to call up the flexible disk diagnostic tests. This diagnostic loads and tests information via the terminal parallel I/O channel. Two modes are tested, DMA operations and interrupt routines. Refer to checkout information in section 3 for details of diagnostic operation.

EXPLANATION OF SAM FORMAT


A SAM listing is a specialized format used to present troubleshooting information in a logical manner. Figure 6-2 illustrates the basic SAM format. Any applicable assumptions or advisory information is provided in the header information of the SAM.

To interpret a SAM, start at the top of the page and determine the response for the first question posed. Then follow the appropriate dashed line beneath the Y or N response. Answer the next question, etc. until the action numbers are reached. Perform the action(s) listed in that column in numerical order to correct the problem.

ORGANIZATION OF SAMs AND PROCEDURES

The SAMs and maintenance procedures are organized in two separate subsections of this manual as follows:

- SAM Listings (section 6A)
- Maintenance Procedures (section 6B)



03680

Figure 6-2. SAM Example

SAMS
SECTION 6A



SAM 1 POWER FAULT ISOLATION

This SAM assumes that the ac power cord is plugged into a live site outlet and is firmly seated at the rear ac connector of the unit.

- | | | | | | | | | |
|---------------------|--|---|---|--------------------|--|--------------------|---------------------|---------------------|
| 001 | Y | N | Does unit circuit breaker trip when power is applied?
Allow time to cool and retry before proceeding with additional steps. | | | | | |
| 002 | Y | N | Are fan and drive motor running? | | | | | |
| 003 | | 1 | Check that connector J3 from ac entry panel is plugged into backplane. | | | | | |
| 004 | | 2 | Check internal ac wiring connections (see ac power wiring schematic in section 5). | | | | | |
| 005 | | 3 | Check power cord for continuity. | | | | | |
| 006 | | 4 | Check/replace circuit breaker. | | | | | |
| 007 | | 5 | Replace fan or drive unit (procedure 6) as applicable. | | | | | |
| 008 | Y | N | Are all LEDs on power supply lit? | | | | | |
| 009 | | 1 | Replace power supply (procedure 5). | | | | | |
| 010 | | 1 | Check that correct power supply voltages are present.
Voltages should be: | | | | | |
| | | | <table border="0"> <tr> <td>● +5 V ± 0.1 V</td> <td rowspan="4">} Test points at front edge of controller board.</td> </tr> <tr> <td>● -5 V ± 0.1 V</td> </tr> <tr> <td>● +12 V ± 0.1 V</td> </tr> <tr> <td>● +24 V ± 0.5 V</td> </tr> </table> | ● +5 V ± 0.1 V | } Test points at front edge of controller board. | ● -5 V ± 0.1 V | ● +12 V ± 0.1 V | ● +24 V ± 0.5 V |
| ● +5 V ± 0.1 V | } Test points at front edge of controller board. | | | | | | | |
| ● -5 V ± 0.1 V | | | | | | | | |
| ● +12 V ± 0.1 V | | | | | | | | |
| ● +24 V ± 0.5 V | | | | | | | | |
| | | | Check at J4 of drive unit (see procedure 5) | | | | | |

NOTE

The +5-V and +24-V outputs are adjustable. Refer to procedure 5. If correct voltages are not obtained, replace power supply (procedure 5).

2 2
A B

	A	B	
	1	1	
011	Y	N	Is Power indicator (LED 20) lit on controller board (primary units only)?
012		<u>1</u>	Replace controller board (procedure 4).
013		<u>1</u>	Internal power checks are OK.
014	1		Check internal wiring visually for shorts.
015	2		Unseat power supply board and retry. If circuit breaker no longer trips, replace power supply (procedure 5).
016	3		Unseat controller board (primary units only) and retry. If circuit breaker no longer trips, replace controller board (procedure 4).
017	4		Disconnect J4 from disk drive unit and retry. If circuit breaker no longer trips, replace disk drive unit (procedure 6).
018	<u>5</u>		Refer to ac power wiring schematic in section 5 and disconnect wiring/connectors from ac entry panel, line filter, and transformer back to circuit breaker to isolate load fault. Replace defective item.

SAM 2 INTERNAL DIAGNOSTIC CHECKS (MASTER UNITS ONLY)

This SAM isolates faults detected by the internal diagnostic tests. Refer to sections 2 and 3 for information on Diagnostic Control Switches and LED Indicators, and to the Diagnostic Self-Test Routines heading in section 6 for test descriptions.

- 001 Y N Do all four LEDs at front of controller board light momentarily following a power application or a master reset?
- 002 1 If no LEDs light, check for power fault per SAM 1.
- 003 2 Replace controller board (procedure 4).
- 004 N Y Is Error LED (2³) lit and other LEDs off? (Indicates a ROM Checksum Test 0 error.)
- 005 1 Replace ROM chips, Z80 chip, or controller board (procedure 4).

- 006 N Y Is Error LED (2³) and Power LED (2⁰) lit? (Indicates a RAM memory Test 1 error.)

NOTE

Verify that switches 2⁴ and 2⁵ are set correctly for number of RAM banks present. See section 3, Sub-system Installation.

- 007 1 Replace controller board (procedure 4), or isolate and replace bad RAM chip as follows:
- o Place switch 2¹ up and switch 2² down to display failing RAM bank in LEDs 2⁰ through 2² (bank 0 is row A, bank 1 is row B, bank 2 is row C, and bank 3 is row D).
 - o Place switch 2² up to display failing bit (chip) within bank in LEDs 2⁰ through 2² (bit 0 is at location 6, bit 7 is at location 1. See figure 6B-4 for board layout).
 - o Replace failing RAM chip and rerun internal diagnostic tests.

2
A

- 008 N Y Is Error LED (23) and Write LED (21) lit? (Indicates an Interrupt Generator Test 2 error.)
- 009 1 Replace controller board (procedure 4). Problem with 9519 Interrupt Controller IC or support logic.
- 010 N Y Is Error LED (23), Write LED (21), and Power LED (20) lit? (Indicates a Flexible Disk Controller Test 3 error.)
- 011 1 Replace controller board (procedure 4). Problem with 1791 Flexible Disk Controller IC or support logic.
- 012 N Y Is Error LED (23) and Read LED (22) lit? (Indicates a DMA Test 4 error.)
- 013 1 Replace controller board (procedure 4). Problem with 9517 DMA IC or support logic.
- 014 N Y Is Error LED (23), Read LED (22), and Power LED (20) lit? (Indicates an I/O Loopback Test 5 error.)
- 015 1 Replace controller board (procedure 4). Problem with support logic.
- 016 N Y Is Error LED (23), Read LED (22), and Write LED (21) lit? (Indicates a CTC Test 6 error.)
- 017 1 Replace controller board (procedure 4). Problem with Z80 CTC IC.
- 018 N Y Is Error LED (23), Read LED (22), Write LED (21), and Power LED (20) lit? (Indicates a Writing and Reading the Disk Test 7 error.)
- 019 1 Verify correct diagnostic control switch settings (see section 3 of manual).
- 020 2 Verify that flexible disk is properly formatted.
- 021 3 Verify that flexible disk is Write Protected (slot covered). If not Write Protected, set diagnostic control switch 23 up.
- 022 4 Replace controller board (procedure 4).
- 023 5 Replace disk drive unit (procedure 6).

3
A

	A	B	
	2		
024	N	Y	Is Error LED (23) off, and Read LED (22), Write LED (21), and Power LED (20) lit? (Indicates that controller logic is communicating with drive unit, but test is not complete).
025		1	Check that flexible disk is installed in drive unit (procedure 2) and access door is closed.
026		2	Replace controller board (procedure 4).
027		3	Disconnect secondary unit (if applicable).
028		4	Replace disk drive unit (procedure 6)
029	N	Y	Is Power LED (20) lit and other LEDs off?
030		1	Indicates successful completion of resident diagnostic.
031	1		Diagnostic test error. Begin at step 001 of this SAM to isolate failure.

SAM 3 DIAG FLEXIBLE DISK DIAGNOSTIC CHECKS

This SAM provides fault isolation information for problems detected by the DIAG Flexible Disk Diagnostics. Use of this SAM assumes that the internal self-test diagnostics execute without error. Refer to section 3, Checkout, for the procedure to be used to load and execute the DIAG Flexible Disk Diagnostics.

- | | | |
|-----|-----|--|
| 001 | N Y | Is there a terminal log-in or diagnostic loading problem? |
| 002 | 1 | Refer to applicable terminal hardware maintenance manual for troubleshooting information (see preface for publication number). |
| 003 | N Y | Is there a Disk System Not Ready to Load or Incorrect Load message displayed? |
| 004 | 1 | Try loading again by entering option 10 of display prompts. |
| 005 | 2 | Check that power is applied to flexible disk subsystem and last peripheral device connected to parallel I/O channel. |
| 006 | 3 | Check that no flexible disk is installed in drive unit of primary or secondary and perform a long master reset (press and hold Master Reset switch longer than three seconds). (1) |
| 007 | 4 | Check that device address strap/switch of flexible disk subsystem is set correctly. |
| 008 | 5 | Check seating of I/O cable between terminal and flexible disk subsystem and check that terminator is installed at last peripheral device. |
| 009 | 6 | Reseat controller board. |
| 010 | 7 | Replace controller board (procedure 4). |
| 011 | 8 | Refer to applicable terminal hardware maintenance manual for troubleshooting information (see preface for publication number). |
| 012 | N Y | Is there a Bad Seek message displayed? |
| | 2 2 | |
| | A B | |

A	B	
1	1	
013	1	Verify that side of flexible disk entered for seek and track number are valid.
014	2	Check that a correctly formatted flexible disk is being used.
015	3	Possible bad flexible disk, try a different one.
016	4	Reseat controller board.
017	5	Replace controller board (procedure 4).
018	6	Replace disk drive unit (procedure 6).
019	7	Refer to applicable terminal hardware maintenance manual for additional troubleshooting information.
020	N Y	Does a switch-test error message appear?
021	1	Verify that switch being toggled is one being referenced on terminal.
022	2	Verify that toggling switch does not change switch position indicated on terminal.
023	3	Reseat controller board.
024	4	Replace controller board (procedure 4).
025	N Y	Does a send-interrupt-to-terminal error message appear?
026	1	Reseat controller board.
027	2	Check seating of parallel I/O cable and terminator assembly.
028	3	Verify correct terminal operation. If other devices are connected to parallel I/O channel, verify that interrupts work correctly to those devices.
029	4	Replace controller board (procedure 4).
030	N Y	Does an index-pulse error message appear?
031	1	Reseat controller board.
032	2	Replace controller board (procedure 4).
033	2	Replace power supply (procedure 5).
3	3	
A	B	

	A	B	
	2	2	
034	N	Y	Does a line-sync error message appear?
035		1	Reseat controller board.
036		2	Check seating of internal cable connectors.
037		3	Replace controller board (procedure 4).
038		4	Replace power supply (procedure 5).
039	N	Y	Is there a test-disk error (wrong density, number of sides, etc.)?
040		1	Check flexible disk part number to ensure disk being test has assumed characteristics (density, number of sides, etc.).
041		2	Reseat controller board.
042		3	Replace controller board (procedure 4).
043		4	Replace disk drive unit (procedure 6).
044	N	Y	Does error occur during read-a-sector test?
045		1	Try another flexible disk to verify that media is okay.
046		2	Replace controller board (procedure 4).
047		3	Replace disk drive unit (procedure 6).
048	N	Y	Does a device-address error message appear?
049		1	Ensure that device-address entry being made matches setting of device-address strap/switch.
050		2	Replace controller board (procedure 4).
051	1		DIAG Flexible Disk Diagnostics executed OK.

(1) If a long master reset or power application is performed with a system flexible disk installed, internal diagnostics will autoloading from disk instead of terminal. Therefore, flexible disk must be removed from drive unit(s), or Switch 23, or Switch 27 must be up in order to bypass test 7 or to bypass internal diagnostic execution, respectively.

PROCEDURES
SECTION 6B



Procedure 1 - Power Application/Removal

This procedure assumes that the flexible disk subsystem is plugged into the site ac outlet.

WARNING

Applying improper voltage to the flexible disk subsystem can damage components. Read label on back of unit for proper voltage and frequency.

NOTE

Correct operation of the IST parallel interface channel requires that power be applied to the last peripheral device on the channel. Last device supplies +5 V to the terminator.

1. First apply power to terminal. Then apply power to disk subsystem by pulling forward on Power On/Off switch connecting rod (early units) or by pressing Power ON/OFF switch to ON position (later units). See figure 6B-1.




Figure 6B-1. Power On/Off Switch Location

2. Power on is indicated by LED 20 being lit (primary units only).

3. Remove power by pushing Power On/Off switch connecting rod in (early units) or by pressing Power On/Off switch to Off position (later units).

Procedure 2 - Flexible Disk Installation/Removal

Install flexible disk in drive unit per the following:

1. Apply power to disk subsystem (procedure 1).
2. Press door latch to open access door (figure 6B-2).




Figure 6B-2. Disk Installation/Removal

3. Remove flexible disk from storage envelope.

NOTE

If information is to be written onto disk, Write-Protect slot must be covered with tape that is opaque to infrared light.

4. Hold flexible disk so that Write-Protect slot is to left and slide disk into drive unit until solidly seated.
5. Close drive access door by pressing down on door until latched.
6. To remove disk, press door latch to open door and remove disk from drive. Place flexible disk in storage envelope.

NOTE

Care should be taken in handling the flexible disks. Recommendations are:

- Do not use lead or grease pencils when writing on flexible disk jacket label as these items deposit flakes. Remove flexible disk before writing on jacket.
- Do not fasten paper clips to flexible disk jacket edges.
- Do not touch disk surface exposed by jacket slot.
- Do not attempt to clean disk surface in any manner.
- Keep flexible disk away from magnetic fields and ferromagnetic materials that may be magnetized.
- Protect flexible disk from liquids, dust, and metallic substances.
- Always place flexible disk in its protective jacket when not in use.
- Store flexible disks loosely in a vertical position, not stacked.

Procedure 3 - Front Panel and Cabinet Hood Removal/Replacement

To remove the front panel or cabinet hood, refer to figure 6B-3 and perform the following:

1. Turn subsystem power off (procedure 1).
2. To remove front panel, remove two screws from panel and tip bottom of panel forward to release.
3. To reinstall front panel, engage retaining slots at top of panel, then tip panel down and install mounting screws.
4. To remove cabinet hood, first remove front panel, then remove four screws from Nylon feet at bottom of unit and two screws at rear of unit.
5. When reinstalling cabinet hood, install two screws at rear of unit first before installing bottom screws and Nylon feet.




Figure 6B-3. Front Panel and Cabinet Hood Mounting Details

Procedure 4 - Controller Board Removal/Replacement

Perform the following steps to remove/replace the controller board and/or RAM, EROM, and Z80 chips. See figure 6B-4 for board layout.

1. Turn subsystem power off (procedure 1).
2. Remove front panel (procedure 3).
3. Release controller board extractors and slide pc board out of unit.
4. Remove master reset push button and install on replacement board. This button is eccentric which allows for some adjustment. This adjustment is performed in step 6 of this procedure.

EARLY MODELS HAVE
DEVICE ADDRESS SWITCH




Figure 6B-4. Controller Board Layout

5. When installing a replacement controller board, verify that device address strap* is wired to 7 and diagnostic

*If unit has device address switch, it must be set to address 7.

control switches are set correctly for subsystem operation (see section 3 for switch settings). For FA501-A/B only, if RAM options are installed on a controller board that is being replaced, transfer RAM chips to new controller board. Locations for RAM options are:

- 1st RAM option - locations C1, C2A, C2B, C3, C4A, C4B, C5, and C6.
 - 2nd RAM option - locations D1, D2A, D2B, D3, D4A, D4B, D5, and D6.
 - 3rd RAM option - locations A1, A2A, A2B, A3, A4A, A4B, A5, and A6.
6. Slide controller board in and replace front panel (procedure 3).
 7. Rotate master reset push button unit until best fit is achieved.


Procedure 5 - Power Supply Removal/Replacement

This procedure describes removal/replacement of the power supply assembly. See figure 6B-5.

1. Turn subsystem power off (procedure 1).
2. Remove front panel (procedure 3).
3. Release power supply board extractors and slide assembly out of unit.
4. After installing a replacement power supply assembly, perform voltage adjustments as follows:
 - +5-V Adjustment
 - a. Connect meter leads as follows:
 - Primary units - Attach meter leads to +5-V and GND test points at left front edge of controller board.
 - Secondary units - Remove disk drive unit from cabinet by pulling drive unit forward until free of slides. Set drive unit on its side, rotated to the left, to allow access to connector J4 at rear of drive PC board. Check that board connectors are seated firmly. Connect + meter lead to J4 pin 2 (+5 V) and - meter lead to J4 pin 3 (ground)

b. Apply power to unit.

c. Adjust top potentiometer on power supply board for $+5\text{ V} \pm 0.1\text{ V}$.



03931-1

Figure 6B-5. Power Supply Voltage Adjustments

● **+24-V Adjustment**

a. Turn power off.

b. Remove disk drive unit from cabinet by pulling drive unit forward until free of slides but cables remain firmly attached. Set drive unit on its side, rotated 90° to the left, to allow access to connector J4 at rear of drive PC board.

c. Connect + meter lead to J4 pin 4 (+24 V) and - lead to J4 pin 6 (+24-V return).

- d. Apply power to unit.
- e. Adjust bottom potentiometer on power supply board for +24 V +0.5 V.
- f. Turn power off, disconnect meter leads, and reinstall drive unit. Check that cables do not bind when installing drive unit.

Procedure 6 - Disk Drive Unit Removal/Replacement

Refer to figure 6B-6 and perform the following steps to remove/replace the disk drive unit.

1. Turn subsystem power off (procedure 1).
2. Remove front panel (procedure 3).

CAUTION


Do not set disk drive unit down with PC board at bottom. Damage to PC components may occur.

3. Remove disk drive unit from cabinet by pulling drive unit forward until free of slides. Set drive unit on its side and disconnect three cables from rear of unit.
4. Remove slides and shields (figure 6B-6) from existing drive unit. The shields are to be installed on the replacement drive as follows:
 - When replacement drive is a primary unit (FA501-A/B/C/D Primary Flexible Drive), both side and bottom shields must be replaced.
 - When using the secondary unit as the replacement (BR801-A,B Secondary Flexible Drive), only the side shield must be replaced (figure 6B-6).
5. Verify that drive pulley on replacement drive unit is installed correctly for 50-Hz/60-Hz operation as required. Pulley must be reversed to change the rotating speed of drive unit. Refer to figure 6B-7 for details.

6. Verify that Unit Select switch (DIP switches 1, 2, 3, and 4) and Ready switch (DIP switches 5, 6, 7, and 8) are set as follows:


- o Primary Unit - DIP switch 1 and 5 ON, remaining switches OFF.
- o Secondary Unit - DIP switch 2 and 6 ON, remaining switches OFF.

7. Remove cardboard head-protective flexible disk from drive unit if replacement unit is being installed.



03931-2

Figure 6B-6. Disk Drive Unit Installation



Note - Refer to the 9406 Flexible Disk Drive Assembly Hardware Maintenance manual for additional information if needed (see preface for publication number).

Figure 6B-7. Drive Pulley Details

This section contains the spare parts lists, genealogy charts, and assembly drawings for the flexible disk subsystem. Parts data for the 9406 Flexible Disk Drive unit is contained in a separate publication (see the preface for publication number).

NOTE

Parts list information is provided under separate dividers for the pre-production and production units. Common parts list information is also provided under a separate divider.

Table 7-1 explains the column headings on the assembly parts lists.

TABLE 7-1. EXPLANATION OF COLUMN HEADINGS ON ASSEMBLY PARTS LISTS

COLUMN HEADING	EXPLANATION
FIND NO.	Identifies an electrical or mechanical part on an assembly drawing. If more than one listing appears for a find number, refer to LI, WK IN, and WK OUT.
LI (Line Item)	Gives a chronological or historical record of the addition of a new part to a find number. For example, 01 indicates that the part was the first one used, and 02 indicates the second, etc. See also WK IN and WK OUT.
PART NUMBER	Gives the Control Data Corporation part identification. Use this number when ordering replacements.
CD (Check Digit)	Gives the information-control system a means of cross-checking the correctness of a part number.
QUANTITY	Lists the total number of a part required to complete an assembly. The vertical line near the center of the column acts as a decimal point. Numbers to the left of the line are whole numbers. Those to the right of the line are tenths, hundredths, and thousandths.
U/M (Unit of Measure)	Indicates how the information-control system counts or supplies a part.
PART DESCRIPTION	Describes the physical appearance, type, or name of a part.
MC (Material Code)	Supplies additional descriptive data to the information-control system.
YLD (Yield)	A 2-digit number that indicates the usable portion of any quantity of parts expressed as a percentage.
ECO NO. IN	Engineering Change Order that adds a new part to an assembly. See also WK IN.
ECO NO. OUT	Engineering Change Order that deletes a part from an assembly. See also WK OUT.
S/N (Serial Number)	Used to specify an ECO's effectivity by serial number.
WK IN (Week In)	Lists the date when manufacturing begins using a new part and when it is available for parts replacement. For example, 7222 means a part is available of the 22nd week of 1972.
WK OUT (Week Out)	Lists the date when manufacturing no longer uses a part in building an assembly. See also WK IN. Do not order a part after its week-out date.

0643-2A



PARTS DATA FOR PRE-PRODUCTION UNITS ONLY

0



DWN	P. Trautman	2-6-80	CONTROL DATA	TITLE	SPL	PREFIX	DOCUMENT NO	REV	J
CHKD	P. Trautman	2-6-80		PRIMARY FLEXIBLE DISK SUBSYSTEM	SPL		66308923		
ENG	P. Trautman	2-6-80		FIRST USED ON					
MFG	N/A								
APPR	E. V. Voss	7-16-80	CODE IDENT	FA501A/B				SHEET	1 OF 3
	66308923	2-16-80	15920						

SHEET REVISION STATUS										REVISION RECORD				
3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP						
00	00	00	00	5000-62	RELEASED CLASS B		2/13/80	RAM						
01	01	01	01	51000	ADDED F/N 18 & NOTE 9	WJG	2/13/80	RAM						
02	01	02	02	51011	F/N 18 WAS 66312007	WJG	2/14/80	RAM						
03	03	03	03	51168	F/N 12 WAS 66139318 F/N 13 WAS 66139319	D.S.	7/17/80	7-15-80	RAM					
A	A	A	A	11565-80	RELEASED CLASS "A"		7/23/80	RAM						
B	A	B	B	14165	REVISED PER ECO	WJG	9/15/80	RAM						
C	C	C	C	14376	REVISED PER ECO	EE	1/12/81	RAM						
D	D	D	D	14571	CHG 1, 15, 19, DELETE NOTE 3	WJG	3-2-81	RAM						
E	D	E	E	14721	F/N 16 WAS 90446140	EE	7/13/81	RAM						
F	D	F	F	14663	ADDED F/N 20	EE	7/14/81	RAM						
G	G	G	G	14838	ADDED NOTE 10	EE	10/12/81	RAM						
G	H	H	H	14820	REVISED PER ECO	WJG	11-6-81	RAM						
J	J	J	J	15867	INACTIVE SERVICE USE ONLY, SUPERSEDED BY 44513407	WJG	5-18-83	RAM						

NOTES:

EQUIPMENT	EQUIPMENT CONFIGURATOR	TOP LEVEL ASSEMBLY
FA501A 60HZ	15632205	15632209
FA501B 50HZ	15632206	15632210

THIS SPL APPLIES ONLY TO A/B01 EQUIPMENTS

DETACHED LISTS -

AA3180 REV 2-71

PRINTED IN U.S.A.

CONTROL DATA CORPORATION	CODE IDENT	15920	SHEET	2	PREFIX	DOCUMENT NO.	66308923	REV.	J
--------------------------	------------	-------	-------	---	--------	--------------	----------	------	---

NOTES:

- These parts are the total required for a unit with no options installed.
- A unit could have 3 RAM options of 8 RAM ICs for each option for a total of 32 RAM ICs in the unit.

4. Find Numbers 1 thru 7 and 19 are for the 98ED Controller Board.

5. Use Find Number 8 for the FA501A 60HZ unit and use Find Number 9 for the FA501B 50HZ unit.

6. Find Number 10 is for the 50HZ AC Entry only.

8. Find Number 11 is the signal cable used to connect the Primary Flexible Disk Subsystem to the IST Terminal.

9. One of these devices is required on the last device on the Plato IST Parallel I/O channel daisy chain configuration.

10. Original production units were built with P/N 90446140. Current production units are built with P/N 90446290. These cards are interchangeable.

AA3180

PRINTED IN U.S.A.

CONTROL DATA				CODE IDENT		SHEET		SPL		DOCUMENT NO		REV			
				15420		3				66308723		J			
FIND NO.	PART IDENTIFICATION	QUANTITY REQUIRED										UNIT OF MEAS	NOMENCLATURE OR DESCRIPTION	SPECIFICATIONS, NOTES, OR MATERIAL	
		60 HZ	50 HZ												
1	66312070	1	1											2716 2KX8 ROM	4
2	15153821	8	8											4116 16K RAM	4
3	15163201	1	1											Z80 Processor	4
4	15163444	1	1											FD1791 Disk Controller	4
5	15163458	1	1											9517 DMA	4
6	15163459	1	1											9519 Interrupt Cont.	4
7	15164429	1	1											Z80A-CTC	4
8	15165425	1	0											60Hz Power Cord	5
9	15165426	0	1											50Hz Power Cord	5
10	51918789	0	1											Step down Transformer	6
11	61408865	1	1											25 pin I/O Cable	8
12	75587103	1	1											Circuit Breaker	
13	15164356	1	1											Line Filter	
14	77618000	1	1											Flexible Disk Assembly	
15	90446284	1	1											98ED Controller Board	
16	90446290	1	1											1AFD Power Supply	10
17	90446143	1	1											98MD Backplane	
18	15632316	1	1											FT116A Terminator	9
19	66312071	1	1											2716 2KX8 Rom	
20	71493364	1	1											SCR Shoulder Nylon	

AA3181 REV. 8/71

PRINTED IN U.S.A.

DWN	R. Trautman	2-6-80	CONTROL DATA	TITLE	SPL SECONDARY FLEXIBLE DISK	PREFIX	DOCUMENT NO	REV					
CHKD	P. Trautman	2-6-80			SPL	66308921	E						
ENG	P. Trautman	2-6-80											
APPR	E. J. M.	7-16-80											
MFG	7-16-80	7-16-80	CODE IDENT	15920	FIRST USED ON	BR810A/B	SHEET	1 of 3					
SHEET REVISION STATUS				REVISION RECORD									
					3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP
					00	00	00	00	500044	Released Class B		2-11-80	
					01	00	01	01	51004	F/N 4 WAS 51097345	WJG	2-11-80	2-11-80
					02	01	02	02	51114	F/N 4 WAS 51940854	WJG	6-6-80	6-6-80
					03	03	03	03	51168	F/N 5 WAS 66309519 F/N 6 WAS 66309318	WJG	7-18-80	7-18-80
					A	A	A	A	11565-88	RELEASED CLASS 'A'		7-23-80	7-23-80
					B	A	B	B	14165	REVISED PER ECO	WJG	9-15-80	9-15-80
					C	A	C	C	14721	F/N 9 WAS 90446140	EE	7-13-81	7-13-81
					D	D	D	D	14838	ADDED F/N 2 AND NOTE 5	EE	11-13-81	11-13-81
					E	D	E	E	14820	REVISED PER ECO	WJG	11-13-81	11-13-81
NOTES:													
EQUIPMENT				EQUIPMENT CONFIGURATOR				TOP LEVEL ASSEMBLY					
BR810A 60HZ				15632207				15632211					
BR810B 50HZ				15632208				15632212					
THIS SPL APPLIES ONLY TO A/B01 EQUIPMENTS.													
DETACHED LISTS													


CONTROL DATA CORPORATION	CODE IDENT	SHEET	PREFIX	DOCUMENT NO.	REV.
	15920	2	SPL	66308921	D

NOTES:

- These parts are the total required for a unit with no options installed
- Use find number 1 (60HZ Power Cord) for the BR810A (60HZ unit) and find number 2 (50HZ Power Cord) for the BR810B (50HZ unit).
- Use find number 3 for the 50HZ AC Entry only.
- Find number 4 is the Signal Cable used to connect the BR810A or BR810B to the FAS01A or FAS01B.
- Original production units were built with P/N 90446140. Current production units are built with P/N 90446290. These cards are interchangeable.

[illegible]

SHEET REVISION STATUS				REVISION RECORD			
REV	CO	DESCRIPTION	DATE	CHKD	APP		
01	5118	RELEASE CLASS B	8/6/88				
01	5118	W/TE 9046147	W/6 6/23/88				
A	1/26/88	RELEASED CLASS A	1/22/88				



REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION 6542272

SPARE PARTS LIST 88308923


SCHEMATIC DIAGRAM (9800) 9046139

SCHEMATIC DIAGRAM (9800) 9046141

SCHEMATIC DIAGRAM (9800) 9046172

REFERENCE DRAWING		TITLE	
FA 501A		GENEALOGY CHART	
FIRST USED ON		PLATO MASTER FLEXIBLE DISK SUBSYSTEM 60 HZ	
CHKD	DATE	CODE IDENT	DRAWING NO
8/12/88	8/12/88	15920	C 66310611
ENG	DATE	CROSS REF NO	SHEET
W/6	2/10/88		OF 1
APP	DATE		
11/1/88	2/10/88		
COMPONENTS EXCEPT AS NOTED			
TOLERANCE	VALUE		
BES			
CAP			

SHEET REVISION STATUS			REVISION RECORD		
REV	CO	DESCRIPTION	DATE	CHKD	APP
00	6004/12	RELEASED CLASS B	7/1/77		
01	51118	DELETE 90446147	WJG/6-9-80 (WJG)		
1 A 11545-00 RELEASED CLASS N			7-2-82		




REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION..... 16342254
 SPARE PARTS LIST..... 68308921
 SCHEMATIC DIAGRAM (9880)..... 90446138
 SCHEMATIC DIAGRAM (9880)..... 90446141

REFERENCE DRAWING		TITLE	
		GENEALOGY CHART	
		PLATO SLAVE FLEXIBLE DISK DRIVE 60HZ	
FIRST USED ON		CODE	DRAWING NO
8B610A		15920	66310612
COMPONENTS, EXCEPT AS NOTED		CODE	REVISION
RES TOLERANCE VALUE RATING		15920	C
CAP		SCALE	SHEET / OF
			1

SHEET REVISION STATUS				REVISION RECORD			
REV	CD	DESCRIPTION	DRFT	DATE	CHKD	APP	
00	5000/12	RELEASED CLASS B	✓	4/2/80	✓		
01	51118	DELETE 50496147	WJS	5-80	10/18		
02	51172	SPL WAS 64303922	WJS	2-80	1		
A	11545-08	RELEASED CLASS A					




REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION 10042154
 SPARE PARTS LIST 86300023
 SCHEMATIC DIAGRAM 9800 90448138
 SCHEMATIC DIAGRAM 9800 90448141
 SCHEMATIC DIAGRAM 9800 90448172

REFERENCE DRAWING		CONTROL DATA		TITLE	
		FASOIB		GENEALOGY CHART	
		3-12-79		PLATO MASTER FLEXIBLE	
		7-11-79		SUBSYSTEM SCHZ	
		7-11-79		DRAWING NO	
		7-11-79		C 66310613	
		7-11-79		CORE UNIT	
		7-11-79		15920	
		7-11-79		SCALE	
		7-11-79		SHEET / OF	

SHEET REVISION STATUS							REVISION RECORD						
							REV	CO	DESCRIPTION	DRFT	DATE	CHKD	APP
							00	5000/10	RELEASED CLASS B		15/1/80		
							01	51118	DELETE 90446143		WUG 6-9-80		
							02	51172	SPL WAS 66308920		WUG 7-22-80		
							03	115-5-88	RELEASED CLASS A		11/5-88		



REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION 18042854
 SPARE PARTS LIST 86308321
 SCHEMATIC DIAGRAM (9880) 90446138
 SCHEMATIC DIAGRAM (9880) 90446141

TIME		GENEALOGY CHART	
REFERENCE DRAWING		PLATO SLAVE FLEXIBLE DISK DRIVE 50HZ	
INT	EXT	BRB10B	
REV	USED ON	REV	DATE
OWN	OWN	OWN	DATE
CHKD	CHKD	CHKD	DATE
ENGR	ENGR	ENGR	DATE
APPR	APPR	APPR	DATE
COMPONENTS EXCEPT AS NOTED		DRAWING NO	
RES	TOLERANCE	CODE	15920
CAP	VALUE	SCALE	66310614
CROSS REF NO		SHEET / OF	

[illegible]

INACTIVE

METRIC

APL 156322109		DO NOT TEST BALLS CHANGING		DO NOT TEST BALLS CHANGING	
DATE		TIME		TIME	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	
156322109		156322109		156322109	



BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
09-04-80	1	00014165

DIV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. RESP.	FILE DATE			
0060	15632209	1	B	D	REPLACED BY 15632572 14165	G	INA	09-04-80	FAS01A	09-04-80			
ITEM NO.	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	66309318	5	1		PC REPLACED BY 61409021 14165	A						
002	01	90446124	1	1		PC CD ASSY 98ED DISK CONTR	S						
003	01	90446140	7	1		PC CD ASSY 98KD PWR SPLY	A						
004	01	90446143	1	1		PC CD ASSY 98MD BACKPLANE	A						
005	01	71493032	8	1		PC COVER METAL AL	P						
006	01	71493037	7	1		PC FACE PLATE (SM) PAINTED	P						
007	01	71493050	0	1		PC BASE METAL CRS	P						
008	01	71492950	2	2		PC TRACK DISK MTG	P						
009	01	71492951	0	2		PC SLIDE DISK MTG	P						
010	01	71492954	4	1		PC RDD ACTUATOR	P						
011	01	71492955	1	1		PC PANEL CABLE SUPPDR	P						
012	01	71492966	8	4		PC GUIDE CARD	P						
013	01	71493189	6	1		PC BUTTON, MINGED (PLASTIC-BLK)	P						
014	01	71492968	4	1		PC BUTTON SWITCH	P						
015	01	71493053	4	1		PC PANEL SWITCH/INDICATOR	P						
016	01	51886600	9	1		PC FAN, 50CFM 115V 50/60HZ 1PM	P						
017	01	94375401	0	1		PC GUARD, FAN 50/60HZ	P						
018	01	77618000	2	1		PC FLOPPY DISK ASSY	V						
019	01	71493064	1	4		PC FOOT	P						
020	01	91976649	3	4		PC NSCR PAN PHL M4X40NN	B						
021	01	91975724	5	8		PC NUT HEK400N SZ 5MM	B						

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
09-04-80	2	00014165

DIV	ASSEMBLY NUMBER	CD	REV.	DWG	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. RESP.	FILE DATE			
0060	15632209	1	B	D	REPLACED BY 15632572 14165	G	INA	09-04-80	FAS01A	09-04-80			
FIND NO	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
022	01	15164911	8	4		PC NSCR MEX=LK PLN M4X8NN STL ZP	B						
023	01	15164917	5	7		PC NSCR MEX=LK PLN M5X8NN STL Z	B						
024	01	91976758	2	2		PC NSCR PNH M5X10MM	B						
025	01	91976864	8	4		PC NSCR MACH FLN M5X10MM	B						
026	01	91976652	7	5		PC NSCR PAN PML M5X10MM	B						
027	01	91975706	2	5		PC WASHER LK METRIC NS	B						
028	01	71493078	1	5		PC STANDOFF HEX METRIC CRS	B						
029	01	51918435	2	1		PC ENBLEM, CDC 1D	P						
030	01	51918108	7	1		PC SPG, COMP	P						
031	01	93109381	9	2		PC STOFF, NO. 1/4 .250L RD ZINC	B						
032	01	91975684	1	7		PC WSHR METRIC SZ 5 SCREW	B						
033	01	93522018	6	1		PC PLUG, SNAP BUTTDN 1 1/4 DIA HO	P						
034	01	94374900	2	125		PC STRIP CONTACT	P						
035	01	89040204	1	8		PC WSHR, NO. 10 DISHED LOCK STL	B						
036	01	51005700	5	4		PC BUMPER SELF STICKING	P						
0036 TOTAL LINES													

BUILO ARC 440					ASSEMBLY PARTS LIST					PRINT DATE		PAGE	FILE CHANGE NO.		
					09-08-80		1	00014165							
REV.	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION			MC	STATUS	STATUS DATE		BKG. RESP.		FILE DATE	
0060	15632210	9	B	0	REPLACED BY 15632573 14165			0	INA	09-04-80		FA5018		09-08-80	
ITEM NO.	LT	PART NUMBER	CD	QTY.	U/M	PART DESCRIPTION			MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	66309319	3	1		PC REPLACED BY 61409022 14165			A						
002	01	90446124	1	1		PC CO ASSY 98ED 015K CONTR			S						
003	01	90446140	7	1		PC CO ASSY 98KO PWR SPLY			A						
004	01	90446143	1	1		PC CO ASSY 98MD BACKPLANE			A						
005	01	71493032	0	1		PC COVER METAL AL			P						
006	01	71493037	7	1		PC FACE PLATE (SM) PAINTED			P						
007	01	71493050	0	1		PC BASE METAL CRS			P						
008	01	71492950	2	2		PC TRACK 015K MT8			P						
009	01	71492951	0	2		PC SL10E 015K MT8			P						
010	01	71492954	4	1		PC ROO ACTUATOR			P						
011	01	71492955	1	1		PC PANEL CABLE SUPPORT			P						
012	01	71492966	8	4		PC 0010E CARD			P						
013	01	71493189	6	1		PC BUTTON, HINGED PLASTIC-BLK)			P						
014	01	71492968	4	1		PC BUTTON SWITCH			P						
015	01	71493053	4	1		PC PANEL SWITCH/INDICATOR			P						
016	01	51886600	9	1		PC FAN, 50CFM 115V 50/60HZ 1PH			P						
017	01	94375401	0	1		PC GUARD, FAN 50/60HZ			P						
018	01	77618000	2	1		PC FLOPPY 015K ASSY			V						
019	01	71493064	1	4		PC FOOT			P						
020	01	91976649	3	4		PC MSCR PAN PHL M4X40MM			B						
021	01	91975724	5	0		PC NUT HEXAGON 52 5MM			B						

BUILO ARC 440					ASSEMBLY PARTS LIST					PRINT DATE		PAGE	FILE CHANGE NO.				
					09-08-80		2	00714165									
REV.	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION					MC	STATUS	STATUS DATE		BKG. RESP.		FILE DATE	
0060	15632210	9	B	0	REPLACED BY 15632573 14165					0	1MA	09-04-80		FA5018		09-08-80	
ITEM NO.	LT	PART NUMBER	CD	QTY.	U/M	PART DESCRIPTION					MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
022	01	15164911	0	4		PC MSCR HEX-LK PLN M4X8MM STL ZP					B						
023	01	15164917	5	7		PC MSCR HEX-LK PLN M5X8MM STL Z					B						
024	01	91976758	2	2		PC MSCR PNH M5X10MM					B						
025	01	91976864	8	4		PC MSCR MACH FLN M5X10MM					B						
026	01	91976652	7	5		PC MSCR PAN PHL M5X10MM					B						
027	01	91975706	2	5		PC WASHER LK METRIC M5					B						
028	01	71493078	1	5		PC STANDOFF HEX METRIC CRS					B						
029	01	51918435	2	1		PC EMBLEM, COC 10					P						
030	01	51918188	7	1		PC SPG, COMP					P						
031	01	93109381	9	2		PC STOFF, MO. 1/4 .250L RO ZINC					B						
032	01	91975684	1	7		PC WASHER METRIC 52 5 SCREW					B						
033	01	93522019	6	1		PC PLUG, SNAP BUTTON 1 1/4 DIA MO					P						
034	01	94374900	2	125		PC STRIP CONTACT					P						
035	01	09040204	1	8		PC WASHER, NO. 10 OISHED LOCK STL					B						
036	01	51805700	5	4		PC BUMPER SELF STICKING					P						
0036 TOTAL LINES																	

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE
09-08-80

PAGE
1

FILE CHANGE NO.
00014165

DIV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE
0860	15632211	7	8	D	REPLACED BY 15632574 14165	0	INA	09-04-80	BR810A	09-08-80

TP/IND NO.	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	66309318	5	1		PC REPLACED BY 61409021 14165	A						
003	01	90446140	7	1		PC CD ASSY 98KO PWR SPLY	A						
004	01	90446143	1	1		PC CD ASSY 98MD BACKPLANE	A						
005	01	71493032	8	1		PC COVER METAL AL	P						
006	01	71493037	7	1		PC FACE PLATE (SM) PAINTED	P						
007	01	71493050	0	1		PC BASE METAL CRS	P						
008	01	71492950	2	2		PC TRACK DISK MTG	P						
009	01	71492951	0	2		PC SLIDE DISK MTG	P						
010	01	71492954	4	1		PC ROD ACTUATOR	P						
011	01	71492955	1	1		PC PANEL CABLE SUPPORT	P						
012	01	71492966	8	2		PC GUIDE CARO	P						
013	01	71493189	6	1		PC BUTTON, HINGED (PLATIC-BLK)	P						
014	01	71492968	4	1		PC BUTTON SWITCH	P						
015	01	71493054	2	1		PC PANEL SWITCH INDICATOR	P						
016	01	51886600	9	1		PC FAN, 50CFM 115V 50/60HZ 1PM	P						
017	01	94375401	0	1		PC GUARD, FAN 50/60HZ	P						
018	01	77418000	2	1		PC FLOPPY DISK ASSY	V						
019	01	71493064	1	4		PC FOOT	P						
020	01	91976649	3	4		PC MSCR PAN PHL M4X40MM	B						
021	01	91975724	5	8		PC NUT HEXAGON S2 5MM	B						
022	01	15164911	8	4		PC MSCR HEX-LK PLN M4X8MM S7L ZP	B						

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440					ASSEMBLY PARTS LIST					PRINT DATE		PAGE		FILE CHANGE NO.				
										09-08-80		2		00014165				
DIV.	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION					MC	STATUS	STATUS DATE		ENG. DESP.		FILE DATE	
0860	15632211		7	8	0	REPLACED BY 15632574 14165					0	INA	09-04-80		BR810A		09-08-80	
TP/IND NO.	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION					MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
023	01	15164917		5	7		PC MSCR HEX-LK PLN M5XBMM STL Z					B						
024	01	91976758		2	2		PC MSCR PNM MSX10MM					B						
025	01	91976864		8	4		PC MSCR MACH FLH MSX10MM					B						
026	01	91976652		7	5		PC MSCR PAN PHL MSX10MM					B						
027	01	91975706		2	5		PC WASHER LK METRIC M5					B						
028	01	71493078		1	4		PC STANDOFF HEX METRIC CRS					B						
029	01	51918435		2	1		PC EMBLEM, CDC ID					P						
030	01	51918188		7	1		PC SPG, COMP					P						
031	01	931093B1		9	2		PC STOFF, NO. 1/4 .250L RD ZINC					B						
032	01	91975684		1	7		PC WSHR METRIC S2 5 SCREW					B						
033	01	93522018		6	1		PC PLUG, SNAP BUTTON 1 1/4 DIA HD					P						
034	01	94374900		2	125		PC STRIP CONTACT					P						
035	01	09040204		1	8		PC WSHR, NO. 10 DISHED LOCK STL					B						
036	01	51805700		5	4		PC BUMPER SELF STICKING					P						
0035 TOTAL LINES																		

BUILD ARC 440					ASSEMBLY PARTS LIST					PRINT DATE		PAGE	FILE CHANGE NO.		
										09-08-80		1	00014165		
REV.	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		END. RESP.		FILE DATE	
0860	15632212		S	B	D	REPLACED BY 15632575 14165		0	INA	09-04-80		BR0108		09-08-80	
ITEM NO.	LI	PART NUMBER	CD	MC	QUANTITY	U/M	PART DESCRIPTION		MC	YLD	SCD. NO. IN	SCD. NO. OUT	S/N	WE IN	WE OUT
001	01	66309319	3		1		PC REPLACED BY 61489022 14165		A						
003	01	90446140	7		1		PC CD ASSY 98KD PWR SPLY		A						
004	01	90446143	1		1		PC CD ASSY 98MD BACKPLANE		A						
005	01	71493032	8		1		PC COVER METAL AL		P						
006	01	71493037	7		1		PC FACE PLATE (SM) PAINTED		P						
007	01	71493050	0		1		PC BASE METAL CRS		P						
008	01	71492950	2		2		PC TRACK DISK MT6		P						
009	01	71492951	0		2		PC SLIDE DISK MT6		P						
010	01	71492954	4		1		PC ROD ACTUATOR		P						
011	01	71492955	1		1		PC PANEL CABLE SUPPORT		P						
012	01	71492966	8		2		PC GUIDE CARD		P						
013	01	71493189	6		1		PC BUTTON, HINGED (PLASTIC-BLK)		P						
014	01	71492960	4		1		PC BUTTON SWITCH		P						
015	01	71493054	2		1		PC PANEL SWITCH INDICATOR		P						
016	01	51886600	9		1		PC FAN, 50CFM 115V 50/60HZ 1PH		P						
017	01	94375401	0		1		PC GUARD, FAN 50/60HZ		P						
018	01	77610000	2		1		PC FLOPPY DISK ASSY		V						
019	01	71493064	1		4		PC FOOT		P						
020	01	91976649	3		4		PC MSCR PAN PHL M4X40MM		B						
021	01	91975724	5		8		PC NUT HEXAGON SZ 5MM		B						
022	01	15164911	8		4		PC MSCR HEX-LK PLN M4X8MM STL ZP		B						

BUILD ARC 440					ASSEMBLY PARTS LIST					PRINT DATE		PAGE	FILE CHANGE NO.	
										09-08-80		2	00014165	
REV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		END. RESP.	FILE DATE		
0860	15632212	S	B	D	REPLACED BY 15632575 14165		0	INA	09-04-80		BR0108	09-08-80		
ITEM NO.	LI	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION	MC	YLD	PCO. NO. IN	SCO. NO. OUT	S/N	WE IN	WE OUT	
023	01	15164917	5	7		PC MSCR HEX-LK PLN M5X8MM STL Z	B							
024	01	91976758	2	2		PC MSCR PNH M5X10MM	B							
025	01	91976864	8	4		PC MSCR NACH FLH M5X10MM	B							
026	01	91976652	7	5		PC MSCR PAN PHL M5X10MM	B							
027	01	91975706	2	5		PC WASHER LK METRIC M5	B							
028	01	71493078	1	5		PC STANDOFF HEX METRIC CRS	B							
029	01	51918435	2	1		PC EMBLEM, CDC 10	P							
030	01	51918188	7	1		PC SP0, CMP	P							
031	01	93109381	9	2		PC STOFF, NO. 1/4 .250L R0 ZINC	B							
032	01	91975684	1	7		PC WSHR METRIC SZ 5 SCREW	B							
033	01	93522018	6	1		PC PLUG, SNAP BUTTON 1 1/4 DIA HD	P							
034	01	94374980	2	125		PC STRIP CONTACT	P							
035	01	89040204	1	8		PC WSHR, NO. 10 DISHED LOCK STL	B							
036	01	51805700	5	4		PC BUMPER SELF STICKING	P							
0035 TOTAL LINES														

24

25(4)

TAB 19

STUD E2 DETAIL

BUILD ARC 230										ASSEMBLY PARTS LIST										PRINT DATE	PAGE	FILE CHANGE NO.
0860										REPLACED BY 61409021 141A5										03-12-81	1	00014582
ITEM NO	U	PART NUMBER	CB	IN	QUANTITY	U/M	PART DESCRIPTION	AC	STATUS	STATUS DATE	BOO NO IN	BOO NO OUT	S/N	WK IN	WK OUT							
001	01	71497952	8		1		PC BRACKET SWITCH/FILTER/XFORM	P	INA	09-04-80												
002	01	71497953	6		1		PC COVER SWITCH/FILTER	P														
003	01	95587103	3		1		PC CB D-P 250 VAC 3 AMP	P														
004	01	15164356	6		1		PC FILTER RF1	P														
005	01	15012408	9		1		PC RSHG, SHAP-IN .500 M/H .381U	B														
007	01	44674034	2		1		PC CONN POWER RECEPT	P														
008	01	15164917	5		2		PC MSCR HEX-LK PLN M5X8MM STL Z	B														
009	01	91976625	3		4		PC MSCR PAN PHL M3X6MM	B														
010	01	10125803	6		2		PC WSHR, NO.6 SPG LOCK STL 7P	B														
011	01	10127111	2		2		PC MSCR PAN PHL 6-32X.250 STL ZP	B														
014	01	91975669	2		2		PC WSHR METRIC SCREW SZ 3	B														
015	01	44674036	7		3		PC CONN PWR RECPT	P														
016	01	51797218	8		4		PC LUG, NO.10 CRNP-R 22-18AWG	B			14199	14199		8030								
016	02	51797218	8		3		PC LUG, NO.10 CRNP-R 22-18AWG	B						8030								
017	01	24534707	5		249	FT	SLV, 3/16 HT/SHRINK BLK UL	B			14199	14199		8030	8030							
017	02	51758103	9		249	FT	INS SLV+CLR,PVC HEAT SHRINK	B						8030								
018	01	51906200	4		3		PC CONT, SKT 20-14GA .13017 STR	P														
019	01	52810001	9		333	FT	WIR 18GA STRO BRN 600V UL PVC	W			14199	14199		8030	8030							
019	02	52810001	9		458	FT	WIR 18GA STRO BRN 600V UL PVC	W						8030								
020	01	52810005	0		T08	FT	WIR 18GA STRO GRN 600V UL PVC	W			14199	14199		8030	8030							
020	02	52810005	0		833	FT	WIR 18GA STRO GRN 600V UL PVC	W						8030								
021	01	51906001	6		1		PC CONN, 3 SK7 PLUG F16 1 NYLON	P														
024	01	91975724	5		2		PC NUT HEXAGON SZ 5MM	B														

BUILD ARC 230										ASSEMBLY PARTS LIST										PRINT DATE		PAGE		FILE CHANGE NO.			
0860										REPLACED BY 61409021 14165										03-12-81		2		00014582			
06309318 5 D D										A										INA		09-04-80		FAS01A		03-12-81	
025 01 91975671 8 6										PC WASHER EX TOOTH SZ 5										B							
026 01 61408888 8 REF										PC REPLACED BY 61409023 14165										O							
027 01 52810006 8 417 FT										WIR 18GA STRD BLU 600V UL PVC										W		14199				8030	
028 01 10125605 5 2										PC WSHR, NO.6 7YP A PLN STL ZP										B		14199				8030	
										0027 TOTAL LINES																	

BUILD ARC 230

ASSEMBLY PARTS LIST

BUILD ARC 230				ASSEMBLY PARTS LIST				PRINT DATE 03-12-81		PAGE 1		FILE CHANGE NO. 00014582	
REV	ASSEMBLY NUMBER	CD	REV	QTY	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. DESG.	FILE DATE			
0860	66309319	3	D	D	REPLACED BY 61409022 14165	A	INA	09-04-80	FA501B	03-12-81			
ITEM NO.	U	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	71492952	8	1		PC BRACKET SWITCH/FILTER/XFORM	P						
002	01	71492953	6	1		PC COVER SWITCH/FILTER	P						
003	01	95587103	3	1		PC CB D-P 250 VAC 3 AMP	P						
004	01	15164356	6	1		PC FILTER RFI	P						
005	01	15012408	9	1		PC BSHG. SNAP-IN .500 M/H .3810	B						
007	01	44674034	2	1		PC CONN POWER RECEPT	P						
008	01	15164917	5	2		PC MSCR HEX-LK PLN MSX6MM STL Z	B						
009	01	91976625	3	4		PC MSCR PAN PHL M3X6MM	B						
010	01	10125803	6	2		PC WSHR, NO.6 SPG LOCK STL ZP	B						
011	01	10127111	2	2		PC MSCR PAN PHL 6-32X.250 STL ZP	B						
012	01	51919789	2	1		PC XFMR STEP DOWN 220/240V	P						
013	01	15165001	7	4		PC NUT METRIC HEX-LK M5	B						
014	01	91975669	2	2		PC WSHR METRIC SCREW SZ 3	B						
015	01	44674036	7	3		PC CONN PWR RECP7	P						
016	01	51797218	8	3		PC LUG, NO.10 CRMP-R 22-18AWG	B						
017	01	24534707	5	583	FT	SLVG, 3/16 MT/SHRINK BLK UL	B						
017	02	51758103	9	249	FT	INS SLV CLR PVC HEAT SHRINK	B		14199	14199		8030	8030
018	01	51906200	4	1		PC CONT, SK7 20-14GA .130IT STR	P						
019	01	52810001	9	250	FT	WIR 18GA STRD BRN 600V UL PVC	W						
019	02	52810001	9	458	FT	WIR 18GA STRD BRN 600V UL PVC	W		14199	14199		8030	8030
020	01	52810005	0	708	FT	WIR 18GA STRD GRN 600V UL PVC	W						
020	02	52810005	0	833	FT	WIR 18GA STRD GRN 600V UL PVC	W		14199	14199		8030	8030

BUILD ARC 230

ASSEMBLY PARTS LIST

BUILD ARC 230				ASSEMBLY PARTS LIST				PRINT DATE		PAGE		FILE CHANGE NO.				
								03-12-81		2		00014582				
REV	ASSEMBLY NUMBER			CD	REV	QTY	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. DESP.		FILE DATE	
0860	66309319			3	D	0	REPLACED BY 61409022 14165		A	INA	09-04-80		FA501B		03-12-81	
ITEM NO.	U	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION			MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
022	01	51918969		0	1		PC SWITCH VOLTAGE SELECTOR			P						
023	01	51873600		4	001	OZ	VARNISH INSUL RED GLPT			B						
024	01	91975724		5	2		PC NUT HEXAGON SZ 5MM			B						
025	01	91975671		8	6		PC WASHER EX TOOTH SZ 5			B						
026	01	61408889		6	REF		PC REPLACED BY 61409024 14165			D						
028	01	10125605		5	2		PC WSHR: NO.6 TYP A PLN STL ZP			B		14199			8030	
029	01	51758101		3	188	FT	INS SLV CLR PVC HEAT SHRINK			B		14199			8030	
0029 TOTAL LINES																

0

0

0

PARTS DATA FOR PRODUCTION UNITS ONLY



OWN	W. Gleser	6/80	CONTROL DATA	TITLE	SPL 50/60 HZ	PREFIX	DOCUMENT NO	REV.
CHKD	D. Gleser	8/70			PRIMARY FLEXIBLE DISK SUBSYSTEM	SPL	66313407	L
ENG	J. Gleser	8/70						
MFG	J. Gleser	8/70						
APPR	J. Gleser	8/70						
			CODE IDENT	FIRST USED ON	FA501A-D		SHEET	1 of 4
			15920					

SHEET REVISION STATUS										REVISION RECORD				
4	3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP					
				A	A	12754-76	RELEASED CLASS A		9-3-80	Act				
				B	A	14292	ADD F/N 16	DS	9-80	Act				
				C	C	14376	REVISED PER ECO	EE	11/2/81	Act				
				D	D	14571	CHG F/N 1,12,17, DELETE NOTE 3	WJG 12-2-81	5-2-81	Act				
				E	D	14663	ADDED F/N 18	EE	7/14/81	Act				
				F	F	14838	ADDED F/N 19 AND NOTE 7	EE	11/14/81	Act				
				F	G	14820	REVISED PER ECO	RF (11-3-81)	11-2-81	Act				
				H	H	14885	ADD FA501K CONFIG	WJG (12-2-81)	12-21-81	Act				
				J	J	14985	REVISED PER ECO	EE	1/10/82	Act				
				K	J	15771	CHANGED F/N 12 & 20	EE	3/10/83	Act				
				L	L	15867	REVISED & ADDED SA 4 PER ECO	MD	5-18-83	Act				

NOTES 1. Quantities shown are those used per equipment. Quantities used for FA501A are under Heading A. FA501B are under Heading B. FA501C are under Heading C. FA501D are under Heading D.

EQUIPMENT	EQUIPMENT CONFIGURATOR	TOP LEVEL ASSY
FA501A 60 HZ	15632205	15632572
FA501B 60 HZ (CD110)	15632206	15632573
FA501C 60 HZ (CD110)	15632207	15632573
FA501D 50 HZ (CD110)	15632981	15632982

DETACHED LISTS

AA318C REV. 8-71

PRINTED IN U.S.A.

CONTROL DATA CORPORATION	CODE IDENT	15920	SHEET	2	PREFIX	DOCUMENT NO.	66313407	REV.	L
--------------------------	------------	-------	-------	---	--------	--------------	----------	------	---

NOTES:

- These parts are the total required for a unit with no options installed.
- The FA501A/B could have 3 RAM options of 8 RAM IC's for each option for a total of 32 RAM IC's in the unit. This is standard equipment for the FA501C/D.
- Find Numbers 1 thru 7 and 17 are for the 98ED Controller Board.
- Find Number 9 is the signal cable used to connect the Primary Flexible Disk Subsystem to the IST Terminal.
- One of these devices is required on the last device on the Plato IST Parallel I/O channel daisy chain configuration.
- Original production units were built with P/N 90446140. Current production units are built with P/N 90446443. These cards are interchangeable.

AA318B

PRINTED IN U.S.A.

DWN	W. Glaser	8/80	CONTROL DATA	TITLE	SPL 50 HZ	PREFIX	DOCUMENT NO.	REV.
CHKD	D. J. J.	9/80		PRIMARY	FLEXIBLE DISK SUBSYSTEM	SPL	66313408	K
ENG	J. J. J.	9/80		FIRST USED ON	FA501B/D			
MFG	J. J. J.	9/80						
APPR	S. H. H.	9/80	CODE IDENT					SHEET 1 of 3
			15920					

SHEET REVISION STATUS										REVISION RECD				
3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP						
			A	A	12754-76	RELEASED CLASS "A"		9-3-80	ACT					
			B	B	14376	REVISED PER ECO	EE	1/12/81	200					
			C	C	14571	CHG F/N 1,13,17, DELETE NME 3	WJG 3-2-81	3-2-81	71					
			D	C	14663	ADDED F/N 18	EE	7/14/81	200					
			E	E	14938	ADDED F/N 19 AND NOTE 7	EE	10/12/81	200					
			E	F	14820	REVISED PER ECO	WJG 11-6-81	11-6-81	200					
			G	G	14885	ADD FA501D CONFIG	WJG 12-21-81	12-21-81	200					
			H	H	14985	REVISED PER ECO	EE	1/12/82	200					
			J	H	15771	CHANGED F/N 13 & 20	EE	3/11/83	200					
			K	K	15867	INACTIVE, SERVICE USE ONLY, SUPERSEDED BY 66313407	MD	5/11/83	200					

NOTES: 1. Quantities shown are those used per equipment. Quantities used for FA501B are under Heading A. FA501D are under Heading B.

EQUIPMENT	EQUIPMENT CONFIGURATOR	TOP LEVEL ASSY
FA501B 50 HZ	15632206	15632573
FA501D 50 HZ (CD110)	15632981	15632982

INACTIVE

DETACHED LISTS

AA3180 REV. B 71

PRINTED IN U.S.A.

CONTROL DATA CORPORATION	CODE IDENT	15920	SHEET 2	PREFIX	DOCUMENT NO.	66313408	REV.	K
--------------------------	------------	-------	---------	--------	--------------	----------	------	---

NOTES:

- These parts are the total required for a unit with no options installed.
- The FA501B could have 3 RAM options of 8 RAM IC's for each option for a total of 32 RAM IC's in the unit. This is standard equipment for the FA501D.
4. Fine Numbers 1 thru 7 and 17 are for the 98ED Controller Board.

5. Find Number 10 is the signal cable used to connect the Primary Flexible Disk Subsystem to the IST Terminal.

6. One of these devices is required on the last device on the PLATO IST Parallel I/O Channel daisy chain configuration.

7. Original production units were built with P/N 90446140. Current production units are built with P/N 90446443. These cards are interchangeable.

AA3180

PRINTED IN U.S.A.

CONTROL DATA		CODE IDENT 15920										SHEET 3	SPL	DOCUMENT NO. 66313408	REV.
FINO NO.	PART IDENTIFICATION	QUANTITY REQUIRED										UNIT OF MEAS	NOMENCLATURE OR DESCRIPTION	SPECIFICATIONS, NOTES, OR MATERIAL	
		A	B												
1	66312070	1	1										2716 2KXB ROM	△4	
2	15153621	8	32										4116 16K RAM	△4	
3	15163201	1	1										Z80 Processor	△4	
4	15163444	1	1										FD1791 Disk Controller	△4	
5	15163458	1	1										9517 DMA	△4	
6	15163459	1	1										9519 Interrupt Cont.	△4	
7	15164429	1	1										Z80A-CTC	△4	
8	15165426	1	1										50HZ Power Cord		
9	61409022	1	1										AC Entry Assy		
10	61408865	1	1										25 pin I/O Cable	△5	
11	96837907	1	1										Circuit Breaker		
12	77618000	1	1										Flexible Disk Assy		
13	90446570	1	0										9BED-3 Controller Board		
14	90446140	REF	REF										9BKD Power Supply	△7	
15	90446143	1	1										9BMD Backplane		
16	15632316	1	1										FT116A Terminator	△6	
17	66312071	1	1										2716 2KXB Rom	△4	
18	71493364	1	1										SCR Shoulder Nylon		
19	90446443	1	1										1AFD Power Supply	Interchangeable with F/N 14	
20	90446571	0	1										Controller Board		

AA9101 REV. 9/71

PRINTED IN U.S.A.

DWN	W. Gleser	8/80	CONTROL DATA	TITLE	60 HZ	PREFIX	DOCUMENT NO	REV.
CHKD	D. Sager	8/80		SPL SECONDARY FLEXIBLE DISK		SPL	66313409	E
ENG	P. H. H. H.	8/80		FIRST USED ON	BR810A		SHEET	1 of 3
MFG	P. H. H. H.	8/80	CODE IDENT					
APPR	P. H. H. H.	8/80	15920					

SHEET REVISION STATUS										REVISION RECORD				
3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP						
	A	A	A	12754-76	RELEASED CLASS 'A'		9-80	Met						
	B	A	B	14292	ADD F/N 7	DS	9-80	ESK						
	C	C	C	14838	ADDED F/N 8 AND NOTE 3	EE	11-81							
	D	C	D	14820	REVISED PER ECO	EE	11-81	QW						
	E	E	E	14999	F/N 8 WAS 90446290	EE	4/1/82	RIS						

NOTES:

EQUIPMENT CONFIGURATOR - 15632207

TOP LEVEL ASSEMBLY ----- 15632574

DETACHED LISTS

CS CONTROL DATA CORPORATION	CODE IDENT 15920	SHEET 2	SPL	DOCUMENT NO. 66313409	REV. E
-----------------------------------	---------------------	---------	-----	--------------------------	-----------

NOTES:

- These parts are the total required for a unit with no options installed.
- Find number 2 is the Signal Cable used to connect the BR810A or BR810B to the FA501A or FA501B.
- Original production units were built with P/N 90446140. Current production units are built with P/N 90446443. These cards are interchangeable.

AA31M

PRINTED IN U.S.A.

DWN	W. Glosier	8/80	CONTROL DATA	TITLE	50 HZ	PREFIX	DOCUMENT NO	REV.
CHKD	D. Glosier	8-80		SPL SECONDARY FLEXIBLE DISK		SPL	66313410	D
ENG	D. Glosier	8-80						
MFG	D. Glosier	8-80						
APPR	E. J. H. H.	8-2-80	CODE IDENT 15920	FIRST USED ON	BR810B		SHEET 1 of 3	

SHEET REVISION STATUS										REVISION RECORD								
										3	2	1	REV	ECO	DESCRIPTION	DRFT	DATE	APP
										A	A	A	A	12754-76	RELEASED CLASS "A"		8-3-80	Det
										B	B	B	B	14838	ADDED FN 8 AND MORE 3	EE	10/24/81	TR
										C	B	C	C	14820	REVISED PER ECO	ET	11-3-81	JKH
										D	D	D	D	14999	FN 8 WAS 90446290	EE	2/10/82	WIS

NOTES:

EQUIPMENT CONFIGURATOR - 15632208
TOP LEVEL ASSEMBLY ----- 15632575

DETACHED LISTS

CD CONTROL DATA CORPORATION	CODE IDENT 15920	SHEET 2	PREFIX SPL	DOCUMENT NO. 66313410	REV. D
-----------------------------------	---------------------	---------	---------------	--------------------------	-----------


NOTES:

- These parts are the total required for a unit with no options installed.
- Find number 3 is the Signal Cable used to connect the BR810A or BR810B to the FA501A or FA501B.
- Original production units were built with P/N 90446140. Current production units are built with P/N 90446443. These cards are interchangeable.

[illegible]

PRINTED IN U.S.A.

62949100 J



ENGINEERING SPECIFICATION.....	41-042854
SPARE PARTS LIST.....	66313407
SCHEMATIC DIAGRAM (MPS).....	90446288
SCHEMATIC DIAGRAM (SMBD).....	8048141
SCHEMATIC DIAGRAM (BRED).....	9048738
SCHEMATIC WIRING.....	67201057

[illegible]

2

3

4

EC	FA5018	FA5010
TLA	15632706	15632981
PRB ASSY 98ED	15632573	15632982
	90446570	90448571

1ST FLEXIBLE DISK
CONTROLLER
(SEE TABLE) 98ED

1ST FLEXIBLE DISK
CONTROLLER 50H2
(SEE TABLE)

AC ENTRY ASSY
G14090 22

BACKPLANE ASSY
PRB 98MD
80448143

FIBER SUPPLY
PRB 1AFD
90444443

PRB ASSY
98ED CONT BD
(SEE TABLE)

FLEX DISK
DRIVE 8400-1
2781000

REV	CO	DESCRIPTION	DRFT	DATE	CHKD	APP
00	15632706	RELEASED CLASS B	WJG	7-22-80	WJG	WJG
01	151118	DELETE 20446147	WJG	7-22-80	WJG	WJG
02	151172	SPL WAS 46308522	WJG	7-22-80	WJG	WJG
A	11545-88	RELEASED CLASS A	WJG	7-22-80	WJG	WJG
B	14165	REVISED PER ELO	WJG	7-11-80	WJG	WJG
C	14376	LOGIC WAS 90446124	WJG	7-12-80	WJG	WJG
D	14571	98ED PRB WAS 90446200	WJG	7-12-80	WJG	WJG
E	14721	REVISED PER ELO	WJG	7-12-80	WJG	WJG
F	14820	REVISED PER ELO	WJG	7-12-80	WJG	WJG
G	14885	ADD TABLE	WJG	7-12-80	WJG	WJG
H	14985	PRB 1AFD WAS 90446270	WJG	7-12-80	WJG	WJG
J	15771	REVISED PER ELO	WJG	7-12-80	WJG	WJG
K	15867	REVISED PER ELO	WJG	7-12-80	WJG	WJG

REV	CO	DESCRIPTION	DRFT	DATE	CHKD	APP
00	15632706	RELEASED CLASS B	WJG	7-22-80	WJG	WJG
01	151118	DELETE 20446147	WJG	7-22-80	WJG	WJG
02	151172	SPL WAS 46308522	WJG	7-22-80	WJG	WJG
A	11545-88	RELEASED CLASS A	WJG	7-22-80	WJG	WJG
B	14165	REVISED PER ELO	WJG	7-11-80	WJG	WJG
C	14376	LOGIC WAS 90446124	WJG	7-12-80	WJG	WJG
D	14571	98ED PRB WAS 90446200	WJG	7-12-80	WJG	WJG
E	14721	REVISED PER ELO	WJG	7-12-80	WJG	WJG
F	14820	REVISED PER ELO	WJG	7-12-80	WJG	WJG
G	14885	ADD TABLE	WJG	7-12-80	WJG	WJG
H	14985	PRB 1AFD WAS 90446270	WJG	7-12-80	WJG	WJG
J	15771	REVISED PER ELO	WJG	7-12-80	WJG	WJG
K	15867	REVISED PER ELO	WJG	7-12-80	WJG	WJG

REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION 18042854

SPARE PARTS LIST 66313407

SCHEMATIC DIAGRAM 1AFD 90446286

SCHEMATIC DIAGRAM 98MD 90448141

SCHEMATIC DIAGRAM 98ED 90448258

SCHEMATIC WIRING 6220 CS

REFERENCE DRAWING		CONTROL DATA		TITLE	
FA5018/D		FA5018/D		GENEALOGY CHART	
COMPONENTS, EXCEPT AS NOTED		FIRST USED ON		PRIMARY FLEXIBLE DISK	
TOLERANCE		DWN		SUBSYSTEM 50H2	
VALUE		ENGR		DRAWING NO	
DATE		APR		15920	
BY		APR		CODE BENT	
BY		APR		15920	
BY		APR		DRAWING NO	
BY		APR		66310613	
BY		APR		SCALE	
BY		APR		SHEET	
BY		APR		OF	

SHEET REVISION STATUS				REVISION RECORD			
REV	CD	DESCRIPTION	DATE	DRFT	DATE	DRFT	APP
00	6000/12	RELEASED CLASS "B"	7/1/77				
01	51118	DELETE 30446147	WJG 6-9-80				
A	11545-80	RELEASED CLASS "A"	7-23-80				
B	14165	REVISED PER ECO	WJA 9/1/80				
C	14721	REVISED PER ECO	EE 7/30/82				
D	14820	REVISED PER ECO	EE 10-3-81				
E	14985	PMB INF 90446290	EE 1/1/82				

1ST FLEXIBLE DISK FC
SECONDARY 60HZ
15632207

BRG10A

1ST FLEXIBLE DISK TA
SECONDARY 60HZ
15632574

AC ENTRY ASST
60409021

BACKPLANE ASST
PMB 88ND
90448143

POWER SUPPLY
PMB INF
90446443


FLEX DISK
PMB INF
77818000

REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION..... 16042254
SPARE PARTS LIST..... 66313409
SCHEMATIC DIAGRAM (INF)..... 90446288
SCHEMATIC DIAGRAM (88ND)..... 90448141
SCHEMATIC WIRING..... 62201057

REFERENCE DRAWING		CONTR. DATA		TITLE	
		88310A		GENEALOGY CHART	
		88310A		SECONDARY FLEXIBLE DISK DRIVE 60HZ	
PART USED ON		DRAWN		CODE BOOK	
CHD		ENG		15920	
MFG		APR		DRAWING NO	
CN		7-15-78		C 66310612	
COMP. PARTS EXCEPT AS NOTED		TOLERANCE		CROSS REF. NO.	
VAL		RATING		SHEET	
1		2		OF 1	

66310612



REFERENCE DOCUMENTS

ENGINEERING SPECIFICATION.....10042054
 SPARE PARTS LIST.....1-12
 SCHEMATIC DIAGRAM (IAPD).....90446200
 SCHEMATIC DIAGRAM (BRB).....90446141
 SCHEMATIC N 2:16.....6225-5

SHEET REVISION STATUS				REVISION RECORD			
REV	CO	DESCRIPTION	DATE	CHKD	APP		
00	6000/10	RELEASED CLASS B	7/1/74				
01	51118	DELETE 90446147	WJG 6-5-80				
02	51172	SPL WAS 66308920	WJG 7-22-80				
A	11525-00	RELEASED CLASS A	7-27-80				
B	114 65	REVISED PER ESS	WJG 1-15-80				
C	14721	REVISED PER ECO	EE 7/1/81				
D	14820	REVISED PER ECO	WJG 11-3-81				
E	14985	PWB IAFD WAS 90446200	EE 10/12/82				

TITLE		GENEALOGY CHART	
SECONDARY FLEXIBLE DISK DRIVE 50HZ			
CODE IDENT	15070	DRAWING NO	66310614
CROSS REF NO		SHEET	1 OF 1
SCALE			
REFERENCE DRAWING	N. P. C. 1	BRB10B	BRB10B
FIRST USED ON	OWN	CHD	ENG
COMPONENTS EXCEPT AS NOTED	VALUE	RATING	
TOLERANCE			
RES			
CAP			

66310614

15632572	PRIMARY	60 HZ
15632573	PRIMARY	50 HZ
15632574	SECONDARY	60 HZ
15632575	SECONDARY	50 HZ


[illegible]

EMERGENCY CONVERSION PROCEDURE


THIS PROCEDURE IS TO BE USED TO CONVERT THE FPM UNIT FROM ONE OPERATION TO ANOTHER APPLICATION, OR OTHER MEANS. THIS IS ACCOMPLISHED BY MEASURING THE BALL-DIAMETER REVERENDS FULLY ON THE SPINDLE-DRIVEN SLIP USING THE FOLLOWING STEPS

- [illegible]

IT IS IMPORTANT THAT THE WFO OPERATING FREQUENCY BE MARKED ON THE UNIT'S RATING NAMEPLATE. USE A 3/8 INCH X 3/8 INCH GUMMED LABEL BETWEEN THE UNIT'S RATING NAMEPLATE WITH THE CORRECT FREQUENCY.



THE UNIVERSITY OF CHICAGO



(TOP VIEW SHOWN WITH ITEMS 5, 8, 9, & 18 REMOVED)


NOTES:

⚠ MARK ASSY 1563257X IN AREA SHOWN
PER CDC SPEC 10121508.

2. CONNECT SUBASSEMBLIES AS FOLLOWS:

PLUG A4P1 INTO ALJ9
PLUG A4P2 INTO ALJ4
PLUG A4P3 INTO ALJ1
PLUG A4P4 INTO BLJ1
PLUG A5P3 INTO A4J3

3. MARK NO'S ONLY PER CDC SPEC 10121508,
.12 HIGH, WHITE, IN LOCATION APPROX A3
SHOWN.
PLUG ASP3 INTO A4J3

 OPTIC RODS (F/N 44) TO BE INSTALLED FROM BACK OF FACE PLATE (F/N 6). INSTALL RODS UNTIL THEY ARE FLUSH WITH FRONT OF FACE PLATE. THEN APPLY VERY SMALL AMOUNT (LESS THAN A DROP) OF ADHESIVE (F/N 45) AROUND EACH ROD, ON BACK SIDE OF FACE PLATE. WIPE OFF EXCESS.

5 TIGHTEN SCREW F/N 49 BY HAND, DO NOT USE ANY TOOLS.

METRIC

PLATO FLEXIBLE DISK

(TIA)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255	256	257	258	259	260	261	262	263	264	265	266	267	268	269	270	271	272	273	274	275	276	277	278	279	280	281	282	283	284	285	286	287	288	289	290	291	292	293	294	295	296	297	298	299	300	301	302	303	304	305	306	307	308	309	310	311	312	313	314	315	316	317	318	319	320	321	322	323	324	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339	340	341	342	343	344	345	346	347	348	349	350	351	352	353	354	355	356	357	358	359	360	361	362	363	364	365	366	367	368	369	370	371	372	373	374	375	376	377	378	379	380	381	382	383	384	385	386	387	388	389	390	391	392	393	394	395	396	397	398	399	400	401	402	403	404	405	406	407	408	409	410	411	412	413	414	415	416	417	418	419	420	421	422	423	424	425	426	427	428	429	430	431	432	433	434	435	436	437	438	439	440	441	442	443	444	445	446	447	448	449	450	451	452	453	454	455	456	457	458	459	460	461	462	463	464	465	466
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

020

15632205/0

VIEW H-H
SCALE: NONE

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
03-31-83	1	00015812

DIV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. RESP.	FILE DATE			
0060	15632572	2	W	D	FD 58g, PRIMARY 60HZ (TA)	0	REL	09-03-80	FA501A	03-31-83			
ITEM NO.	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	61409021	5	1		PC AC ENTRY, FLEX DISK 60HZ	A						
002	03	90446204	3	1		PC REPLACED BY 90446570 15771	N		14571	15771		8113	8314
002	04	90446570	5	1		PC CD ASSY 98ED-3	N		15771			8314	
003	03	90446443	5	1		PC PC CD ASSY 1AFD	A		14985			8209	
004	01	90446143	1	1		PC CD ASSY 98ND BACKPLANE	A						
005	01	71493032	8	1		PC COVER METAL AL	P						
006	01	71493185	4	1		PC FACE PLATE	P						
007	01	71493188	8	1		PC BASE	P						
008	02	71493295	1	2		PC TRACK DISK MTG	P		14539			8143	
009	02	71493296	9	2		PC SLIDE DISK MTG	P		14539			8143	
010	01	96837907	3	1		PC CKT BRKR MAGNETIC 3.0 AMPS	P						
011	01	71492955	1	1		PC PANEL CABLE SUPPORT	P						
012	01	71492966	8	4		PC GUIDE CARD	P						
014	02	71492968	4	1		PC BUTTON SWITCH	P			15812			8321
014	03	61409606	3	1		PC SWITCH BUTTON ASSY	N		15812			8321	
015	01	71493055	9	1		PC PANEL SWITCH IND	P						
016	01	51886600	9	1		PC FAN, 58CFM 1PH 115VAC 50/60HZ	P						
017	01	94375401	0	1		PC GUARD, FAN 50/60HZ	P						
018	01	77018000	2	1		PC FLEX DISK DRV, 9406 2-SIDED	V						
019	02	71493350	4	4		PC FOOT	P		14853			8147	
020	01	91976649	3	4		PC M5CR PAN PHL M4X40MM STL ZP	B						
021	01	91975724	5	8		PC NUT, HEX M5 STL ZP	B			15786			8320

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
03-31-83	2	00015812

DIV.	ASSEMBLY NUMBER				CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE		ENG RESP	FILE DATE	
0060	15632572				2	W	D	FD 58S, PRIMARY 60HZ (TA)	0	REL	09-03-80		FA501A	03-31-83	
ITEM NO	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION			MC	YLR	ECO NO. IN	ECO NO. OUT	S/N	WE IN	WE OUT
021	02	15165001	7	8		PC NUT, HEX/FLG-LK M5 STL ZP			B		15786			8320	
022	01	15164911	8	4		PC MSCR HEX/W-LK PLN M4X8MM STL			B						
023	01	15164917	5	4		PC MSCR HEX/W-LK PLN M5X8MM STL			B			15289		8238	8238
023	02	15164917	5	12		PC MSCR HEX/W-LK PLN M5X8MM STL			B		15289			8238	
024	01	91976758	2	5		PC MSCR PAN PHL M5X10MM SST PASS			B			15289		8238	
025	01	91976864	8	4		PC MSCR FLT PHL M5X10MM STL ZP			B						
026	01	91976652	7	5		PC MSCR PAN PHL M5X10MM STL ZP			B			15289		8238	8238
026	02	91976652	7	2		PC MSCR PAN PHL M5X10MM STL ZP			B		15289			8238	
027	01	91975706	2	5		PC WSHR, M5 LOCK SST PASS			B			15289		8238	
028	01	71493078	1	5		PC STANDOFF HEX METRIC CRS			P						
029	03	51918435	2	1		PC EMBLEM, CDC 10			P		14742			8136	
031	01	93109381	9	2		PC STOFF, NO. 1/4 .025 L RD ZINC			P						
032	01	91975684	1	6		PC WSHR, M5 EXT/T SST PASS			B			15786		8320	8320
032	02	91975671	8	6		PC WSHR, M5 EXT/T 5PG-STL 7P			B		15786			8320	
033	01	93522018	6	1		PC PLUG, SNAP BUTTON 1 1/4 DIA HO			P						
034	01	94374900	2	125		PC STRIP CONTACT			P						
035	01	89040204	1	8		PC WSHR, NO. 10 DISHED LOCK STL			B			15786		8320	
037	01	62044200	4	1		PC CLAMP-CABLE ADHESIVE BACK			B						
038	04	94277400	1	1		PC STRAP, CBL TIE TYP-1 TO 5/A			B		14539			8143	
039	02	71493294	4	1		PC SHIELD			P		14539			8143	
040	02	94952302	1	1		PC CLIP CORD TYPE 3 NYLON			P		14742A			8136	
041	01	10127103	9	4		PC MSCR PAN PHL 4-40X.312 STL ZP			B		14454			8041	

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440					ASSEMBLY PARTS LIST				PRINT DATE		PAGE	P/R CHANGE NO			
					03-31-83				3	00015812					
DIV.	ASSEMBLY NUMBER		CR	REV	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG DESG	FILE DATE		
0860	15632572		2	W	D	FD SBS, PRIMARY 60HZ (TA)		8	REL	09-03-80		FA501A	03-31-83		
TRND NO	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION		MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WR IN	WR OUT
042	01	10126400	0	4			PC WSHR, (4) EXT/T LK STL ZP	B		14454				8041	
043	01	71493269	6	1			PC SHIELD	P		14454				8041	
044	01	71493297	7	4			PC ROD OPTIC	P		14591				8114	
045	01	94850711	6	001			OZ SEAL, EASTMAN CLR (910)	B		14591				8114	
046	01	94277411	8	2			PC STRAP, CRL TIE TYP-1 TO 1-1/8	B		14539A				8133	
047	01	71493354	6	1			PC RAIL SUPPORT PC CD	P		14663				8133	
048	01	71493360	3	1			PC GUIDE-PC CONN	P		14663				8133	
049	01	71493364	5	1			PC SCREW SHLDR NYLON	P		14663				8133	
050	01	91976507	3	1			PC WSCR PAN 5LT M3X10MM NYL NAT	B		14663				8133	
0053 TOTAL LINES															

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
03-31-83	1	00015012

DIV	ASSEMBLY NUMBER	CD	REV.	QWG	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE			
0860	15632573	0	W	D	FD SBS, PRIMARY 50HZ (TA)	8	REL	09-03-80	FA5018	03-31-83			
ITEM NO.	LT	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	61489022	3	1		PC AC ENTRY, FLEX DISK 50HZ	A						
002	03	90446284	3	1		PC REPLACED BY 90446570 1ST71	N		14571	15771		0113	0314
002	04	90446570	5	1		PC CD ASSY 98ED-3	N		15771			0314	
003	03	90446443	5	1		PC PC CD ASSY 1AFO	A		14985			0209	
004	01	90446143	1	1		PC CD ASSY 98MD BACKPLANE	A						
005	01	T1493032	8	1		PC COVER METAL AL	P						
006	01	T1493185	4	1		PC FACE PLATE	P						
007	01	T1493188	8	1		PC BASE	P						
008	02	T1493295	1	2		PC TRACK DISK MTG	P		14539			0143	
009	02	T1493296	9	2		PC SLIDE DISK MTG	P		14539			0143	
010	01	9683790T	3	1		PC CKT BRKR MAGNETIC 3.0 AMPS	P						
011	01	T1492955	1	1		PC PANEL CABLE SUPPORT	P						
012	01	T1492966	8	4		PC GUIDE CARD	P						
014	02	T1492968	4	1		PC BUTTON SWITCH	P			15812		0321	0321
014	03	61489606	3	1		PC SWITCH BUTTON ASSY	N		15812			0321	
015	01	T1493055	9	1		PC PANEL SWITCH 1NO	P						
016	01	51886600	9	1		PC FAN, 50CFM 1PH 115VAC 50/60HZ	P						
017	01	94375401	0	1		PC GUARD, FAN 50/60HZ	P						
018	01	T7618000	2	1		PC FLEX DISK DRV, 9406 2-SLIDE	V						
019	02	T1493350	4	4		PC FOOT	P		14853			0147	
020	01	91976649	3	4		PC MSCR PAN PHL 44X40MM STL ZP	B						
021	01	91975724	5	8		PC NUT, HEX M5 STL ZP	B			15786		0320	

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
03-31-83	2	00015012

DIV	ASSEMBLY NUMBER				CD	REV	QWG	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE	
0860	15632573				0	W	D	FD SBS, PRIMARY 50HZ (TA)		6	REL	09-03-80		FA5018		03-31-83	
ITEM NO	LT	PART NUMBER		CD		QUANTITY	U/M	PART DESCRIPTION		MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT	
021	02	15165001		7		8		PC NUT, HEX/FLG-LK M5 STL ZP		B		15786				0320	
022	01	15164911		8		4		PC MSCR HEX/W-LK PLN 44X8MM STL		B							
023	01	15164917		5		4		PC MSCR HEX/W-LK PLN 44X8MM STL		B			15289			0238	
023	02	15164917		5		12		PC MSCR HEX/W-LK PLN 44X8MM STL		B		15289			0238		
024	01	91976758		2		5		PC MSCR PAN PHL 44X10MM SST PASS		B			15289			0238	
025	01	91976864		8		4		PC MSCR FLT PHL 44X10MM STL ZP		B							
026	01	91976652		7		5		PC MSCR PAN PHL 44X10MM STL ZP		B			15289			0238	
026	02	91976652		7		2		PC MSCR PAN PHL 44X10MM STL ZP		B		15289			0238		
027	01	91975706		2		5		PC WSHR, M5 LOCK SST PASS		B			15289			0238	
028	01	71493078		1		5		PC STANDOFF HEX METRIC CRS		P							
029	03	51918435		2		1		PC EMBLEM, CDC ID		P		14742			0136		
031	01	93109381		9		2		PC STOFF, NO. 1/4 250L RD ZINC		P							
032	01	91975684		1		6		PC WSHR, M5 EXT/T SST PASS		B			15786			0320	
032	02	91975671		8		6		PC WSHR, M5 EXT/T SPG-STL ZP		B		15786			0320		
033	01	93522018		6		1		PC PLUG+SNAP BUTTON 1 1/4 DIA HD		P							
034	01	94374900		2		125		PC STRIP CONTACT		P							
035	01	09040204		1		8		PC WSHR, NO. 10 DISHED LOCK STL		B			15786			0320	
037	01	62044200		4		1		PC CLAMP-CABLE ADHESIVE BACK		B							
038	04	94277400		1		1		PC STRAP, CRL TIE TYP-1 TO 5/8		B		14539			0143		
039	02	T1493294		4		1		PC SHIELD		P		14539			0143		
040	02	94952302		1		1		PC CLIP CORD TYPE 3 NYLON		P		14742A			0136		
041	01	10127103		9		4		PC MSCR PAN PHL 4-40X.312 STL ZP		B		14454			0041		

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440						ASSEMBLY PARTS LIST			PRINT DATE		PAGE	FILE CHANGE NO			
									03-31-83		3	00015812			
DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION		AC	STATUS	STATUS DATE		ENG DESP		PLS DATE	
0860	15632573		C	W	D	FD S85, PRIMARY 50W, (TA)		6	REL	09-03-80		FA5018		03-31-83	
TP/NO	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION		AC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
042	01	10126400		0	4		PC WSHR, (4) EXT/T LK STL ZP		B		14454			8041	
043	01	71493269		6	1		PC SHIELD		P		14454			8041	
044	01	71493297		7	4		PC ROD OPTIC		P		14591			8114	
045	01	94850711		6		001	OZ SEAL, EASTMAN CLR (910)		U		14591			8114	
046	01	94277411		8	2		PC STRAP, CBL TIE TYP-1 TO 1-1/8		B		14539A			8133	
047	01	71493354		6	1		PC RAIL SUPPORT PC CO		P		14663			8133	
048	01	71493360		3	1		PC GUIDE-PC CONN		P		14663			8133	
049	01	71493364		5	1		PC SCREW SHLDR NYLON		P		14663			8133	
050	01	91076507		3	1		PC HSCR PAN SLT M3X10MM NYL NAT		B		14663			8133	
0053 TOTAL LINES															

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE		PAGE	FILE CHANGE NO.	
03-31-83		1	00015812	
STATUS DATE		ENG. RESP.		FILE DATE
09-03-80		BR010A		03-31-83
SCO. NO. IN	SCO. NO. OUT	S/N	WE IN	WE OUT
14985			8209	
14539			8143	
14539			8143	
14984			8204	
	15012			8321
14853			8147	
15786	15786		8320	8320

BUILD ARC 440

ASSEMBLY PARTS LIST

BU1LD ARC 440					ASSEMBLY PARTS LIST				PRINT DATE		PAGE		FILE CHANGE NO.				
									03-31-83		2		00015812				
DIV		ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION			MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE	
0860		15632574		8	W	D	FD 585, SECONDARY 60HZ (TA)			0	REL	09-03-80		BR810A		03-31-83	
ITEM NO.	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION			MC	YLD	ECO. NO. IN	ECO. NO. OUT	E/N	WE IN	WE OUT	
023	01	15164917		5	4		PC	MSCR HEX/W-LK PLN M5X8MM STL			B						
023	02	15164917		5	12		PC	MSCR HEX/W-LK PLN M5X8MM STL			B		15289		15289	8238	
024	01	91976758		2	5		PC	MSCR PAN PHL M5X10MM SST PASS			B			15289		8238	
025	01	91976864		8	4		PC	MSCR FLT PHL M5X10MM STL ZP			B						
026	01	91976652		7	5		PC	MSCR PAN PHL M5X10MM STL ZP			B			15289		8238	
026	02	91976652		7	2		PC	MSCR PAN PHL M5X10MM STL ZP			B		15289		8238		
027	01	91975706		2	5		PC	WSHR, M5 LOCK SST PASS			B			15289		8238	
028	01	71493078		1	4		PC	STANDOFF HEX METRIC CRS			P						
029	03	51918435		2	1		PC	EMBLEM, CDC ID			P		14742		8136		
031	01	93109381		9	2		PC	STOFF, NO. 1/4 .0250L RD ZINC			P						
032	01	91975684		1	6		PC	WSHR, M5 EXT/T SST PASS			B			15786		8320	
032	02	91975671		8	6		PC	WSHR, M5 EXT/T SPG-STL ZP			B		15786		8320		
033	01	93522018		6	1		PC	PLUG, SNAP BUTTON 1 1/4 DIA HO			P						
034	01	94374900		2	125		PC	STRIP CONTACT			P						
035	01	09040204		1	8		PC	WSHR, NO. 10 DISHED LOCK STL			B			15786		8320	
037	01	62044200		4	1		PC	CLAMP-CABLE ADHESIVE BACK			B						
038	04	94277400		1	1		PC	STRAP, CBL TIE TYP-1 7D S/A			B		14539		8143		
039	02	71493294		4	1		PC	SHIELD			P		14539		8143		
040	82	94952302		1	1		PC	CLIP CORD TYPE 3 NYLON			P		14742A		8136		
046	01	94277411		8	2		PC	STRAP, CBL TIE TYP-1 TO 1-1/8			B		14539A		8133		

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE		PAGE		FILE CHANGE NO									
03-31-83		3		00015012									
DIV.	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION	SC	STATUS	STATUS DATE	ENG. DESK	FILE DATE			
8860	15632574	8	M	D	FD SBS, SECONDARY 60HZ (TA)	0	REL	09-03-80	MR810A	03-31-83			
ITEM NO	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	SC	VLS	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
0041 TOTAL LINES													

BUILD ARC 440

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
03-31-83	1	00010012

DIV.	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE			
0060	15632575	S	M	D	FD 585, SECONDARY 50HZ (TA)	0	REL	09-03-80	BR0100	03-31-83			
ITEM NO.	LT	PART NUMBER	CS	QTY.	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	61409022	3	1		PC AC ENTRY, FLEX DISK 50HZ	A						
003	03	90446443	5	1		PC PC CD ASSY 1APD	A		14905			0209	
004	01	90446143	1	1		PC CD ASSY 90ND BACKPLANE	A						
005	01	71493032	0	1		PC COVER METAL AL	P						
006	01	71493105	4	1		PC FACE PLATE	P						
007	01	71493100	0	1		PC BASE	P						
008	02	71493295	1	2		PC TRACK DISK MT0	P		14539			0143	
009	02	71493296	9	2		PC SLIDE DISK MT0	P		14839			0143	
010	01	90037907	3	1		PC CKT BRKR MAGNETIC 3.0 AMPS	P						
011	01	71492955	1	1		PC PANEL CABLE SUPPORT	P						
012	02	71492906	0	4		PC GUIDE CARD	P		14904			0204	
014	01	71492968	4	1		PC BUTTON SW17CH	P			15012			0321
015	01	71493054	2	1		PC PANEL SW17CH INDICATOR	P						
016	01	51006600	9	1		PC FAN, 50CFM 1PH 115VAC 50/60HZ	P						
017	01	94375401	0	1		PC GUARD, FAN 50/60HZ	P						
018	01	77610000	2	1		PC FLEX DISK DRV, 9406 2-SIDED	V						
019	02	71493350	4	4		PC FOOT	P		14053			0147	
020	01	91976649	3	4		PC MSCR PAN PHL M4X40MM S7L 2P	B						
021	01	91975724	5	0		PC NUT, HEX M5 S7L 2P	B			15706			0320
021	02	15165001	7	0		PC NUT, HEX/FLG-LK M5 S7L 2P	B		15706			0320	
022	01	15164911	0	4		PC MSCR HEX/W-LK PLN M4X40MM STL	B						

BUILD ARC 440

ASSEMBLY PARTS LIST


PRINT DATE	PAGE	FILE CHANGE NO.
03-31-83	2	00010012

DIV.	ASSEMBLY NUMBER			CD	REV.	QTY.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. DESG.	FILE DATE	
0060	15632575			S	N	0	FD 585, SECONDARY 50HZ (TA)		0	REL	09-03-80		BR0100	03-31-83	
ITEM NO.	LT	PART NUMBER		CS	IN	QUANTITY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
023	01	15164917		5		4		PC MSCR HEX/W-LK PLN M5X8MM S7L	B			15209		0230	0230
023	02	15164917		5		12		PC MSCR HEX/W-LK PLN M5X8MM S7L	B		15209			0230	0230
024	01	91976750		2		5		PC MSCR PAN PHL M5X10MM S57 PASS	B			15209			0230
025	01	91976064		0		4		PC MSCR FL7 PHL M5X10MM S7L 2P	B						
026	01	91976652		7		5		PC MSCR PAN PHL M5X10MM S7L 2P	B			15209			0230
026	02	91976652		7		2		PC MSCR PAN PHL M5X10MM S7L 2P	B		15209			0230	
027	01	91975706		2		5		PC WSHR, M5 LOCK S57 PASS	B			15209			0230
028	01	71493070		1		5		PC STANDOFF HEX METRIC CRS	P						
029	03	51910435		2		1		PC EMBLEM, CDC 10	P		14742			0136	
031	01	93109301		9		2		PC S7OFF, NO. 1/4 .0250L RD ZINC	P						
032	01	91975604		1		6		PC WSHR, M5 EX7/7 S57 PASS	B			15706			0320
032	02	91975671		0		6		PC WSHR, M5 EX7/7 SPS-S7L 2P	B		15706			0320	
033	01	93522010		0		6		PC PLUG, SNAP BUTON 1 1/4 DIA MO	P						
034	01	94374900		2		125		PC S7RIP CONTACT	P						
035	01	09040204		1		0		PC WSHR, NO. 10 DISHED LOCK S7L	B			15706			0320
037	01	02044200		4		1		PC CLAMP-CABLE ADHESIVE BACK	B						
038	04	94277400		1		1		PC STRAP, CBL TIE TYP-1 70 5/A	B		14539			0143	
039	02	71493294		4		1		PC SHIELD	P		14539			0143	
040	02	94952302		1		1		PC CLIP CORO TYPE 3 NYLON	P		14742A			0136	
040	01	94277411		0		2		PC STRAP, CBL TIE TYP-1 TO 1-1/8	B		14039A			0133	










BUILD ARC 440

ASSEMBLY PARTS LIST

REV		ASSEMBLY NUMBER		CD	REV.	QTY.	DESCRIPTION	AC	STATUS	STATUS DATE	REQ. QTY.	FILE DATE
0066		15632575		5	W	D	FD 585, SECONDARY 50HZ (TA)	6	REL	09-03-80	000100	03-31-83
FORM NO.	11	PART NUMBER		CD	REV.	QTY.	DESCRIPTION	AC	STATUS	STATUS DATE	REQ. QTY.	FILE DATE
0001 TOTAL LINES												



REV	NO	DESCRIPTION	DATE	BY
1	1	2862551 2		



CD110 FLEXIBLE DISK (TLA)		REV	NO	DESCRIPTION	DATE	BY
1	1	15642982				

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440					ASSEMBLY PARTS LIST			PRINT DATE		PAGE	FILE CHANGE NO					
								03-31-83		1	00015812					
DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. RESP.	FILE DATE			
0860	15632982		3	G	D	FDD, COIL, PRIMARY 50HZ (TA)		6	REL	12-18-81		FA5010	03-31-83			
ITEM NO	LT	PART NUMBER		CD	MC	QUANTITY	U/M	PART DESCRIPTION		MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	61409022		3		1		PC AC ENTRY, FLEX DISK 50HZ	A							
002	01	90446396		5		1		PC REPLACED BY 90446571 15771	S							
002	02	90446571		3		1		PC CD ASSY CONT MOD W/FULL MEM	S			15771			8314	8314
003	02	90446443		5		1		PC PC CO ASSY 1AFO	A			14985			8209	
004	01	90446143		1		1		PC CD ASSY 98HD BACKPLANE	A							
005	01	71493032		8		1		PC COVER METAL AL	P							
006	01	71493185		4		1		PC FACE PLATE	P							
007	01	71493188		8		1		PC 8A5E	P							
008	01	71493295		1		2		PC TRACK DISK M70	P							
009	01	71493296		9		2		PC SLIDE DISK M70	P							
010	01	96837907		3		1		PC CK7 BRKR MAGNETIC 3.0 AMPS	P							
011	01	71492955		1		1		PC PANEL CABLE SUPPORT	P							
012	01	71492966		8		4		PC GUIDE CARO	P							
014	02	71492968		4		1		PC BUTTON SWITCH	P							
014	03	61409606		3		1		PC SWITCH BUTTON ASSY	N			15812	15812		8321	8321
015	01	71493055		9		1		PC PANEL SWITCH IND	P							
016	01	51886600		9		1		PC FAN, 50CFM 1PH 115VAC 50/60HZ	P							
017	01	94375401		0		1		PC GUARD, FAN 50/60HZ	P							
018	01	77618000		2		1		PC FLEX DISK DRV, 9406 2-510ED	V							
019	01	71493350		4		4		PC FOOT	P							
020	01	91976649		3		4		PC MSCR PAN PHL M4X40MM S7L ZP	B							
021	01	91975724		5		8		PC NUT, HEX M5 S7L ZP	B				15786			8320

BUILD ARC 440

ASSEMBLY PARTS LIST

BUJLO ARC 440

ASSEMBLY PARTS LIST

PRINT DATE

PAGE

FILE CHANGE NO.

03-31-83

2

00015812

DIV	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. RESP.	FILE DATE			
0860	15632982	3	G	0	FDD, COIL, PRIMARY 50HZ (TA)	6	REL	12-18-81	FA5010	03-31-83			
ITEM NO	LT	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
021	02	15165801	7	8		PC NUT, HEX/FLG-LK M5 S7L ZP	B		15786			8320	
022	01	15164911	8	4		PC MSCR HEX/W-LK PLN M4X8MM S7L	B						
023	01	15164917	5	4		PC MSCR HEX/W-LK PLN M5X8MM S7L	B		15289	15289		8238	8238
023	02	15164917	5	12		PC MSCR HEX/W-LK PLN M5X8MM S7L	B					8238	
024	01	91976758	2	5		PC MSCR PAN PHL M5X10MM S57 PASS	B			15289		8238	
025	01	91976864	8	4		PC MSCR FLT PHL M5X10MM S7L ZP	B						
026	01	91976652	7	5		PC MSCR PAN PHL M5X10MM S7L ZP	B		15289	15289		8238	8238
026	02	91976652	7	2		PC MSCR PAN PHL M5X10MM S7L ZP	B					8238	
027	01	91975706	2	5		PC WSHR, M5 LOCK S57 PASS	B			15289		8238	
028	01	71493078	1	5		PC STANDOFF HEX METRIC CRS	P						
029	01	51918435	2	1		PC EMBLEM, COC 10	P						
031	01	93109381	9	2		PC STOFF, NO. 1/4 .250L RO ZINC	P						
032	01	91975684	1	6		PC WSHR, M5 EX7/T SST PASS	B		15786	15786		8320	8320
032	02	91975671	8	6		PC WSHR, M5 EX7/T SP8-S7L ZP	B					8320	
033	01	93522010	6	1		PC PLUG, SNAP BUTTON 1 1/4 DIA HO	P						
034	01	94374900	2	125		PC STRIP CONTACT	P						
035	01	09040204	1	8		PC WSHR, NO. 10 OISHEO LOCK S7L	B			15786		8320	
036	01	51805700	5	4		PC BUMPER SELF STICKING	P			15669		8301	
037	01	62844200	4	1		PC CLAMP-CABLE ADHESIVE BACK	B						
038	01	94277400	1	1		PC STRAP, CBL TIE TYP-1 TO 5/8	B						
039	01	71493294	4	1		PC SHIELD	P						
040	01	94952302	1	1		PC CLIP CORD TYPE 3 NYLON	P						

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440										ASSEMBLY PARTS LIST										PRINT DATE		PAGE		PLI CHANGE NO.	
																				03-31-83		3		00015012	
DIV.		ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION				REV.	STATUS	STATUS DATE		DWG. DESK.		PLI DATE								
0000		15632982		3	6	D	FDD: CD110 PRIMARY 50HZ (TA)				6	REL	12-10-81		FA501D		03-31-83								
ITEM NO.	LT	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION				REV.	YTD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT								
041	01	10127103		9	4		PC MSCR PAN PHL 4-40X.312 STL ZP				B														
042	01	10126400		0	4		PC WSHR. (4) EXT/T LK STL ZP				B														
043	01	71493269		6	1		PC SHIELD				P														
044	01	71493297		7	4		PC ROD OPTIC				P														
045	01	94850711		6	001		OZ SEAL. EASTMAN CLR (910)				B														
046	01	94277411		8	2		PC STRAP. CHL TIE TYP-1 TO 1-1/8				B														
047	01	71493354		6	1		PC RAIL SUPPDRT PC CD				P														
048	01	71493360		3	1		PC GUIDE-PC CONN				P														
049	01	71493364		5	1		PC SCREW SHLDR NYLON				P														
050	01	91976507		3	1		PC MSCR PAN SLT M3X10MM NYL MAT				B														
0054 TOTAL LINES																									

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440					ASSEMBLY PARTS LIST			PRINT DATE		PAGE		FILE CHANGE NO.				
								03-31-83		1		00015812				
DIV	ASSEMBLY NUMBER		CR	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE		
0866	15632903		1	0	D	FDD: CD110 PRIMARY 60HZ (TA)		0	REL	12-10-81		FA501C		03-31-83		
TP/NO	LI	PART NUMBER		CD	IN	QUANTITY	U/M	PART DESCRIPTION		MC	YLR	DCO. NO. IN	DCO. NO. OUT	S/N	WE IN	WE OUT
001	01	61409021		5		1		PC AC ENTRY, FLEX DISK 60HZ		A						
002	01	90446396		5		1		PC REPLACED BY 90446571 15771		S			15771			0314
002	02	90446571		3		1		PC CD ASSY CONT MOD W/FULL MEM		S		15771			0314	
003	01	90446290		8		1		PC REPLACED BY 90446443 14905		A			14905			0209
003	02	90446443		5		1		PC PC CD ASSY 1AFD		A		14905			0209	
004	01	90446143		1		1		PC CD ASSY 90MD BACKPLANE		A						
005	01	71493032		8		1		PC COVER METAL AL		P						
006	01	71493105		4		1		PC FACE PLATE		P						
007	01	71493108		6		1		PC BASE		P						
008	01	71493295		1		2		PC TRACK DISK MT6		P						
009	01	71493296		9		2		PC SLIDE DISK MT6		P						
010	01	90837907		3		1		PC CKT BRKR MAGNETIC 3.0 AMP5		P						
011	01	71492955		1		1		PC PANEL CABLE SUPPORT		P						
012	01	71492966		0		4		PC GUIDE CARD		P						
014	02	71492968		4		1		PC BUTTON SWITCH		P			15012			0321
014	03	61499606		3		1		PC SWITCH BUTTON ASSY		N		15012			0321	
015	01	71493055		9		1		PC PANEL SWITCH 1ND		P						
016	01	51066600		9		1		PC FAN: 50CFM 1PH 115VAC 50/60HZ		P						
017	01	94375401		0		1		PC GUARD, FAN 50/60HZ		P						
018	01	77618000		2		1		PC FLEX DISK DRV, 9406 2-SIDED		V						
019	01	71493350		4		4		PC FOOT		P						
020	01	91976649		3		4		PC MSCR PAN PHL M4X40MM STL ZP		B						

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440					ASSEMBLY PARTS LIST				PRINT DATE		PAGE		FILE CHANGE NO.		
									03-31-83		2		00015812		
DIV.	ASSEMBLY NUMBER	CR	REV	DWG.	DESCRIPTION			MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE	
0860	15632983	I	0	0	FDD: CD110 PRIMARY 60HZ (TA)			0	REL	12-10-81		FA501C		03-31-83	
TP/NO	LI	PART NUMBER	CD	MC	QUANTITY	U/M	PART DESCRIPTION		MC	YLR	DCO. NO. IN	DCO. NO. OUT	S/N	WE IN	WE OUT
021	01	91975724	5		8		PC NUT, HEX M5 STL ZP	B				15786			0320
021	02	15165001	7		8		PC NUT, HEX/FLG-LK M5 STL ZP	B			15786			0320	
022	01	15164911	8		4		PC MSCR HEX/W-LK PLN M4X8MM STL	B							
023	01	15164917	5		4		PC MSCR HEX/W-LK PLN M5X8MM STL	B				15289			0230
023	02	15164917	5		12		PC MSCR HEX/W-LK PLN M5X8MM STL	B			15289			0230	
024	01	91976750	2		5		PC MSCR PAN PHL M5X10MM SST PASS	B				15289			0230
025	01	91976864	8		4		PC MSCR FLT PHL M5X10MM STL ZP	B							
026	01	91976652	7		5		PC MSCR PAN PHL M5X10MM STL ZP	B				15289			0230
026	02	91976652	7		2		PC MSCR PAN PHL M5X10MM STL ZP	B			15289			0230	
027	01	91975706	2		5		PC WSHR, M5 LOCK SST PASS	B				15289			0230
028	01	71493078	1		5		PC STANDOFF HEX METRIC CRS	P							
029	01	51910435	2		1		PC EMBLEM, CDC ID	P							
031	01	93109381	9		2		PC STOFF, NO. 1/4 .025, L RD ZINC	P							
032	01	91975684	1		6		PC WSHR, M5 EXT/T SST PASS	B				15786			0320
032	02	91975671	8		6		PC WSHR, M5 EXT/T SP8-STL ZP	B			15786			0320	
033	01	93522018	6		1		PC PLUG, SNAP BU77DN 1 1/4 DIA MO	P							
034	01	94374900	2		125		PC STRIP CONTACT	P							
035	01	09040204	1		8		PC WSHR, NO. 10 DISHED LOCK STL	B				15786			0320
036	01	51065700	5		4		PC BUMPER SELF STICKING	P				15669			0301
037	01	62044200	4		1		PC CLAMP-CABLE ADHESIVE BACK	B							
038	01	94277400	1		1		PC STRAP, CBL TIE TYP-1 70 5/8	B							
039	01	71493294	4		1		PC SHIELD	P							
040	01	94952302	1		1		PC CLIP CORD TYPE 3 NYLON	P							

BUILD ARC 440

ASSEMBLY PARTS LIST

BUILD ARC 440				ASSEMBLY PARTS LIST				PRINT DATE		PAGE		FILE CHANGE NO			
								03-31-83		3		00015812			
DIV.		ASSEMBLY NUMBER		CD	REV.	QTY.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. DESK.	FILE DATE	
0060		15632983		1	6	D	FDD, CD110 PRIMARY 60HZ (TA)		8	REL	12-10-81		FA501C	03-31-83	
PRINT NO.	LI	PART NUMBER		CD	QTY.	U/M	PART DESCRIPTION		MC	YLB	SCO. NO. IN	SCO. NO. OUT	S/N	WK IN	WK OUT
041	01	10127103		9	4		PC MSCR PAN PHL 4-40X.312 STL ZP		B						
042	01	10126400		0	4		PC MSHR, (4) EXT/T LK STL ZP		B						
043	01	71493269		6	1		PC SHIELD		P						
044	01	71493297		7	4		PC ROD OPTIC		P						
045	01	94050711		6	001		OZ SEAL, EASTMAN CLR (910)		B						
046	01	94277411		8	2		PC STRAP, CBL TIE TYP-1 TO 1-1/8		B						
047	01	71493354		6	1		PC RAIL SUPPORT PC CD		P						
048	01	71493360		3	1		PC GUIDE-PC CONN		P						
049	01	71493364		5	1		PC SCREW SHLDR NYLON		P						
050	01	91976507		3	1		PC MSCR PAN SLT M3X10MM NYL NAT		B						
							0055 TOTAL LINES								

1. <input type="checkbox"/> NO 2. <input type="checkbox"/> YES		3. <input type="checkbox"/> NO 4. <input type="checkbox"/> YES		5. <input type="checkbox"/> NO 6. <input type="checkbox"/> YES		7. <input type="checkbox"/> NO 8. <input type="checkbox"/> YES		9. <input type="checkbox"/> NO 10. <input type="checkbox"/> YES		11. <input type="checkbox"/> NO 12. <input type="checkbox"/> YES		13. <input type="checkbox"/> NO 14. <input type="checkbox"/> YES		15. <input type="checkbox"/> NO 16. <input type="checkbox"/> YES		17. <input type="checkbox"/> NO 18. <input type="checkbox"/> YES		19. <input type="checkbox"/> NO 20. <input type="checkbox"/> YES		21. <input type="checkbox"/> NO 22. <input type="checkbox"/> YES		23. <input type="checkbox"/> NO 24. <input type="checkbox"/> YES		25. <input type="checkbox"/> NO 26. <input type="checkbox"/> YES		27. <input type="checkbox"/> NO 28. <input type="checkbox"/> YES		29. <input type="checkbox"/> NO 30. <input type="checkbox"/> YES		31. <input type="checkbox"/> NO 32. <input type="checkbox"/> YES		33. <input type="checkbox"/> NO 34. <input type="checkbox"/> YES		35. <input type="checkbox"/> NO 36. <input type="checkbox"/> YES		37. <input type="checkbox"/> NO 38. <input type="checkbox"/> YES		39. <input type="checkbox"/> NO 40. <input type="checkbox"/> YES		41. <input type="checkbox"/> NO 42. <input type="checkbox"/> YES		43. <input type="checkbox"/> NO 44. <input type="checkbox"/> YES		45. <input type="checkbox"/> NO 46. <input type="checkbox"/> YES		47. <input type="checkbox"/> NO 48. <input type="checkbox"/> YES		49. <input type="checkbox"/> NO 50. <input type="checkbox"/> YES		51. <input type="checkbox"/> NO 52. <input type="checkbox"/> YES		53. <input type="checkbox"/> NO 54. <input type="checkbox"/> YES		55. <input type="checkbox"/> NO 56. <input type="checkbox"/> YES		57. <input type="checkbox"/> NO 58. <input type="checkbox"/> YES		59. <input type="checkbox"/> NO 60. <input type="checkbox"/> YES		61. <input type="checkbox"/> NO 62. <input type="checkbox"/> YES		63. <input type="checkbox"/> NO 64. <input type="checkbox"/> YES		65. <input type="checkbox"/> NO 66. <input type="checkbox"/> YES		67. <input type="checkbox"/> NO 68. <input type="checkbox"/> YES		69. <input type="checkbox"/> NO 70. <input type="checkbox"/> YES		71. <input type="checkbox"/> NO 72. <input type="checkbox"/> YES		73. <input type="checkbox"/> NO 74. <input type="checkbox"/> YES		75. <input type="checkbox"/> NO 76. <input type="checkbox"/> YES		77. <input type="checkbox"/> NO 78. <input type="checkbox"/> YES		79. <input type="checkbox"/> NO 80. <input type="checkbox"/> YES		81. <input type="checkbox"/> NO 82. <input type="checkbox"/> YES		83. <input type="checkbox"/> NO 84. <input type="checkbox"/> YES		85. <input type="checkbox"/> NO 86. <input type="checkbox"/> YES		87. <input type="checkbox"/> NO 88. <input type="checkbox"/> YES		89. <input type="checkbox"/> NO 90. <input type="checkbox"/> YES		91. <input type="checkbox"/> NO 92. <input type="checkbox"/> YES		93. <input type="checkbox"/> NO 94. <input type="checkbox"/> YES		95. <input type="checkbox"/> NO 96. <input type="checkbox"/> YES		97. <input type="checkbox"/> NO 98. <input type="checkbox"/> YES		99. <input type="checkbox"/> NO 100. <input type="checkbox"/> YES	
---	--	---	--	---	--	---	--	--	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	--	--

AC ENTRY ASSY, FLEX DISK

BUILD ARC 230					ASSEMBLY PARTS LIST					PRINT DATE		PAGE	PLS CHANGE NO.				
					03-02-83					1	88015786						
DIV.	ASSEMBLY NUMBER	CD	REV.	SWG	DESCRIPTION					REV	STATUS	STATUS DATE		ENG. DESP.	FILE DATE		
0860	61409021	5	J	D	AC ENTRY, FLEX DISK 60MHz					A	REL	09-03-80		FA501A	03-02-83		
ITEM NO	LI	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION					REV	PLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
801	01	71492952	8	1		PC BRACKET SWITCH/FILTER/XFORM					P						
802	01	71492953	6	1		PC COVER SWITCH/FILTER					P						
804	01	15164356	6	1		PC FILTER RFI					P						
805	01	15012408	9	2		PC 95M8, SNAP-IN .500 M/H .3810					B						
807	01	44674034	2	1		PC CONN POWER RECEPT					P						
808	01	15164917	5	2		PC HSCR HEX/W-LK PLN M5X8MM STL					B						
809	01	91976625	3	4		PC HSCR PAN PHL M3X8MM STL ZP					B		15509	15509		8243	8243
809	02	91976626	1	4		PC HSCR PAN PHL M3X8MM STL ZP					B					8243	
810	01	51809101	2		020	FT TAPE-WIRE MARKING CHAR 1					B						
811	01	51809103	8		020	FT TAPE-WIRE MARKING CHAR 3					B						
814	01	91975669	2	2		PC WSHR, M3 EXT/T SP8-STL ZP					B		15509	15509		8243	8243
814	02	91975669	2	4		PC WSHR, M3 EXT/T SP8-STL ZP					B					8243	
815	01	44674036	7	3		PC CONN PWR RECPY					P						
816	01	51797218	8	3		PC LUG, 22-18GA 5510 INS-RING					B						
817	01	94277400	1	1		PC STRAP, CBL TIE TYP-1 TO 5/8					B		15351	15351		8234	8234
817	02	94277400	1	3		PC STRAP, CBL TIE TYP-1 TO 5/8					B					8234	
818	01	51906200	4	3		PC CONT, SKT 20-14AWG SN STRIP					P						
819	01	52810001	9	2	833	FT WIR 18GA STRD BRN 600V UL PVC					W						
820	01	52810020	9		833	FT WIR 18GA STRD GRN/YEL 600V UL					W						
821	01	51906001	6	1		PC CONN, PLUG 3 CKT NYL/NAT F-1					P						
824	01	91975724	5	2		PC NUT, HEX M5 STL ZP					B		15786	15786		8320	8320
824	02	15165001	7	2		PC NUT, HEX/FLG-LK M5 STL ZP					B					8320	
825	01	91975671	8	6		PC WSHR, M5 EXT/T SP8-STL ZP					B			15786			8320

BUILD ARC 230					ASSEMBLY PARTS LIST					PRINT DATE		PAGE	PLS CHANGE NO.			
										03-02-83		2	88015786			
DIV	ASSEMBLY NUMBER		CD	REV.	SWG.	DESCRIPTION			REV	STATUS	STATUS DATE		ENG. DESP.	FILE DATE		
0860	61409021		5	J	D	AC ENTRY, FLEX DISK 60HZ			A	REL	09-03-80		FA501A	03-02-83		
ITEM NO	LI	PART NUMBER		CD	QUANTITY	U/M	PART DESCRIPTION			REV	PLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
025	02	91975671	8		3		PC	WSHR, M5 EXT/T 5PG-STL 7P	B		15786				8320	
026	01	61409023	1		REF		PC	W/L AC ENTRY 60HZ	D							
027	01	52810006	8		2	833	FT	WIR 18GA STRD BLU 600V UL PVC	W							
028	01	93083004	7		2		PC	SPLICES 22-16	W							
029	01	62201057	7		REF		PC	SCH DIAG 50/60HZ	D							
030	01	95643231	4		4		PC	LUG, Q-CONN 22-18AWG F18 5	P		15634	15634			8313	8313
030	02	95643248	8		4		PC	CONN QUICK CONN 22-18 1.00L	P							
031	01	51809102	0			020	FT	TAPE-WIRE MARKING CHAR 2	B							
032	01	51809104	6			020	FT	TAPE-WIRE MARKING CHAR 4	B							
033	01	24528636	4			333	FT	TBG, NO. 2 INS BLK UL PVC	B							
0033 TOTAL LINES																

BUILD ARC 230

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
03-01-83	1	00015786

DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION	INC	STATUS	STATUS DATE		ENG. RESP.	FILE DATE	
0060	61409022		3	J	D	AC ENTRY, FLEX DISK 50HZ	A	REL	09-03-80		FA501A	03-01-83	
TP/NO	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	INC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	71492952	0	1		PC BRACKET SWITCH/FILTER/XFORM	P						
002	01	71492953	0	1		PC COVER SWITCH/FILTER	P						
004	01	15164356	6	1		PC FILTER RF1	P						
005	01	15012408	9	3		PC BSMG, SNAP-IN .500 M/H .381D	M						
007	01	44674034	2	1		PC CONN POWER RECEPT	P						
008	01	15164917	5	2		PC MSCR HEX/W-LK PLN MSX8MM STL	B						
009	01	91976625	3	4		PC MSCR PAN PHL M3X6MM STL ZP	B		15509	15509		8243	8243
009	02	91976626	1	4	PC MSCR PAN PHL M3X8MM STL ZP	B							
010	01	51809101	2		020	FT TAPE-WIRE MARKING CHAR 1	B						
011	01	51809103	0		020	FT TAPE-WIRE MARKING CHAR 3	B						
012	01	51918789	2	1		PC XFMR STEP DOWN 220/240V	P						
013	01	09040204	1	4		PC WSHR, NO.10 DISHEO LOCK STL	B			15786		8320	
014	01	91975669	2	2		PC WSHR, M3 EXT/T SP6-STL ZP	B		15509	15509		8243	8243
014	02	91975669	2	4	PC WSHR, M3 EXT/T SP6-STL ZP	B							
015	01	44674036	7	3		PC CONN PWR RECPY	P						
016	01	51797218	0	2		PC LUG, 22-18GA SS10 INS-RING	B						
017	01	94277400	1	1		PC STRAP, CBL TIE TYP-1 TO 5/8	B		14321 15351	14321 15351		8041 8234	8041 8234
017	02	94277400	1	2	PC STRAP, CBL TIE TYP-1 TO 5/8	B							
017	03	94277400	1	4	PC STRAP, CBL TIE TYP-1 TO 5/8	B							
019	01	52810001	9	2		FT WIR 18GA STRO BRN 600V UL PVC	M						
020	01	52810020	9		250	FT WIR 18GA STRO GRN/YEL 600V UL	M						
022	01	51918969	0	1		PC SWITCH VOLTAGE SELECTOR	P						
023	01	51A73600	4		001	OZ VARNISH INSUL RED GLPT	B						

BUILD ARC 230

ASSEMBLY PARTS LIST


PRINT DATE	PAGE	FILE CHANGE NO.
03-01-83	2	00015786

DIV	ASSEMBLY NUMBER			CD	REV.	DWG.	DESCRIPTION		INC	STATUS	STATUS DATE		ENG. RESP.	FILE DATE		
0060	61409022			3	J	D	AC ENTRY, FLEX DISK 50HZ		A	REL	09-03-80		FA501A	03-01-83		
TP/NO	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION			INC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
024	01	91975724		5	6		PC	NUT, HEX M5 STL ZP			B					8320
024	02	15165001		7	6		PC	NUT, HEX/FLG-LK M5 STL ZP			B	15786	15786		8320	
025	01	91975671		8	6		PC	WSHR, M5 EXT/T SPG-STL ZP			B		15786			8320
025	02	91975671		8	4		PC	WSHR, M5 EXT/T SPG-STL ZP			B	15786			8320	
026	01	61409024		9	REF		PC	W/L AC ENTRY 50HZ			D					
027	01	52810006		8	1	166	FT	WIR 18GA STRD BLU 600V UL PVC			M					
028	01	93083004		7	2		PC	SPLICES 22-16			M					
029	01	51758101		3		18B	FT	INS SLV CLR PVC HEAT SHRINK			B					
030	01	95643231		4	4		PC	LUG, 0-CONN 22-18AWG FIG 5			P		15634		8313	8313
030	02	95643248		B	4		PC	CONN QUICK CONN 22-18 1.00L			P					
031	01	62201057		7	REF		PC	SCH DIA6 50/60HZ			D					
032	01	51809102		0		020	FT	TAPE-WIRE MARKING CHAR 2			B					
033	01	51809104		6		020	FT	TAPE-WIRE MARKING CHAR 4			B					
034	01	62044200		4	1		PC	CLAMP-CABLE ADHESIVE BACK			B					
0037 TOTAL LINES																



COMMON PARTS DATA APPLICABLE
TO BOTH PRE-PRODUCTION
AND PRODUCTION UNITS





BUILD ARC 214										PRINT DATE		PAGE	REV CHANGE NO.	
ASSEMBLY PARTS LIST										02-05-81		1	14571	
REV	ASSEMBLY NUMBER	CR	REV	SWP	DESCRIPTION	REV	STATUS	STATUS DATE	ENG. DESP.	REV DATE				
0860	90446260	3	Df	0	PW BO ASSY 98EO REPLACED BY 90446264	S	12-17-80	FA501A	02-05-81					
REV NO.	U	PART NUMBER	CR	QUANTITY	U/M	PART DESCRIPTION	REV	YTD	QTY. NO. IN	QTY. NO. OUT	S/N	REV IN	REV OUT	
001	01	90446259	5	1		PC PW BO 98EO	P							
002	01	15144900	6	6		PC IC 74LS00 140LS QUAD 2-IMP	P							
003	01	15145100	2	6		PC IC 74LS04 146LS 7TL HEX INV	P							
004	01	15145400	6	2		PC IC 74LS08 201LS Q2IMP AND	P							
005	01	15145600	1	2		PC IC 74LS10 141LS 7TL 3I/P NAND	P							
006	01	15148500	0	1		PC IC 74LS14 943LS 7TL 6 ND RCVR	P							
007	01	15145900	5	3		PC IC 74LS20 208LS TTL 4I/P NAND	P							
008	01	15147600	9	4		PC IC 74LS42	P							
009	01	15146300	7	9		PC IC 74LS74 175LS F/F DUAL D	P							
010	01	15146500	2	1		PC IC 74LS112 243LS TTL DUAL F/F	P							
011	01	15146600	0	1		PC IC 74LS139 538LS DECODER 10F4	P							
012	01	15148700	6	2		PC IC 74LS153 7TL DUAL 4I/P	P							
014	01	15146800	6	2		PC IC 74LS161 158LS 4BIT COUNTER	P							
016	01	15147500	1	1		PC IC 74LS174 TTL 6 BIT 16 PIN	P							
017	01	15163414	4	8		PC IC 74LS244 OCTAL BFR 3-S OP	P							
018	01	15163324	5	3		PC IC 74LS245 OCTAL BUS XCEIVER	P							
019	01	15163404	5	5		PC IC 74LS374 OCTAL D-EODE F-F	P							
020	01	15163232	0	1		PC IC 74LS375 TTL 4-81T	P							
021	01	96744155	1	3		PC IC 7406 ORVR HEX INV BUFFER	P							
023	01	88883700	2	2		PC IC 74504 146S TTL HEX INV7R	P							
024	01	88884200	2	2		PC IC 74510 141S 7TL 3 3-1N NANO	P							

BUILD ARC 214

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	REV CHANGE NO.
02-05-81	2	00014314
14571		
STATUS DATE	REV. DESP.	REV DATE
02-17-80	FA501A	02-05-81

REV	ASSEMBLY NUMBER	CR	REV	SWP	DESCRIPTION	REV	STATUS	STATUS DATE	REV. DESP.	REV DATE			
0860	90446260	3	Df	0	PW BO ASSY 98ED	REPLACED BY 90446264	S	02-17-80	FA501A	02-05-81			
REV NO.	U	PART NUMBER	CR	QUANTITY	U/M	PART DESCRIPTION	REV	YTD	QTY. NO. IN	QTY. NO. OUT	S/N	REV IN	REV OUT
025	01	88885300	9	1		PC IC 74520 TTL DUAL 4 1/P	P						
026	01	88923000	9	2		PC IC 74574 7TL DUAL	P						
029	01	15157100	7	1		PC IC LM358N 344 DUAL OP-AMP	P						
030	01	15163444	1	1		PC IC FD1791	P						
031	01	66312068	1	1		PC FLEXIBLE DISK CODED E-ROM	G						
032	01	66312069	9	1		PC FLEXIBLE DISK CODED E-ROM	G						
033	01	15153821	2	8		PC IC 4116 MOS 16384-BIT RAM	P						
034	01	15163201	5	1		PC IC Z80A MOS 8017 MICROPROCESSOR	P						
036	01	15164429	1	1		PC IC Z80A-CTC SILICON GATE NMOS	P						
037	01	51904109	9	1		PC OSCILLATOR TTL D 1 P	P						
038	01	15105700	7	1		PC IC 4024 582 7TL DL/V CONT MVB	P						
039	01	83452230	2	1		PC SW17CM DUAL 8POS .88 FIG 2	P						
041	01	94402116	1	1		PC RES FM 22 OHM 1/4W CARBON	P						
042	01	94402140	1	2		PC RES FM 220 OHM 1/4W CARBON	P						
044	01	94402157	5	1		PC RES FM 1.1K OHM 1/4W CARBON	P						
047	01	94402180	7	2		PC RES FM 10K OHM 1/4W CARBON	P						
048	01	95894500	8	1		PC RES MOD 16 PINS 2B RESISTORS	P						
051	01	51001120	8	62		PC CAP CER F-2 .01UF +80-20P 25V	P						
053	01	24504333	6	6		PC CAP FXD TANT 2.2UF 20P 35VDCW	P						
054	01	24504369	0	7		PC CAP FXD TANT 10UF 20P 15VDCW	P						
055	01	24504373	2	1		PC CAP FXD TANT 47UF 20P 15VDCW	P						

62949100 D

BUILD ARC 214

ASSEMBLY PARTS LIST

BUILD ARC 214										ASSEMBLY PARTS LIST										PRINT DATE 02-05-81		PAGE 3		REV CHANGE NO. 1467	
REV	ASSEMBLY NUMBER		CR	REV	QTY	DESCRIPTION				INC	STATUS	STATUS DATE		DWS. REP.		REV DATE									
0860	90446260		3	DL	0	PW 8D ASSY 98ED				S	REMA	12-17-80		FA501A		02-05-81									
T	REV NO.	U	PART NUMBER		CR	QTY	U/M	PART DESCRIPTION			INC	YLD	SCD. NO. IN	SCD. NO. OUT	S/N	REV IN	REV OUT								
056	01		75887677	5		1		PC	CAP CER 33PF 5P	P															
057	01		19171201	T		4		PC	LIGHT IND	P															
058	01		51007385	1		4		PC	DID IN4148 10MA MICRO SIL 30V	P															
059	01		51714000	0		2		PC	XSTR 2N290T PNP SIL	P															
060	01		51940524	5		1		PC	SWITCH PUSH BUTTON RT ANGLE	P															
061	01		51848404	3		2		PC	SOCKET, IC 24 PDS D-I-L TIN	P															
062	01		51848405	0		2		PC	SOCKET, IC 28 PDS D-I-L TIN	P															
063	01		51848406	0		3		PC	SOCKET, IC 40 PDS D-I-L TIN	P															
065	01		82311900	3		2		PC	INJECTOR-EJECTOR, NATURAL PCB	P															
066	01		93533118	1		2		PC	ROLLPIN, .125D X .250L STL ZP 8	P															
069	01		24584320	3		1		PC	CAP TANT 60CMV 33UF 20P	P															
070	01		94375122	2		4		PC	RES 85IP NTWK 470HM 3P	P															
071	01		94789205	5		1		PC	SWITCH ROTARY PC 10 POS	P															
072	01		15117400	0		2		PC	IC 77L 8MUX 2-1 A 1895 DIC16	P															
073	01		15150400	0		1		PC	IC 93S16 TTL 48IT	P															
074	01		15163459	9		1		PC	IC 9519 INT CONT	P															
075	01		94354826	3	28			PC	CAP FXD CER 0.10UF 50V	P															
077	01		51918283	6		1		PC	DELAY LINE TAP 100 OHM FIG 5	P															
078	01		15140400	1		2		PC	IC DM 809T HEX BUFFER TRI STA	P															
079	01		15147200	0		1		PC	IC 74LS85 COMP TTL 4 8IT	P															
080	01		15145200	0		1		PC	IC 74LS03 202LS TTL 4 2-1 NAND	P															

BUILD ARC 214

ASSEMBLY PARTS LIST

BUILD ARC 214							ASSEMBLY PARTS LIST							PRINT DATE 02-19-81		PAGE 1		REV CHANGED NO. 001131	
REV	ASSEMBLY NUMBER		CR	REV	QTY	DESCRIPTION		INC	STATUS	STATUS DATE		DWS. REP.		REV DATE					
0860	90446260		3	DL	0	PW 8D ASSY 98ED		S	REMA	12-17-80		FA501A		02-05-81					
T	REV NO.	U	PART NUMBER		CR	QTY	U/M	PART DESCRIPTION		INC	YLD	SCD. NO. IN	SCD. NO. OUT	S/N	REV IN	REV OUT			
081	01		51848401	9		32		PC SOCKET, IC 16 PDS D-I-L TIN		P									
082	01		T5738666	9		2		PC RES PAK 10.0K OHM 1.50W FIG 2		P									
083	01		94402141	9		1		PC RES FM 240 OHM 1/4W CARBON		P									
085	01		15163458	1		1		PC IC 9517A MULTIMODE DMA CONT		P									
086	01		15145000	4		2		PC IC 74LS02 14BLS 921NP NOR		P									
087	01		15158700	3		1		PC IC 774S140 77L OVAL 4 I/P GA7		P									
088	01		88884500	5		1		PC IC 74S00 1405 TTL 6D 2IN NAND		P									
090	01		94402156	T		8		PC RES FM 1K OHM 1/4W CARBON		P									
091	01		51903400	3		2		PC PIN, .025 IN SQ PC MTG 2A		P									
092	01		77612624	5		1		PC CONNECTOR, JUMPER		P									
093	01		51918281	0		1		PC DELAY LINE TAP 200 OHM FIG 3		P									
094	01		90446122	5	REF			PC SCH DIAG 98ED		D									
094	02		90446258	7	REF			PC SCH DIAG 98ED		D		14469	14469		8103	8103			
095	01		16033200	3	REF			PC FABRICATION SPEC 70 PAK		D									
096	01		15163434	2		1		PC IC 74LS373 DCTAL 0 LATCH		P									
097	01		94402168	2		1		PC RES FM 3.3K OHM 1/4W CARBON		P									
102	01		94227221	9		1		PC CAP 110 PF DIPPED MICA		P									
103	01		15158600	5		2		PC IC 74S112 TTL DUAL J-K NET		P									
104	01		50254300	2		1		PC IC 74123 193 TTL 2 RE7GR MVB		P									
105	01		66299099	3		1		PC IC 7400 TTL QUAD 2-IN NAND		P									
106	01		51908710	0		1		PC RES CERM VAR 20K OHM 10P 3/4W		P									



190446284

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75


76

77

78

79

80



CROSS REFERENCE TABLE	
TYPE NUMBER	REFERENCE DESIGNATION
37	OSC
38	32
39	31
40	30
41	29
42	28
43	27
44	26
45	25
46	24
47	23
48	22
49	21
50	20
51	19
52	18
53	17
54	16
55	15
56	14
57	13
58	12
59	11
60	10
61	9
62	8
63	7
64	6
65	5
66	4
67	3
68	2
69	1
70	0
71	-1
72	-2
73	-3
74	-4
75	-5
76	-6
77	-7
78	-8
79	-9
80	-10
81	-11
82	-12
83	-13
84	-14
85	-15
86	-16
87	-17
88	-18
89	-19
90	-20
91	-21
92	-22
93	-23
94	-24
95	-25
96	-26
97	-27
98	-28
99	-29
100	-30
101	-31
102	-32
103	-33
104	-34
105	-35
106	-36
107	-37
108	-38
109	-39
110	-40
111	-41
112	-42
113	-43
114	-44
115	-45
116	-46
117	-47
118	-48
119	-49
120	-50
121	-51
122	-52
123	-53
124	-54
125	-55
126	-56
127	-57
128	-58
129	-59
130	-60
131	-61
132	-62

- NOTES:
- △ MARK ASSY NO. AND REV LEVEL. 12 HIGH. WHITE IN AREA SHOWN PER CDC SPEC 1071508.
 - △ MARK SERIAL NUMBER IN AREA SHOWN PER RYLOPS PGP NO. 80120134 AND PER MARKING REQUIREMENTS IN NOTE (1) ONE.
 - 3. FIND NUMBERS ELEMENT IDENTIFIERS AND REFERENCE DESIGNATIONS ARE FOR REFERENCE ONLY AND DO NOT APPEAR ON PART.
 - 4. AFTER ALIGNING R33, R34 AND R38, SEAL THEM WITH GLYPHIC CDC PIN 51873400.
 - △ SOLDER 226A. BUSS WIRE (FIN 136) IN THIS CONFIGURATION.

CHANGE TABLE	
DELETIONS	ADDITIONS
CUT FOIL:	ADD WIRE SOURCE SIDE
1143 B-4	11441 TO 134-13
2184 B-4	21841 TO 240-A
3183 B-1	31831 TO 371-5
4183 A-4	41831 TO 471-5
	5187 TO 521-5
	6187 TO 621-5
	7187 TO 721-5
	8187 TO 821-5
	9187 TO 921-5
	10187 TO 1021-5
	11187 TO 1121-5
	12187 TO 1221-5
	13187 TO 1321-5
	14187 TO 1421-5
	15187 TO 1521-5
	16187 TO 1621-5
	17187 TO 1721-5
	18187 TO 1821-5
	19187 TO 1921-5
	20187 TO 2021-5
	21187 TO 2121-5
	22187 TO 2221-5
	23187 TO 2321-5
	24187 TO 2421-5
	25187 TO 2521-5
	26187 TO 2621-5
	27187 TO 2721-5
	28187 TO 2821-5
	29187 TO 2921-5
	30187 TO 3021-5
	31187 TO 3121-5
	32187 TO 3221-5
	33187 TO 3321-5
	34187 TO 3421-5
	35187 TO 3521-5
	36187 TO 3621-5
	37187 TO 3721-5
	38187 TO 3821-5
	39187 TO 3921-5
	40187 TO 4021-5
	41187 TO 4121-5
	42187 TO 4221-5
	43187 TO 4321-5
	44187 TO 4421-5
	45187 TO 4521-5
	46187 TO 4621-5
	47187 TO 4721-5
	48187 TO 4821-5
	49187 TO 4921-5
	50187 TO 5021-5
	51187 TO 5121-5
	52187 TO 5221-5
	53187 TO 5321-5
	54187 TO 5421-5
	55187 TO 5521-5
	56187 TO 5621-5
	57187 TO 5721-5
	58187 TO 5821-5
	59187 TO 5921-5
	60187 TO 6021-5
	61187 TO 6121-5
	62187 TO 6221-5
	63187 TO 6321-5
	64187 TO 6421-5
	65187 TO 6521-5
	66187 TO 6621-5
	67187 TO 6721-5
	68187 TO 6821-5
	69187 TO 6921-5
	70187 TO 7021-5
	71187 TO 7121-5
	72187 TO 7221-5
	73187 TO 7321-5
	74187 TO 7421-5
	75187 TO 7521-5
	76187 TO 7621-5
	77187 TO 7721-5
	78187 TO 7821-5
	79187 TO 7921-5
	80187 TO 8021-5
	81187 TO 8121-5
	82187 TO 8221-5
	83187 TO 8321-5
	84187 TO 8421-5
	85187 TO 8521-5
	86187 TO 8621-5
	87187 TO 8721-5
	88187 TO 8821-5
	89187 TO 8921-5
	90187 TO 9021-5
	91187 TO 9121-5
	92187 TO 9221-5
	93187 TO 9321-5
	94187 TO 9421-5
	95187 TO 9521-5
	96187 TO 9621-5
	97187 TO 9721-5
	98187 TO 9821-5
	99187 TO 9921-5
	100187 TO 10021-5

INACTIVE

PC CARD ASSEMBLY, 9BED (DISK CONTROLLER)	
DATE	15920
REV	D
QTY	90446284
REV	2/1
REV	1

APL90446284	ATTACHED LISTS	DO NOT SCALE DRAWING	DATE	15920	REV	D	QTY	90446284
APL90446284	ATTACHED LISTS	DO NOT SCALE DRAWING	DATE	15920	REV	D	QTY	90446284

BUILD ARC 214						ASSEMBLY PARTS LIST						PRINT DATE		PAGE 1		FILE CHANGE NO	
						03-09-83		1		00015771							
DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION				MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE	
0060	90446284		3	F	D	REPLACED BY 90446570 15771				N	INA	03-04-83		FA501A		03-09-83	
TRND NO	LI	PART NUMBER		CD	QUANTITY	U/M	PART DESCRIPTION				MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	90446259		5	1		PC PW RD 98ED				P						
002	01	15144900		6	6		PC 1C 74LS00 140LS TTL 4 2IN NND				P						
003	01	15145100		2	6		PC 1C 74LS04 146LS TTL HEX INVTR				P						
004	01	15145400		6	2		PC 1C 74LS08 201LS TTL 4 2IN AND				P						
005	01	15145600		1	2		PC 1C 74LS10 141LS TTL 3 3IN NND				P						
006	01	15148500		0	1		PC 1C 74LS14 943LS TTL HEX NAND				P						
007	01	15145900		5	3		PC 1C 74LS20 208LS TTL 2 4IN NND				P						
008	01	15147600		9	4		PC 1C TYPE 74LS42				P						
009	01	15146300		7	8		PC 1C 74LS74 175LS TTL 2 D F/F				P						
010	01	15146500		2	1		PC 1C 74LS112 243LS TTL DUAL F/F				P						
011	01	15146600		0	1		PC 1C 74LS139 538LS DECODER 10F4				P						
012	01	15148700		6	2		PC 1C 74LS153 TTL DUAL 41/P				P						
014	01	15146800		6	2		PC 1C 74LS161 158LS TTL 4B CNTR				P						
016	01	15147500		1	1		PC 1C 74LS174 519LS TTL 6B LATCH				P						
016	02	95965100		1	1		PC 1C 74LS174 6BIT LATCH				P		15675	15675		8325	8325
017	01	15163414		4	8		PC 1C 74LS244 TTL 8 3-STATE DRVH				P						
018	01	15163324		5	3		PC 1C 74LS245 TTL 8 BUS XCEIVER				P						
019	01	15163404		5	5		PC 1C 74LS374 TTL 8 D FLIP/FLOP				P						
020	01	15163232		0	1		PC 1C 74LS375 TTL 4-BIT				P						
021	01	96744155		1	3		PC 1C 7406 DRVH HEX INV BUFFER				P						
023	01	88883700		2	2		PC 1C 74S04 146S TTL HEX INVTR				P						

BUILD ARC 214						ASSEMBLY PARTS LIST						PRINT DATE		PAGE	FILE CHANGE NO.		
						03-09-83		2	00015771								
DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION				MC	STATUS	STATUS DATE		ENG RESP.		FILE DATE	
0060	90446284		3	F	D	REPLACED BY 90446570 15771				N	INA	03-04-83		FA501A		03-09-83	
TRND NO	LI	PART NUMBER		CD	QUANTITY	U/M	PART DESCRIPTION				MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
024	01	88884200		2	2		PC 1C 74S10 141S TTL 3 3-IN NAND				P						
025	01	88885300		9	1		PC 1C 74S20 208S TTL 2 4-IN NAND				P						
026	01	88923000		9	2		PC 1C 74S74 175S TTL 2 D-TYP F-F				P						
029	01	15157100		7	1		PC 1C LM358N 344 DUAL OP-AMP				P						
030	01	15163444		1	1		PC 1C FD1791				P						
031	01	66312070		7	1		PC FLEX DISK CODED E-ROM				G						
032	01	66312071		5	1		PC FLEX DISK CODED E-ROM				G						
033	01	15153021		2	8		PC 1C 4116 MOS 16384-BIT RAM				P						
034	01	15163201		5	1		PC 1C 780A MOS 8BIT PROCESSOR				P						
036	01	15164429		1	1		PC 1C 280A-CTC SILICON GATE NMOS				P						
037	01	51904109		9	1		PC OSC, TTL DIP 16.000MHZ 500MW				P						
038	01	15105700		7	1		PC 1C 4024 58P TTL DL/V COUNT MVB				P						
039	01	83452230		2	1		PC SWITCH DUAL 8PDS .88 F10 2				P						
041	01	94402116		1	1		PC RES FXD C FM 22 OHM 5P 1/4W				P						
042	01	94402140		1	2		PC RES FXD C FM 220 OHM 5P 1/4W				P						
044	01	94402157		5	1		PC RES FXD C FM 1.1K OHM 5P 1/4W				P						
047	01	94402180		7	2		PC RES FXD C FM 10K OHM 5P 1/4W				P						
048	01	95894500		8	1		PC RES MOD 16 PINS 2R RESISTORS				P						
051	02	19115400		4	62		PC CAP FXD CEP .01UF +80-20P 50V				P		14856			8148	
053	01	24504333		5	6		PC CAP FXD TANT 2.2UF 20P 35VDCW				P						
054	01	24504369		0	7		PC CAP FXD TANT 10UF 20P 15VDCW				P						

BUILD ARC 214										PRINT DATE		PAGE	FILE CHANGE NO.	
ASSEMBLY PARTS LIST										03-09-83		3	00015771	
DIV	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION		MC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE			
0860	90446284	3	E	0	REPLACED BY 90446570 15771		N	INA	03-04-83	FA501A	03-09-83			
ITEM NO.	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	MC	TLB	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT	
055	01	24504373	2	1		PC CAP FXD TANT 47UF 20P 15VDCM	P							
056	01	75007677	5	1		PC CAP CER 33PF 5P	P							
057	01	19171201	7	4		PC LIGHT IND	P							
058	01	51007385	1	4		PC D1D 1N4148 S1L MICRO 30V 10MA	P							
059	01	51714000	0	2		PC XSTR: 2N2907 B1-POLAR PNP 51	P							
060	01	51940524	5	1		PC SWITCH PUSH BUTTON RT ANGLE	P							
061	01	51048404	3	2		PC SOCKET: 1C 24-POS D1L F-1 5N	P							
062	01	51848405	0	2		PC SOCKET: 1C 28-POS D1L F-1 5N	P							
063	01	51848406	8	3		PC SOCKET: 1C 40-POS D1L F-1 5N	P							
065	01	82311900	3	2		PC INJECTOR-EJECTOR: NATURAL PCB	P							
066	01	93533118	1	2		PC ROLL PIN: .125D X .250L STL ZP B	P							
069	01	24504320	3	1		PC CAP FXD TANT 33UF 20P 6VDCM	P							
070	01	94375122	2	4		PC RES 851P NTKW 470HM 3P	P							
072	01	15117400	0	2		PC 1C TTL 8MUX 2-1 A 1895 DIC16	P							
073	01	15150400	8	1		PC 1C 93516 TTL 4BIT	P							
074	01	15163459	9	1		PC 1C 9519 INT CONT	P							
075	01	94354026	3	28		PC CAP FXD CEP 0.10UF 50V	P							
077	01	51918203	6	1		PC DELAY LINE TAP 100 OHM F18 5	P							
078	01	15140400	1	2		PC 1C DM 8097 HEX BUFFER TR1 STA	P							
079	01	15147200	8	1		PC 1C 74LS85 COMP TTL 4 BIT	P							
080	01	15145200	0	1		PC 1C 74LS03 202LS TTL 4 2-T NAND	P							

BUILD ARC 214						ASSEMBLY PARTS LIST			PRINT DATE		PAGE	FILE CHANGE NO.			
						03-09-83		4		00015771					
DIV.	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. DESP.	FILE DATE		
0860	90446284		3	E	D	REPLACED BY 90446570 15771		N	INA	03-04-83		FA501A	03-09-83		
ITEM NO	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION		MC	TLB	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
081	01	51848401		9	32		PC SOCKET: 1C 16-POS D1L F-1 5N		P						
082	01	75738666		9	2		PC RES 16PIN DIP 10K R 2P 1.5W 2		P						
083	01	94402141		9	1		PC RES FXD C FM 240 OHM 5P 1/4W		P						
085	01	15163458		1	1		PC IC 9517A MULTIMODE DMA CONT		P						
086	01	15145000		4	2		PC 1C 74LS02 148LS TTL 4 21N NOR		P						
087	01	15158700		3	1		PC 1C 745140 TTL 2 41N NAND BFR		P						
088	01	88884500		5	1		PC 1C 74500 1405 TTL 4 2-1N NAND		P						
090	01	94402156		7	8		PC RES FXD C FM 1.0K OHM 5P 1/4W		P						
091	01	51903400		3	2		PC PIN, .025 IN 50 PC MTG 2A		P						
092	01	77612624		5	1		PC CONNECTOR, JUMPER		P						
093	01	51918201		0	1		PC DELAY LINE TAP 200 OHM FIG 3		P						
094	01	90446258		1	REF		PC SCH DIAG 9RED		U						
095	01	16033200		3	REF		PC FAB SPEC, MULTI-LAYER PWR		U						
096	01	15163434		2	1		PC 1C 74LS373 8 D XPARENT LATCH		P						
097	01	94402168		2	1		PC RES FXD C FM 3.3K OHM 5P 1/4W		P						
102	01	94227227		9	1		PC CAP 110 PF DIPPED MICA		P						
103	01	15158600		5	2		PC 1C 745112 243S TTL 2 J-K F/F		P						
104	01	50254300		2	1		PC 1C 74123 193 TTL 2 RETGR MVB		P						
105	01	66299099		3	1		PC 1C 7400 TTL QUAD 2-1N NAND		P						
106	01	51908710		0	1		PC RES CERM VAR 20K OHM 10P 3/4W		P						
107	01	51908709		2	1		PC RES VAR 10K OHM		P						

BUILD ARC 214

ASSEMBLY PARTS LIST

PRINT DATE
02-28-83PAGE
1FILE CHANGE NO.
15152-44

DIV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE			
0860	90446570	S	A	D	CD ASSY 98ED-3	N	REL	02-22-83	FA501A	02-28-83			
TRND NO.	LT	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION	MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	90446259	5	1		PC PW BD 98ED	P						
002	01	15144900	6	6		PC 1C 74LS00 140LS TTL 4 21N NMD	P						
003	01	15145100	2	6		PC 1C 74LS04 146LS TTL HEX INVTR	P						
004	01	15145400	6	2		PC 1C 74LS08 201LS TTL 4 21N AND	P						
005	01	15145600	1	2		PC 1C 74LS10 141LS TTL 3 31N NMD	P						
006	01	15148500	0	1		PC 1C 74LS14 043LS TTL HEX NAND	P						
007	01	15145900	5	3		PC 1C 74LS20 208LS TTL 2 41N NMD	P						
008	01	15147600	9	4		PC 1C 74LS42	P						
009	01	15146300	7	8		PC 1C 74LS74 175LS TTL 2 D F/F	P						
010	01	15146500	2	1		PC 1C 74LS112 243LS TTL DUAL F/F	P						
011	01	15146600	0	1		PC 1C 74LS139 538LS DECODER 10F4	P						
012	01	15148700	6	2		PC 1C 74LS153 TTL DUAL 41/P	P						
014	01	15146800	6	2		PC 1C 74LS161 150LS TTL 48 CNTR	P						
016	01	95965100	1	1		PC 1C 74LS174 681T LATCH	P						
017	01	15163414	4	8		PC 1C 74LS244 TTL 8 3-STATE DRVR	P						
018	01	15163324	3	3		PC 1C 74LS245 TTL 8 BUS XCEIVER	P						
019	01	15163404	5	5		PC 1C 74LS374 TTL 8 D FLIP/FLOP	P						
020	01	15163232	0	1		PC 1C 74LS375 TTL 4-BIT	P						
021	01	96744155	1	3		PC 1C 7406 DRVR HEX INV BUFFER	P						
023	01	88883700	2	2		PC 1C 74504 146S TTL HEX INVTR	P						
024	01	88884200	2	2		PC 1C 74510 141S TTL 3 3-1N NAND	P						

BUILD ARC 214

ASSEMBLY PARTS LIST

PRINT DATE
02-28-83PAGE
2FILE CHANGE NO.
15152-44

DIV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. REF.	FILE DATE			
0860	90446570	S	A	D	CD ASSY 98ED-3	N	REL	02-22-83	FA501A	02-28-83			
TRND NO.	LT	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION	MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
025	01	88885300	9	1		PC 1C 74S20 208S TTL 2 4-1N NAND	P						
026	01	88923000	9	2		PC 1C 74S74 175S TTL 2 D-7YP F-F	P						
029	01	15137100	7	1		PC 1C LM358N 344 DUAL DP-AMP	P						
030	01	15163444	1	1		PC 1C FD1791	P						
031	01	66312070	7	1		PC FLEX DISK CODED E-ROM	G						
032	01	66312071	5	1		PC FLEX DISK CODED E-ROM	G						
033	01	15153821	2	8		PC 1C 4116 MDS 16384-BIT RAM	P						
034	01	15163201	3	1		PC 1C Z80A MDS 881T MICROPROCESSOR	P						
036	01	15164429	1	1		PC 1C Z80A-CTC SILICON GATE NMOS	P						
037	01	51904109	9	1		PC OSC. TTL DIP 16.000MHZ 500MW	P						
038	01	15105700	7	1		PC 1C 4024 S02 TTL DL/V CONT MVB	P						
039	01	83482230	2	1		PC SWITCH DUAL 8PDS .08 F18 2	P						
041	01	94402116	1	1		PC RES FXD C FM 22 OHM 5P 1/4W	P						
042	01	94402140	1	2		PC RES FXD C FM 220 OHM 5P 1/4W	P						
044	01	94402157	5	1		PC RES FXD C FM 1.1K OHM 5P 1/4W	P						
047	01	94402180	7	2		PC RES FXD C FM 10K OHM 5P 1/4W	P						
048	01	95894500	8	1		PC RES MOD 16 PINS 20 RESISTORS	P						
051	01	19113400	4	62		PC CAP FXD CER .01UF +80-20P 50V	P						
053	01	24504333	6	6		PC CAP FXD TANT 2.2UF 20P 35VDCW	P						
054	01	24584369	0	7		PC CAP FXD TANT 10UF 20P 15VDCW	P						
055	01	24504373	2	1		PC CAP FXD TANT 47UF 20P 15VDCW	P						

BUILD ARC 214

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
02-22-83	3	15152-44

REV.	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	QC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE			
0068	90446570	S	A	D	CD ASSY 98ED-3	N	REL	02-22-83	FA501A	02-20-83			
PART NO.	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	QC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
056	01	75887677	5	1		PC CAP CER 33PF 5P	P						
057	01	19171201	7	4		PC LIGHT IND	P						
058	01	51087305	1	4		PC DIO IN4148 SIL MICRO 30V 10MA	P						
059	01	51714000	0	2		PC XSTR, 2W2987 81-POLAR PNP SI	P						
060	01	51940524	5	1		PC SWITCH PUSH BUTTON R7 ANGLE	P						
061	01	51848404	3	2		PC SOCKET, 1C 24-POS DIL F-1 SN	P						
062	01	51848405	0	2		PC SOCKET, 1C 28-POS DIL F-1 SN	P						
063	01	51848406	8	3		PC SOCKET, 1C 40-POS DIL F-1 SN	P						
065	01	82311900	3	2		PC INJECTOR-EJECTOR, NATURAL PC8	P						
066	01	93533116	1	2		PC ROLL PIN, .1250 X .250L STL ZP B	P						
069	01	24594320	3	1		PC CAP FXD 7ANT 33UF 20P 6VDCW	P						
070	01	94375122	2	4		PC RES 851P NTKW 470HM 3P	P						
072	01	15117400	0	2		PC IC TTL 8MUX 2-1 A 1895 DIC16	P						
073	01	15150406	8	1		PC IC 93516 TTL 481T	P						
074	01	15163459	9	1		PC IC 9519 1N7 CONT	P						
075	01	94354826	3	28		PC CAP FXD CER 0.10UF 50V	P						
077	01	51918283	6	1		PC DELAY LINE TAP 100 OHM F18 5	P						
078	01	15140400	1	2		PC IC OM 8097 HEX BUFFER TR1 STA	P						
079	01	15147200	8	1		PC IC 74LS85 COMP TTL 4 81T	P						
080	01	15145200	0	1		PC IC 74LS03 202LS TTL 4 2-1 NAND	P						
081	01	51848401	9	32		PC SOCKET, 1C 16-POS DIL F-1 SN	P						

BUILD ARC 214

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
02-28-83	4	15152-44

REV.	ASSEMBLY NUMBER	CD	REV.	DWG	DESCRIPTION	QC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE				
0860	90446570	S	A	D	CD ASSY 98ED-3	N	REL	02-22-83	FA501A	02-20-83				
1	PIND NO.	LI	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION	QC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
	082	01	75738666	9	2		PC RES 16PIN 01P 10K R 2P 1.5W 2	P						
	083	01	94402141	9	1		PC RES FXD C FM 240 OHM 5P 1/4W	P						
	085	01	15163458	1	1		PC IC 9517A MULTIMODE DMA CONT	P						
	086	01	15145000	4	2		PC IC 74LS02 148L5 TTL 4 2IN NOR	P						
	087	01	15158700	3	1		PC IC 745140 77L 2 4IN NAND BFR	P						
	088	01	88884500	5	1		PC IC 74500 1405 TTL 4 2-1N NAND	P						
	090	01	94402156	7	8		PC RES FXD C FM 1.0K OHM 5P 1/4W	P						
	091	01	51903400	3	2		PC PIN, .025 1N SQ PC N78 2A	P						
	092	01	77612624	5	1		PC CONNECTOR, JUMPER	P						
	093	01	51918281	0	1		PC DELAY LINE TAP 200 OHM F18 3	P						
	094	01	90446258	7	REF		PC SCH DIA8 98ED	D						
	095	01	16033200	3	REF		PC FAB SPEC, MULTI-LAYER PWB	D						
	096	01	15163434	2	1		PC IC 74LS373 8 D XPARENT LATCH	P						
	097	01	94402168	2	1		PC RES FXD C FM 3.3K OHM 5P 1/4W	P						
	102	01	94227227	9	1		PC CAP 110 PF DIPPED MICA	P						
	103	01	15158600	5	2		PC IC 745112 2435 TTL 2 J-K F/F	P						
	104	01	50254300	2	1		PC IC 74123 193 TTL 2 RETOR NVB	P						
	105	01	66299099	3	1		PC IC 7400 TTL QUAD 2-1N NAND	P						
	106	01	51908710	0	1		PC RES CERM VAR 20K OHM 10P 3/4W	P						
	107	01	51908709	2	1		PC RES VAR 10K OHM	P						
	108	01	51908708	4	1		PC RES CER VAR 5K OHM 10P 3/4W	P						

BUILD ARC 214

ASSEMBLY PARTS LIST

BUILD ARC 214										ASSEMBLY PARTS LIST										PRINT DATE		PAGE		FILE CHANGE NO	
																				02-28-83		5		15152-44	
DIV		ASSEMBLY NUMBER		CD	REV	DWG	DESCRIPTION				MC	STATUS	STATUS DATE		ENCL. RESP.		FILE DATE								
0800		90446570		5	A	D	CD ASSY 98ED-3				N	REL	02-28-83		FAS01A		02-28-83								
ITEM NO	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION				MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT								
110	01	51003092	7	1			PC	XSTR. 2N2222 HI-SPEED NPN SI				P													
111	01	94360304	3	2			PC	RES FXD FM 1100 OHM 1P 1/4W				P													
112	01	94360352	2	2			PC	RES FXD FM 3480 OHM 1P 1/4W				P													
113	01	94402173	2	2			PC	RES FXD C FM 5.1K OHM 5P 1/4W				P													
114	01	94402164	1	2			PC	RES FXD C FM 2.2K OHM 5P 1/4W				P													
115	01	94360400	9	2			PC	RES FXD FM 10.0K OHM 1P 1/4W				P													
116	01	94402166	6	2			PC	RES FXD C FM 2.7K OHM 5P 1/4W				P													
117	01	94402158	3	1			PC	RES FXD C FM 1.2K OHM 5P 1/4W				P													
118	01	94402154	2	1			PC	RES FXD C FM 820 OHM 5P 1/4W				P													
119	01	94402139	3	1			PC	RES FXD C FM 200 OHM 5P 1/4W				P													
120	01	94402161	7	1			PC	RES FXD C FM 1.6K OHM 5P 1/4W				P													
121	01	24500144	1	1			PC	RES FXD COMP 160 OHM 5P 1/2W				P													
122	01	94842154	0	1			PC	CAP FXD CER .001UF 10P 1000V				P													
124	01	15101109	5	1			PC	D10 1N752A 400MW ZEN VR 5.6V				P													
125	01	94227253	5	2			PC	CAP 1300 PF DIPPED MICA				P													
126	01	94354824	8	2			PC	CAP CER 0.047 UF TYPE 1 20P				P													
127	01	94240423	7	1			PC	CAP FXD CEP 150PF 10P 50VDCW				P													
129	01	94240421	1	1			PC	CAP FXD CER 52PF 10P 50VDCW				P													
130	01	94356324	7	2			PC	INDUCTOR 10 MH				P													
131	01	94402148	4	2			PC	RES FXD C FM 470 OHM 5P 1/4W				P													
132	01	15101108	7	1			PC	D10 1N751A 400MW ZEN VR 5.1V				P													

BUILD ARC 214

ASSEMBLY PARTS LIST

BUILD ARC 214						ASSEMBLY PARTS LIST				PRINT DATE 02-28-83		PAGE 6		FILE CHANGE NO 15152-44			
DIV		ASSEMBLY NUMBER		CD	REV	DWG	DESCRIPTION			MC	STATUS	STATUS DATE		ENG DESP		FILE DATE	
0860		90446570		5	A	D	CD ASSY 9BED-3			N	REL	02-22-83		FA501A		02-28-83	
TRND NO	LI	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION			MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT	
133	01	51R50400		6	1	83	FT	CABLE RAD/FREQ 26GA STRD RG			W						
135	01	51873600		4		015	OZ	VARNISH INSUL RED GLPT			B						
136	01	24501801		5		333	FT	WIRE+ BUSS 22AWG SOLID CU/SN			W						
								010R TOTAL LINES									


OWN	W. Glaser	11/81	CONTROL DATA	TITLE	CARD ASSEMBLY 9BED CONT MODULE W/FULL MEMORY	PREFIX	DOCUMENT NO.	REV.
CHKD	P. S. S.	11/81				A	90446396	C
ENG	N. S. S.	12-81						
MFG	P. S. S.	12-81						
APPR	P. S. S.	12-81						
EC	P. S. S.	12-81						
			CODE IDENT	FIRST USED ON	NHA			
			15920	FA501C/D	15632982 15632983	SHEET 1 OF 2		

SHEET REVISION STATUS										REVISION RECORD						
										REV	ECO	DESCRIPTION	DRFT	DATE	APP	
										A	A	13920-68	RELEASED CLASS A		12-81	MS
										B	B	15229	REVISED PER ECO	EE	1/1/82	MS
										C	C	15771	INACTIVE, RECAL BY 11/11/81	EE	1/1/82	MS
										INACTIVE						

NOTES:

- 1 Mark "Assy 90446396" in area shown per CDC SPEC 10121508.
- 2 Mount F/N 2 in sockets located at A1-A6, C1-C6, and D1-D6 on F/N 1.

APL	90446396
DETACHED LISTS	



BUILD ARC 214


ASSEMBLY PARTS LIST

BUILD ARC 214						ASSEMBLY PARTS LIST				PRINT DATE		PAGE	PRE CHANGE NO.		
						03-09-83		1		00015771					
DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE	
0060	90446396		5	C	A	REPLACED BY 90446571 15771		S	INA	13-04-83		FA501C/D		03-09-83	
TRND NO	LI	PART NUMBER		CE	QUANTITY	U/M	PART DESCRIPTION		MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	90446284		3	1		PC	REPLACED BY 90446570 15771	N						
002	01	15153821		2	24		PC	IC 4116 MOS 16384-BIT RAM	P						
003	01	10121508		5	REF		PC	MARKING* INK STP-STENCIL-S/C	U						
0003 TOTAL LINES															

BUILD ARC 214

ASSEMBLY PARTS LIST

BUILD ARC 214						ASSEMBLY PARTS LIST			PRINT DATE 02-28-83		PAGE 1	FILE CHANGE NO 13152-45			
DIV.	ASSEMBLY NUMBER		CD	REV.	QTY.	DESCRIPTION		MC	STATUS	STATUS DATE		END DESP.		FILE DATE	
0060	90448571		3	A	A	CD ASSY CONT MOD W/FULL MEM		S	REL	02-22-83		FA501C/D		02-28-83	
ITEM NO.	LI	PART NUMBER		CB	QUANTITY	U/M	PART DESCRIPTION		MC	TLB	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	90448570		5	1		PC	CD ASSY 9BED-3		N					
002	01	15153821		2	24		PC	IC 4116 MOS 16384-BIT RAM		P					
0002 TOTAL LINES															



B11LD ARC 210

ASSEMBLY PARTS LIST

PRINT DATE

PAGE

FILE CHANGE NO

10-01-81

1

00014838

BUILD ARC 210

ASSEMBLY PARTS LIST

DIV	ASSEMBLY NUMBER	CD	REV.	DWG.	DESCRIPTION	MC	STATUS	STATUS DATE	ENG. DESP.	FILE DATE			
0860	90446140	7	E	D	REPLACED BY 90446290 14838	A	INA	09-23-81	FA501A/B	10-01-81			
PART NO.	U	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION	MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	90446139	9	1		PC PW BD 98K0 PWR 5PLY	P						
002	01	51940599	T	1		PC TRANSFORMER FLYBACK 25KHZ	P						
003	01	51940598	9	1		PC TRANSFORMER FLYBACK 25KHZ	P						
004	01	51918111	9	2		PC XSTR NPN 400V BA TO 220	P						
005	01	51681100	T	2		PC XSTR 2N5189 NPN SIL	P						
006	01	51603092	T	5		PC XSTR 2N2222 HI SPEED NPN SIL	P						
007	01	51714000	C	1		PC XSTR 2N2907 PNP SIL	P						
008	01	95637304	7	14		PC OIO IN4004 400PIV SIL 1.1V/1A	P						
009	01	95691500	J	6		PC RECT, 1N5615 F-R SIL 1 AMP	P						
010	01	77835261	7	2		PC POWER OIODE FAST RECOVER	P						
011	01	19171261	7	4		PC LIGHT IND	P						
012	01	15101110	3	2		PC OIO 1N753A 400MW ZEN VR 6.2V	P						
013	01	15165538	8	4		PC ISOLATOR OPTICALLY COUPLED	P						
014	01	51718400	8	2		PC IC T23C 334 VOLTAGE REGULATOR	P						
015	01	51907385	1	1		PC OIO 1N4148 10MA MICRO SIL 30V	P						
016	01	15163403	7	1		PC IC LM317 ADJ +V RGLTR TO-220	P						
017	01	15151400	T	1		PC IC UA7900-5 356A NEG V RGLTR	P						
018	01	51918616	T	4		PC INDUCTOR	P						
019	01	51918617	5	1		PC INDUCTOR	P						
020	01	51918627	4	2		PC CAP ALUM ELECT 300UF 250V 1SP	P						
021	01	24504816	8	2		PC CAP FXO MYL .33UF 10P 100VDCW	P						

B11LD ARC 210

ASSEMBLY PARTS LIST

811LO ARC 210					ASSEMBLY PARTS LIST			PRINT DATE		PAGE		FILE CHANGE NO.		
								10-01-81		2		00014838		
DIV	ASSEMBLY NUMBER		CD	REV	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. DESP.		FILE DATE
0860	90446140		T	E	0	REPLACED BY 90446290 14838		A	INA	09-23-81		FA501A/B		10-01-81
PART NO.	U	PART NUMBER	CD	QTY	U/M	PART DESCRIPTION		MC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
022	01	36180753	0	2		PC	CAP FXD MYL .001MFO 600V	P						
023	01	51839147	9	2		PC	CAP FXD CER .100UF 10P 100VDC	P						
023	02	51839147	9	3		PC	CAP FXD CER .100UF 10P 100VDC	P		14523	14523		8106	8106
024	01	95691133	3	4		PC	CAP ELEC 270UF -10+100P 25VDC	P						
025	01	94842168	0	4		PC	CAP FXD CER .0033UF 6MV 1000V	P						
026	01	94397161	4	2		PC	CAP AL ELECT 560UF 0MM 75V	P						
027	01	94397162	2	2		PC	CAP AL ELECT 5600UF 0MM 12V	P						
028	01	51001120	8	3		PC	CAP CER F-2 .01UF +80-20P 25V	P						
029	01	94842145	8	2		PC	CAP FXD CER 500PF 20P 1K	P						
031	01	24504333	6	5		PC	CAP FXD TANT 2.2UF 20P 35VDCW	P						
033	01	94360236	7	1		PC	RES FXD FM 237 OHM 1P 1/4W	P						
034	01	24507181	6	2		PC	RES FXD COMP 5600 OHM 5P 1W	P						
035	01	95596503	3	2		PC	RES FXD WW 4.3 OHM 10P 5WATT	P						
036	01	95596520	7	2		PC	RES FXD WW 600 OHM 10P 5WATT	P						
037	01	65019518	3	6		PC	RES CARB COMP 1/2W 1.3 OHMS	P						
038	01	95596511	6	1		PC	RES FXD WW 43 OHM 10P 5WATT	P						
039	01	94402159	1	7		PC	RES FM 1.3K OHM 1/4 W CARBON	P						
040	01	94402172	4	2		PC	RES FM 4.7K OHM 1/4W CARBON	P						
041	01	94402148	4	2		PC	RES FM 470 OHM 1/4W CARBON	P						
042	02	94402166	6	1		PC	RES FM 2.7K OHM 1/4W CARBON	P						
043	01	94402220	1	2		PC	RES FM 470K OHM 1/4W CARBON	P						

BUILD ARC 210


ASSEMBLY PARTS LIST

BUILD ARC 210

ASSEMBLY PARTS LIST

PRINT DATE	PAGE	FILE CHANGE NO.
10-01-81	5	00014838

REV	ASSEMBLY NUMBER	CD	REV	SWG	DESCRIPTION	INC	STATUS	STATUS DATE	SWG. DESP.	FILE DATE			
0000	90446140	7	E	D	REPLACED BY 90446290 14838	A	INA	09-23-81	FA501A/B	10-01-81			
ITEM NO.	U	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION	INC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
089	01	24504343	5	1		PC CAP FXD TANT 15UF 20P 35VDC	P						
						0085 TOTAL LINES							



BUILD ARC 210

ASSEMBLY PARTS LIST

BUILD ARC 210										ASSEMBLY PARTS LIST										PRINT DATE		PAGE		FILE CHANGE NO.	
																				01-13-82		1		00014985	
DIV.		ASSEMBLY NUMBER		CD	REV	DWG.	DESCRIPTION				MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE								
0460		90446290		0	H	0	REPLACED BY 90446443 14985				A	INA	01-08-82		FA501A		01-13-82								
ITEM NO.	I	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION				MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT								
001	01	90446289		2	1		PC REPLACED BY 90446332 14778				P														
001	02	90446332		0	1		PC PW 80 1AFO PWR SPLY				P		14778				8143								
002	01	51940599		7	1		PC TRANSFORMER FLYBACK 25KHZ				P														
003	01	51940598		9	1		PC TRANSFORMER FLYBACK 25KHZ				P														
004	01	51918111		9	2		PC XSTR NPN 400V 8A TO 220				P														
005	01	51681100		7	2		PC XSTR 2N5189 NPN SIL				P														
006	01	51003092		7	5		PC XSTR 2N2222 H1 SPEED NPN SIL				P														
007	01	51714000		0	1		PC XSTR 2N2907 PNP SIL				P														
008	01	95637304		7	14		PC Q10 IN4004 400PIV SIL 1.1V/1A				P														
009	01	95691500		3	6		PC RECT, 1N5615 F-R SIL 1 AMP				P														
010	01	77635261		7	2		PC POWER 0100E FAST RECOVER				P														
011	01	19171201		7	4		PC LIGHT IND				P														
012	01	50240108		6	2		PC 0100E SIL ZEN 6.2V INT53A				P														
013	01	95791300		7	4		PC OPTICAL ISOLATOR				P														
014	01	51718400		8	2		PC 1C 723C 334 VOLTAGE REGULATOR				P														
015	01	51007385		1	1		PC 010 IN4148 10MA MICRO SIL 30V				P														
016	01	15163403		7	1		PC 1C LM317 ADJ +V ROLTR TO=220				P														
017	01	15151400		7	1		PC 1C UA7900=5 356A NEG V ROLTR				P														
018	01	51918616		7	4		PC INDUCTOR				P														
019	01	51918617		5	1		PC INDUCTOR				P														
020	01	51918627		4	2		PC CAP ALUM ELECT 300UF 250V 15P				P														

BUILD ARC 210

ASSEMBLY PARTS LIST

BUILD ARC 210										ASSEMBLY PARTS LIST										PRINT DATE 01-13-82		PAGE 2		FILE CHANGE NO. 00014985	
DIV		ASSEMBLY NUMBER		CD	REV	DWG.	DESCRIPTION				MC	STATUS	STATUS DATE		ENG. RESP.		FILE DATE								
0460		90446290		0	H	0	REPLACED BY 90446443 14985				A	INA	01-08-82		FA501A		01-13-82								
ITEM NO.	LT	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION				MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT								
021	01	24506816		8	2		PC CAP FXO MYL .33UF 10P 100VOCW				P														
022	01	36180753		0	2		PC CAP FXO MYL .001MFO 600V				P														
023	01	94240448		4	5		PC CAP CER 100000PF 50V 10P				P														
024	01	95691133		3	4		PC CAP ELEC 270UF -10+100P 25VOC				P														
025	01	94842168		0	4		PC CAP FXD CER .0033UF 50V 1000V				P			14722			8127								
025	02	51001214		9	4		PC CAP FXO CER .005UF 20P 3000V				P		14722			8127									
026	01	94397161		4	2		PC CAP AL ELECT 560UF OHM 75V				P														
027	01	94397162		2	2		PC CAP AL ELECT 5600UF OHM 12V				P														
028	01	51001120		8	3		PC CAP CER F=2 .01UF +80-20P 25V				P			14886			8148								
028	02	19115400		4	3		PC CAP FXO CER .01MF +80-20P 50V				P		14886			8148									
029	01	94842145		8	2		PC CAP FXD CER 500PF 20P 1K				P														
031	01	94400612		1	5		PC CAP FXD AL 15UF +100-10P 20V				P			14774			8133								
031	02	94400612		1	4		PC CAP FXD AL 15UF +100-10P 20V				P		14774			8133									
033	01	94360236		7	1		PC RES FXO FM 237 OHM 1P 1/4W				P														
034	01	24507181		6	2		PC RES FXO COMP 5600 OHM 5P 1W				P														
036	01	95596503		3	2		PC RES FXD WW 4.3 OHM 10P 5WAT7				P														
036	01	95596520		7	2		PC RES FXD WW 600 OHM 10P 5WAT7				P														
037	01	68019518		3	6		PC RES CARB COMP 1/2W 1.3 OHMS				P														
038	01	95596511		6	1		PC RES FXD WW 43 OHM 10P 5WAT7				P														
039	01	94402159		1	7		PC RES FM 1.3K OHM 1/4 W CARBON				P														
040	01	94402172		4	2		PC RES FM 5.7K OHM 1/4W CARBON				P														
041	01	94402148		4	2		PC RES FM 470 OHM 1/4W CARBON				P														

BUILD ARC 210										ASSEMBLY PARTS LIST										PRINT DATE		PAGE		P/S CHANGE NO.	
DIV		ASSEMBLY NUMBER		CB	REV	SWG	DESCRIPTION				MC	STATUS	STATUS DATE		ENG. DESP.		P/S DATE		01-13-82		3		00014985		
086U		90446290		H	0		REPLACED BY 90446443 14985				A	INA	01-08-82		FAS01A		01-13-82								
TYPE NO	LI	PART NUMBER		CB	QUANTITY	U/M	PART DESCRIPTION				MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT								
042	01	94402166		6	1		PC RES FM 2.7K OHM 1/4W CARBON				P														
043	01	94402220		1	7		PC RES FM 470K OHM 1/4W CARBON				P														
048	01	94402160		9	1		PC RES FM 1.5K OHM 1/4W CARBON				P														
049	01	94402110		4	2		PC RES FM 12 OHM 1/4W CARBON				P														
047	01	94360331		6	1		PC RES FXO FM 2100 OHM 1P 1/4W				P														
048	01	24504839		2	2		PC RES FXO COMP 100 OHM 5P 2WATT				P														
049	01	94402176		5	1		PC RES FM 6.8K OHM 1/4W CARBON				P														
050	01	94402167		4	4		PC RES FM 3K OHM 1/4W CARBON				P														
051	01	51918846		0	2		PC RES VAR CER 1K OHM 20P 1/2W				P														
052	01	94402155		9	1		PC RES FM 9100HM 1/4W CARBON				P														
053	01	94402165		8	1		PC RES FM 2.4K OHM 1/4W CARBON				P														
054	01	24500148		2	1		PC RES FXD COMP 240 OHM 5P 1/2W				P														
056	01	94402180		7	1		PC RES FM 10K OHM 1/4W CARBON				P														
057	01	51918101		0	2		PC MT/SK PLSTC 5EM1 F101 AND2				P														
058	01	94402179		9	1		PC RES FM 9.1K OHM 1/4W CARBON				P														
060	01	51003962		1		001	OZ PASTE, HEAT XFR CMPO NON-CONO				B														
061	01	10127103		9	4		PC MSCR PAN PML 4-40X.312 STL ZP				B														
062	01	10126400		0	4		PC WSHR, NO.4 EXT/T LK STL ZP				B														
063	01	10125103		1	4		PC NUT, HEX 4-40 MSCR STL ZP				B														
064	01	15163443		3	1		PC IC LM311N VOLT COMP H1 IMP				P														
065	01	94402122		9	1		PC RES FM 390HM 1/4W CARBON				P														


BUILD ARC 210						ASSEMBLY PARTS LIST						PRINT DATE		PAGE		P/S CHANGE NO.		
DIV.		ASSEMBLY NUMBER		CB	REV.	SWG.	DESCRIPTION				MC	STATUS	STATUS DATE		ENG. DESP.		P/S DATE	
086U		90446290		H	0		REPLACED BY 90446443 14985				A	INA	01-08-82		FAS01A		01-13-82	
TYPE NO	LI	PART NUMBER		CB	QUANTITY	U/M	PART DESCRIPTION				MC	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT	
066	01	94402132		8	2		PC RES FM 100 OHM 1/4W CARBON				P							
067	01	94360100		5	1		PC RES FXO FM 10 OHM 1P 1/4W				P							
068	01	50240105		2	1		PC 0100E 51L ZEN 4.7V				P							
069	01	14006500		9	REF		PC FABRICATION SPECIFICATION				D							
070	01	94360262		3	1		PC RES FXD FM 442 OHM 1P 1/4W				P							
071	01	51903001		9	1		PC RES FXO WW .02 OHM 5P 2WATT				P							
072	01	95691135		8	2		PC CAP ELEC 470UF -10+100P 25V0C				P							
073	01	17720519		2	2		PC RES FXO COMP 0.2MEG .5W 5P				P							
078	01	90446288		4	REF		PC SCH 01A8 1AFO (PFOS PWR SUP)				O							
076	01	82311900		3	2		PC INJECTOR-EJECTOR, NATURAL PCB				P							
077	01	93533110		1	2		PC ROLL PIN, .1250 X .250L STL ZP				B							
078	01	24500131		8	2		PC RES FXD COMP 47 OHM 5P 1/2W				P							
079	01	94402144		3	2		PC RES FM 330 OHM 1/4W CARBON				P							
080	01	95691506		0	2		PC RECT, 1N5416 F-R SIL 3 AMP				P							
081	01	51719600		2	2		PC HEAT SINK ELCTRN COMP FAN TOP				P							
082	01	51797418		4	1		FY T88 1N5 .059 01A T/W				B							
083	01	62019900		0	050		OZ EPOXY, 2-PART 5-MINUTE CLEAR				B							
084	01	12081500		6	2		PC 010 51L SCHOTTKY PWR .55V/1A				P							
085	01	94240401		3	2		PC CAP CER 1000PF 50V 10P				P							
086	01	51906601		3	2		PC MT SINK, SEMI F10 3 ALUM BLK				P							
087	01	95596512		4	1		PC RES FXO WW 51 OHM 10P 5W				P							

BUILD ARC 210

ASSEMBLY PARTS LIST

BUILD ARC 210				ASSEMBLY PARTS LIST				PRINT DATE		PAGE	FILE CHANGE NO				
								01-13-82		9	00014985				
DIV	ASSEMBLY NUMBER		CD	REV.	QTY	DESCRIPTION		REV.	STATUS	STATUS DATE		ENG. DESK.	FILE DATE		
046U	90446290		0	H	D	REPLACED BY 90446443 14985		A	INA	01-08-82		PASDIA	01-13-82		
ITEM NO.	LT	PART NUMBER		CD	QTY	U/M	PART DESCRIPTION		REV.	VLB	ECO. NO. IN	ECO. NO. OUT	S/H	WR IN	WR OUT
084	01	94842184		7	2		PC CAP FXD CER .02UF +80-20P 1K		P						
084	01	94400619		6	1		PC CAP ELEC 6-63VDC		P						
090	01	94402177		3	2		PC RES FM 7.5K OHM 1/4W CARBON		P						
091	01	16042865		2	REF		PC PLATO FLEX DISK SUBSYS		O		14754			8130	
092	01	94400603		0	1		PC CAP FXD ALUM 3.3UF 50V		P		14774			8133	
							0090 TOTAL LINES								


REV	DATE	BY	CHKD	APP	REVISION
1	10/1/71	WJ	WJ	WJ	1
2	10/1/71	WJ	WJ	WJ	2
3	10/1/71	WJ	WJ	WJ	3
4	10/1/71	WJ	WJ	WJ	4
5	10/1/71	WJ	WJ	WJ	5
6	10/1/71	WJ	WJ	WJ	6
7	10/1/71	WJ	WJ	WJ	7
8	10/1/71	WJ	WJ	WJ	8
9	10/1/71	WJ	WJ	WJ	9
10	10/1/71	WJ	WJ	WJ	10
11	10/1/71	WJ	WJ	WJ	11
12	10/1/71	WJ	WJ	WJ	12
13	10/1/71	WJ	WJ	WJ	13
14	10/1/71	WJ	WJ	WJ	14
15	10/1/71	WJ	WJ	WJ	15
16	10/1/71	WJ	WJ	WJ	16
17	10/1/71	WJ	WJ	WJ	17
18	10/1/71	WJ	WJ	WJ	18
19	10/1/71	WJ	WJ	WJ	19
20	10/1/71	WJ	WJ	WJ	20
21	10/1/71	WJ	WJ	WJ	21
22	10/1/71	WJ	WJ	WJ	22
23	10/1/71	WJ	WJ	WJ	23
24	10/1/71	WJ	WJ	WJ	24
25	10/1/71	WJ	WJ	WJ	25
26	10/1/71	WJ	WJ	WJ	26
27	10/1/71	WJ	WJ	WJ	27
28	10/1/71	WJ	WJ	WJ	28
29	10/1/71	WJ	WJ	WJ	29
30	10/1/71	WJ	WJ	WJ	30
31	10/1/71	WJ	WJ	WJ	31
32	10/1/71	WJ	WJ	WJ	32
33	10/1/71	WJ	WJ	WJ	33
34	10/1/71	WJ	WJ	WJ	34
35	10/1/71	WJ	WJ	WJ	35
36	10/1/71	WJ	WJ	WJ	36
37	10/1/71	WJ	WJ	WJ	37
38	10/1/71	WJ	WJ	WJ	38
39	10/1/71	WJ	WJ	WJ	39
40	10/1/71	WJ	WJ	WJ	40
41	10/1/71	WJ	WJ	WJ	41
42	10/1/71	WJ	WJ	WJ	42
43	10/1/71	WJ	WJ	WJ	43
44	10/1/71	WJ	WJ	WJ	44
45	10/1/71	WJ	WJ	WJ	45
46	10/1/71	WJ	WJ	WJ	46
47	10/1/71	WJ	WJ	WJ	47
48	10/1/71	WJ	WJ	WJ	48
49	10/1/71	WJ	WJ	WJ	49
50	10/1/71	WJ	WJ	WJ	50
51	10/1/71	WJ	WJ	WJ	51
52	10/1/71	WJ	WJ	WJ	52
53	10/1/71	WJ	WJ	WJ	53
54	10/1/71	WJ	WJ	WJ	54
55	10/1/71	WJ	WJ	WJ	55
56	10/1/71	WJ	WJ	WJ	56
57	10/1/71	WJ	WJ	WJ	57
58	10/1/71	WJ	WJ	WJ	58
59	10/1/71	WJ	WJ	WJ	59
60	10/1/71	WJ	WJ	WJ	60
61	10/1/71	WJ	WJ	WJ	61
62	10/1/71	WJ	WJ	WJ	62
63	10/1/71	WJ	WJ	WJ	63
64	10/1/71	WJ	WJ	WJ	64
65	10/1/71	WJ	WJ	WJ	65
66	10/1/71	WJ	WJ	WJ	66
67	10/1/71	WJ	WJ	WJ	67
68	10/1/71	WJ	WJ	WJ	68
69	10/1/71	WJ	WJ	WJ	69
70	10/1/71	WJ	WJ	WJ	70
71	10/1/71	WJ	WJ	WJ	71
72	10/1/71	WJ	WJ	WJ	72
73	10/1/71	WJ	WJ	WJ	73
74	10/1/71	WJ	WJ	WJ	74
75	10/1/71	WJ	WJ	WJ	75
76	10/1/71	WJ	WJ	WJ	76
77	10/1/71	WJ	WJ	WJ	77
78	10/1/71	WJ	WJ	WJ	78
79	10/1/71	WJ	WJ	WJ	79
80	10/1/71	WJ	WJ	WJ	80
81	10/1/71	WJ	WJ	WJ	81
82	10/1/71	WJ	WJ	WJ	82
83	10/1/71	WJ	WJ	WJ	83
84	10/1/71	WJ	WJ	WJ	84
85	10/1/71	WJ	WJ	WJ	85
86	10/1/71	WJ	WJ	WJ	86
87	10/1/71	WJ	WJ	WJ	87
88	10/1/71	WJ	WJ	WJ	88
89	10/1/71	WJ	WJ	WJ	89
90	10/1/71	WJ	WJ	WJ	90
91	10/1/71	WJ	WJ	WJ	91
92	10/1/71	WJ	WJ	WJ	92
93	10/1/71	WJ	WJ	WJ	93
94	10/1/71	WJ	WJ	WJ	94
95	10/1/71	WJ	WJ	WJ	95
96	10/1/71	WJ	WJ	WJ	96
97	10/1/71	WJ	WJ	WJ	97
98	10/1/71	WJ	WJ	WJ	98
99	10/1/71	WJ	WJ	WJ	99
100	10/1/71	WJ	WJ	WJ	100



1. CAPACITOR C15 MUST BE MOUNTED VERTICAL; (PERPENDICULAR TO BOARD PLANE).
2. RESISTOR R15 MUST BE MOUNTED APPROX. .25 INCH FROM BOARD SURFACE. SEE DETAIL. ONE RESISTOR LEG FACING NUMERICS ON BOARD TO BE RAISED.
- NOTES
3. MARK ASSY NO AND REVISION LEVEL 12 HIGH, WHITE, IN AREA SHOWN PER CDC SPEC 10121508.

2. FIND NUMBERS ELEMENT IDENTIFIERS, AND REFERENCE DESIGNATIONS ARE FOR PART
3. MOUNT RESISTORS .250 MIN .350 MAX OFF BD.
4. FAN 96 TO BE INSTALLED ON ONE COMPARTMENT OF EACH PAIR L1, L2 AND L3, L4. PAIRS TO BE HELD TOGETHER BY F/W 97.
5. RESISTORS TO BE INSTALLED WITH PROTRUSION TOWARD THE BOARD.
6. MOUNT DIODES .300 MIN .500 MAX OFF P.C. BOARDS.
7. MARK SERIAL NUMBER IN AREA SHOWN PER RYLOPS PIP NO. 80-20-134 AND PER MARKING REQM'TS IN NOTE (1) ONE.

CHANGES	DELETIONS	ADDITIONS



END NO	REFERENCE DESIGNATION	VALUE	UNIT	QTY	REMARKS
1	R1	10K	Ω	1	
2	R2	10K	Ω	1	
3	R3	10K	Ω	1	
4	R4	10K	Ω	1	
5	R5	10K	Ω	1	
6	R6	10K	Ω	1	
7	R7	10K	Ω	1	
8	R8	10K	Ω	1	
9	R9	10K	Ω	1	
10	R10	10K	Ω	1	
11	R11	10K	Ω	1	
12	R12	10K	Ω	1	
13	R13	10K	Ω	1	
14	R14	10K	Ω	1	
15	R15	10K	Ω	1	
16	R16	10K	Ω	1	
17	R17	10K	Ω	1	
18	R18	10K	Ω	1	
19	R19	10K	Ω	1	
20	R20	10K	Ω	1	
21	R21	10K	Ω	1	
22	R22	10K	Ω	1	
23	R23	10K	Ω	1	
24	R24	10K	Ω	1	
25	R25	10K	Ω	1	
26	R26	10K	Ω	1	
27	R27	10K	Ω	1	
28	R28	10K	Ω	1	
29	R29	10K	Ω	1	
30	R30	10K	Ω	1	
31	R31	10K	Ω	1	
32	R32	10K	Ω	1	
33	R33	10K	Ω	1	
34	R34	10K	Ω	1	
35	R35	10K	Ω	1	
36	R36	10K	Ω	1	
37	R37	10K	Ω	1	
38	R38	10K	Ω	1	
39	R39	10K	Ω	1	
40	R40	10K	Ω	1	
41	R41	10K	Ω	1	
42	R42	10K	Ω	1	
43	R43	10K	Ω	1	
44	R44	10K	Ω	1	
45	R45	10K	Ω	1	
46	R46	10K	Ω	1	
47	R47	10K	Ω	1	
48	R48	10K	Ω	1	
49	R49	10K	Ω	1	
50	R50	10K	Ω	1	
51	R51	10K	Ω	1	
52	R52	10K	Ω	1	
53	R53	10K	Ω	1	
54	R54	10K	Ω	1	
55	R55	10K	Ω	1	
56	R56	10K	Ω	1	
57	R57	10K	Ω	1	
58	R58	10K	Ω	1	
59	R59	10K	Ω	1	
60	R60	10K	Ω	1	
61	R61	10K	Ω	1	
62	R62	10K	Ω	1	
63	R63	10K	Ω	1	
64	R64	10K	Ω	1	
65	R65	10K	Ω	1	
66	R66	10K	Ω	1	
67	R67	10K	Ω	1	
68	R68	10K	Ω	1	
69	R69	10K	Ω	1	
70	R70	10K	Ω	1	
71	R71	10K	Ω	1	
72	R72	10K	Ω	1	
73	R73	10K	Ω	1	
74	R74	10K	Ω	1	
75	R75	10K	Ω	1	
76	R76	10K	Ω	1	
77	R77	10K	Ω	1	
78	R78	10K	Ω	1	
79	R79	10K	Ω	1	
80	R80	10K	Ω	1	
81	R81	10K	Ω	1	
82	R82	10K	Ω	1	
83	R83	10K	Ω	1	
84	R84	10K	Ω	1	
85	R85	10K	Ω	1	
86	R86	10K	Ω	1	
87	R87	10K	Ω	1	
88	R88	10K	Ω	1	
89	R89	10K	Ω	1	
90	R90	10K	Ω	1	
91	R91	10K	Ω	1	
92	R92	10K	Ω	1	
93	R93	10K	Ω	1	
94	R94	10K	Ω	1	
95	R95	10K	Ω	1	
96	R96	10K	Ω	1	
97	R97	10K	Ω	1	
98	R98	10K	Ω	1	
99	R99	10K	Ω	1	
100	R100	10K	Ω	1	

1. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 2. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 3. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		4. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 5. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 6. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
7. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 8. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 9. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		10. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 11. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 12. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
13. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 14. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 15. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		16. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 17. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 18. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
19. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 20. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 21. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		22. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 23. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 24. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
25. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 26. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 27. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		28. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 29. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 30. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
31. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 32. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 33. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		34. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 35. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 36. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
37. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 38. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 39. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		40. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 41. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 42. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
43. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 44. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 45. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		46. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 47. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 48. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
49. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 50. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 51. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		52. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 53. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 54. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
55. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 56. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 57. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		58. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 59. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 60. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
61. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 62. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 63. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		64. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 65. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 66. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
67. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 68. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 69. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		70. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 71. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 72. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
73. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 74. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 75. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		76. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 77. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 78. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
79. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 80. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 81. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		82. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 83. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 84. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
85. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 86. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 87. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		88. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 89. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 90. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
91. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 92. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 93. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		94. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 95. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 96. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
97. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 98. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 99. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		100. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 101. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 102. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
103. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 104. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 105. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		106. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 107. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 108. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
109. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 110. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 111. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		112. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 113. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 114. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
115. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 116. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 117. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		118. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 119. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 120. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
121. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 122. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 123. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		124. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 125. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 126. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
127. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 128. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 129. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		130. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 131. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 132. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
133. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 134. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 135. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		136. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 137. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 138. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
139. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 140. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 141. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		142. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 143. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 144. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
145. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 146. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 147. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		148. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 149. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 150. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
151. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 152. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 153. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		154. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 155. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 156. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
157. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 158. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 159. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		160. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 161. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 162. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
163. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 164. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 165. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		166. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 167. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 168. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
169. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 170. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 171. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		172. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 173. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 174. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
175. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 176. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 177. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		178. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 179. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 180. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
181. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 182. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 183. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		184. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 185. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 186. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
187. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 188. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 189. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		190. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 191. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 192. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
193. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 194. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 195. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		196. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 197. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 198. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
199. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 200. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 201. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		202. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 203. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 204. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
205. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 206. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 207. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		208. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 209. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 210. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
211. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 212. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 213. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		214. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 215. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 216. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
217. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 218. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 219. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		220. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 221. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 222. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
223. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 224. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 225. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		226. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 227. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 228. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
229. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 230. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 231. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		232. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 233. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 234. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
235. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 236. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 237. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		238. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 239. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 240. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
241. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 242. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 243. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		244. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 245. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 246. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
247. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 248. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 249. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		250. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 251. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 252. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
253. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 254. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 255. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		256. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 257. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 258. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
259. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 260. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 261. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		262. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 263. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 264. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
265. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 266. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 267. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		268. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 269. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 270. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
271. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 272. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 273. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		274. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 275. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 276. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
277. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 278. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 279. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		280. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 281. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 282. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
283. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 284. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 285. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		286. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 287. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 288. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
289. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 290. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 291. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		292. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 293. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 294. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
295. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 296. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 297. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		298. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 299. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 300. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
301. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 302. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 303. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		304. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 305. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 306. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
307. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 308. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 309. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		310. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 311. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 312. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
313. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 314. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 315. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		316. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 317. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 318. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
319. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 320. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 321. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		322. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 323. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 324. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
325. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 326. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 327. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		328. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 329. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 330. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
331. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 332. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 333. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		334. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 335. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 336. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
337. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 338. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 339. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		340. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 341. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 342. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
343. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 344. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 345. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		346. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 347. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 348. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
349. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 350. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 351. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		352. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 353. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 354. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
355. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 356. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 357. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		358. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 359. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 360. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
361. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 362. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 363. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		364. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 365. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 366. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
367. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 368. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 369. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		370. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 371. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 372. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
373. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 374. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 375. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		376. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 377. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 378. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
379. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 380. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 381. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		382. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 383. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 384. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
385. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 386. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 387. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		388. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 389. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 390. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
391. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 392. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 393. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		394. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 395. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 396. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
397. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 398. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 399. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		400. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 401. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 402. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
403. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 404. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 405. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		406. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 407. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 408. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
409. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 410. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 411. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		412. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 413. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 414. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
415. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 416. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 417. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		418. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 419. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 420. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
421. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 422. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 423. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		424. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 425. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 426. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
427. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 428. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 429. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		430. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 431. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 432. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
433. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 434. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 435. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		436. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 437. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 438. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
439. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 440. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 441. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		442. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 443. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 444. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
445. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 446. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 447. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		448. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 449. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 450. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
451. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 452. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 453. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		454. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 455. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 456. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
457. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 458. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 459. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		460. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 461. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 462. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
463. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 464. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 465. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		466. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 467. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 468. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
469. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 470. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 471. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		472. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 473. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 474. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
475. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 476. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 477. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		478. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 479. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 480. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
481. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 482. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 483. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		484. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 485. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 486. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
487. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 488. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 489. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		490. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 491. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 492. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
493. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 494. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 495. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		496. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 497. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 498. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	
499. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 500. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED 501. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED		502. ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES 503. DIMENSIONS ARE GIVEN TO CENTER UNLESS OTHERWISE SPECIFIED	

BUILD ARC 220

ASSEMBLY PARTS LIST

 PRINT DATE
08-09-83
 PAGE
1
 PRE CHANGE NO.
0016005A

DIV	ASSEMBLY NUMBER			CD	REV	DWG.	DESCRIPTION		INC	STATUS	STATUS DATE	ENG. RESP.	FILE DATE		
0860	90446443			5	D	D	PC CD ASSY 1AFD		A	REL	01-08-82	FA501A/D	08-09-83		
TRND NO	LI	PART NUMBER		CD	IN	QUANTITY	U/M	PART DESCRIPTION	INC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
001	01	90446332		0		1		PC PW BD 1AFD PWR SPLY	P						
002	01	51940599		7		1		PC TRANSFORMER FLYBACK 25KHZ	P						
003	01	51940598		9		1		PC TRANSFORMER FLYBACK 25KHZ	P						
004	01	51918111		9		2		PC XSTR NPM 400V 8A 70 220	P						
005	01	51681100		7		2		PC XSTR 2N5109 NPM 51L	P						
006	01	51003092		7		5		PC XSTR 2N2222 HI-SPEED MPN 51L	P						
007	01	51714000		0		1		PC XSTR, 2N2907 81-POLAR PNP SI	P						
008	01	95637304		7		14		PC RECT, 51L 1N4004 1A 400V MIN	P						
009	01	95691500		3		6		PC RECT, 51L 1N5615 1A 200V F-R	P						
010	01	77835261		7		2		PC DID MR021 PWR RECT 100WIV SID	P						
011	01	19171201		7		4		PC LIGHT IND	P						
012	01	50240108		6		2		PC DID 1N753A ZEN 6.2V 5P 20MA	P						
013	01	95791300		7		4		PC OPTICAL ISOLATOR	P						
014	01	51718400		8		2		PC IC 723C 334 VOLTAGE REGULATOR	P						
015	01	51007385		1		1		PC DID 1N4148 SIL MICRO 30V 10MA	P						
016	01	15163403		7		1		PC IC LM317 317 ADJ PDS V RGLTR	P						
017	01	15151400		7		1		PC IC UA7905 3S6A NEG V RGLTR	P						
018	01	51918616		7		4		PC IND, RF-CHOKE 100UH 1.5A F-1	P						
019	01	51918617		5		1		PC IND, RF-CHOKE 70UH 7A F-1	P						
020	01	51918627		4		2		PC CAP ALUM ELEC7 300UF 250V 15P	P						
021	01	24506816		8		2		PC CAP FXD MYL .33UF 10P 100VDCW	P						

BUILD ARC 220

ASSEMBLY PARTS LIST

 PRINT DATE
08-09-83
 PAGE
2
 PRE CHANGE NO.
0016005A

DIV	ASSEMBLY NUMBER			CD	REV	DWG.	DESCRIPTION		INC	STATUS	STATUS DATE		INC	ENG. RESP.	FILE DATE	
0860	90446443			5	D	D	PC CD ASSY 1AFD		A	REL	01-08-82			FA501A/D	08-09-83	
TRND NO	LI	PART NUMBER		CD	QUANTITY	U/M	PART DESCRIPTION			INC	YLD	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
022	01	36180753	0		2		PC CAP MYL FM .001UF 10P 600VDCW			P						
023	01	94240448	4		5		PC CAP FXD CER 100KPF 10P 50VDCW			P						
024	01	95691133	3		4		PC CAP ELEC7 270UF -10+100P 25V			P						
025	01	51001214	9		4		PC CAP FXD CER .005UF 20P 3000V			P						
026	01	94397161	4		2		PC CAP AL ELEC 560UF-10+100P 75V			P						
027	01	94397162	2		2		PC CAP AL ELEC 5600UF-10+100 12V			P						
028	01	19115400	4		3		PC CAP FXD CER .01UF +80-20P 50V			P						
029	01	94842145	8		2		PC CAP FXD CER 500PF 20P 1K			P						
031	01	94400612	1		3		PC CAP AL ELEC 15UF-10+100P 25V			P						
033	01	94360236	7		1		PC RES FXD FM 237 OHM 1P 1/4W			P						
034	01	24507181	6		2		PC RES FXD COMP 5600 OHM 5P 1W			P						
035	01	95596503	3		2		PC RES FXD WW 4.3 OHM 10P 5WATT			P						
036	01	95596520	7		2		PC RES FXD WW 600 OHM 10P 5WATT			P						
037	01	65019510	3		6		PC RES CARB COMP 1/2W 1.3 OHMS			P						
038	01	95596511	6		1		PC RES FXD WW 43 OHM 10P 5WATT			P						
039	01	94402159	1		7		PC RES FXD C FM 1.3K OHM 5P 1/4W			P						
040	01	94402172	4		2		PC RES FXD C FM 4.7K OHM 5P 1/4W			P						
041	01	94402140	4		2		PC RES FXD C FM 470 OHM 5P 1/4W			P						
042	01	94402166	6		1		PC RES FXD C FM 2.7K OHM 5P 1/4W			P						
043	01	94402220	1		7		PC RES FXD C FM 470K OHM 5P 1/4W			P						
045	01	94402160	9		1		PC RES FXD C FM 1.5K OHM 5P 1/4W			P						

BUILD ARC 220

ASSEMBLY PARTS LIST

BUILD ARC 220

ASSEMBLY PARTS LIST

PRINT DATE

PAGE

PLS CHANGE NO.

08-09-83

3

0010005A

REV.	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION	REV.	STATUS	STATUS DATE	QTY. DESP.	PLT DATE			
0000	90446443	S	D	D	PC CD ASSY 1AFD	A	REL	01-08-82	FA501A/D	08-09-83			
T/PNO	LI	PART NUMBER	CD	QTY.	U/M	PART DESCRIPTION	REV.	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
046	01	94402110	4	2		PC RES FXD C FM 12 OHM 5P 1/4W	P						
047	01	94360331	6	1		PC RES FXD FM 2100 OHM 1P 1/4W	P						
047	02	94360330	8	1		PC RES FXD FM 2050 OHM 1P 1/4W	P		10060	10060		0330	0330
048	01	24504039	2	2		PC RES FXD COMP 100 OHM 5P 2WATT	P						
049	01	94402170	5	1		PC RES FXD C FM 0.8K OHM 5P 1/4W	P						
050	01	94402107	4	4		PC RES FXD C FM 3.0K OHM 5P 1/4W	P						
051	01	51910040	0	2		PC RES VAR CRW 1K R 20P 1/2W 1	P						
052	01	94402155	9	1		PC RES FXD C FM 910 OHM 5P 1/4W	P						
053	01	94402165	0	1		PC RES FXD C FM 2.4K OHM 5P 1/4W	P						
054	01	24500140	2	1		PC RES FXD COMP 240 OHM 5P 1/2W	P						
056	01	94402100	7	1		PC RES FXD C FM 10K OHM 5P 1/4W	P						
057	01	51910101	0	2		PC HT/5K, SEMICNDCT F10-10 AL/BL	P						
058	01	94402179	9	1		PC RES FXD C FM 9.1K OHM 5P 1/4W	P						
060	01	51003962	1	001		OZ PASTE, HEAT XFR CMPO MON-COND	B						
061	01	10127103	9	4		PC MSCR PAN PHL 4-40X.312 STL ZP	B		10005	10005		0350	0350
061	02	10127103	9	2		PC MSCR PAN PHL 4-40X.312 STL ZP	B						
062	01	10126400	0	4		PC WSHR, (4) EXT/T LK STL ZP	B						
063	01	10125103	1	4		PC NUT, HEX 4-40 MSCR STL ZP	B						
064	01	15163443	3	1		PC IC LM311N 311 VOLT COMPARATOR	P						
065	01	94402122	9	1		PC RES FXD C FM 39 OHM 5P 1/4W	P						
066	01	94402132	8	2		PC RES FXD C FM 100 OHM 5P 1/4W	P						
067	01	94360180	5	1		PC RES FXD FM 10 OHM 1P 1/4W	P						

BUILD ARC 220

ASSEMBLY PARTS LIST

BUILD ARC 220

ASSEMBLY PARTS LIST

PRINT DATE

PAGE

PLS CHANGE NO.

08-09-83

4


0010005A

REV.	ASSEMBLY NUMBER	CD	REV.	QTY.	DESCRIPTION	REV.	STATUS	STATUS DATE	QTY. DESP.	PLT DATE			
0060	90446443	S	D	D	PC CD ASSY 1AFD	A	REL	01-08-82	FA501A/D	08-09-83			
T/PNO	LI	PART NUMBER	CD	QTY.	U/M	PART DESCRIPTION	REV.	YLR	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
068	01	50240105	2	1		PC Q10 INT50A ZEN 4.7V 5P 20MA	P						
069	01	10006500	9	REF		PC FABRICATION SPECIFICATION	D						
070	01	94360262	3	1		PC RES FXD FM 442 OHM 1P 1/4W	P						
071	01	51903001	9	1		PC RES FXD WW .02 OHM 5P 2WATT	P						
072	01	95691135	0	2		PC CAP ELECT 470UF -10+100P 25V	P						
073	01	17720519	2	2		PC RES FXD COMP 0.2MEG .5W 5P	P						
075	01	90446200	4	REF		PC SCH Q1A0 1AFD (PFOS PWR SUP)	D						
076	01	02311900	3	2		PC INJECTOR-EJECTOR, NATURAL PCB	P						
077	01	93533110	1	2		PC ROLLPIN, .01250 X .250L STL ZP	B						
078	01	24500131	0	2		PC RES FXD COMP 47 OHM 5P 1/2W	P						
079	01	94402144	3	2		PC RES FXD C FM 330 OHM 5P 1/4W	P						
080	01	95691500	0	2		PC RECT, 51L 1N5616 3A 100V F-R	P						
081	01	51719600	2	2		PC HEAT SIMK ELCTRN COMP FAN TOP	P						
002	01	51797410	4	062		FT T08 1H5 .059 01A T/W	B						
083	01	62019900	0	050		OZ EPOXY, 2-PART 5-MINUTE CLEAR	B			10005			0350
084	01	12001500	6	2		PC Q10 51L SCHOTTKY PWR .55V/1A	P						
085	01	94240401	3	2		PC CAP FXD CER 1000PF 10P 50VDCW	P						
086	01	51906601	3	2		PC HT/5K, SEMICNDCT F10-1 AL/BLK	P						
086	02	51906604	7	2		PC HT/5K, SEMICNDCT F10-1 AL/BLK	P		10005	10005		0350	0350
087	01	95596512	4	1		PC RES FXD WW 51 OHM 10P 5WATT	P						
088	01	94042104	7	2		PC CAP FXD CER .02UF +00-20P 1K	P						

BUILD ARC 220

ASSEMBLY PARTS LIST

BUILD ARC 220					ASSEMBLY PARTS LIST			PRINT DATE		PAGE		PRT CHANGE NO			
								08-09-83		5		0018005A			
DIV	ASSEMBLY NUMBER		CD	REV.	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. DESP.		FILE DATE	
0000	90446443		5	0	0	PC CD ASSY 1AFD		A	REL	01-00-02		FA501A/D		00-00-03	
ITEM NO	LT	PART NUMBER		CD	QUANTITY	U/M	PART DESCRIPTION		MC	TYP	ECO. NO. IN	ECO. NO. OUT	S/N	WE IN	WE OUT
009	01	94400619		6	1		PC CAP AL ELEC 33UF-10*100P 25V	P							
090	01	94402177		3	2		PC RES FXD C FM 7.5K OHM 5P 1/4W	P							
091	01	16042065		2	REF		PC PLATO FLEX DISK SUBSYS	D							
092	01	94400603		0	1		PC CAP AL ELEC 3.3UF-10*100P 50V	P							
093	01	94400608		6	1		PC CAP AL ELEC 1.0UF-10*100P 63V	P							
094	01	94864044		9	4		PC SPACER, NYLON .400	B		19945				0325	
095	01	94864045		6	10		PC SPACER, NYLON .500	B		19945				0325	
096	01	24528638		0	166		FT T80, SZ 3/8 INSUL BLK UL PVC	B		10005A				0350	
097	01	94277400		1	2		PC STRAP, CBL TIE TYP-1 TO 5/8	B		16005A				0350	
0094 TOTAL LINES															



BUILD ARC 230

ASSEMBLY PARTS LIST

BU1LO ARC 230					ASSEMBLY PARTS LIST			PRINT DATE		PAGE	PRT CHANGE NO.		
					06-14-83			1	00015917				
DIV	ASSEMBLY NUMBER	CD	REV	DWG	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. RESP.	PLS DATE	
0860	90446143	1	D	D	CO ASSY 98MO BACKPLANE		A	REL	07-16-80		FA501A	06-14-83	
ITEM NO	LI	PART NUMBER	CD	QUANTITY	U/M	PART DESCRIPTION	MC	YLB	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
001	01	90446142	3	1		PC PW 8D 98MO BACKPLANE	P						
002	01	51940558	3	1		PC CONN, PC BRD EDGE 8PIN UL	P						
003	01	51940578	1	1		PC CONN, PC BRD EDGE 30PIN	P						
004	01	51906101	4	1		PC CONN, PC-MTD 3 PIN NYL/SN F-1	P						
005	01	71493161	5	1		PC CHANNEL, EXTRUDED PLASTIC	P						
007	02	83465803	1	1		PC CONN, PLUG FEMALE	P						
007	02	10129648	8	1		PC CONN RCPT, 50 SKT HSG PC-MTB	P		14203	14203		8047	8047
008	01	61408892	0	1		PC CABLE SIGNAL PLATD FO	S						
009	01	83434704	9	2		PC CONN 25 PIN	P			14203			
009	02	10129648	1	2		PC CONN PLUG, 25 PIN HSG PC-MTB	P		14203			8047	8047
010	01	61408891	2	1		PC CABLE AC PLATD FO SUBSYSTEM	G						
011	01	61408890	4	1		PC CABLE DC PLATD FO SUBSYSTEM	G						
012	01	24501808	0	250		FT WIRE, BUSS 20AWG SGL10 CU/SN	W						
016	02	65642201	1	1		PC CORD, 24.51N FEM-RCPT 2-CNOCT	P			15294			
016	03	61409511	5	1		PC CABLE ASSY AC MUFFIN FAN	A		15294	15917		8312	8312
016	04	65642201	1	1		PC CORD, 24.51N FEM-RCPT 2-CNOCT	P		15917			8337	8337
017	01	51863202	1	1		PC CONN, 60PDS 8D-EDGE FIG-1 AU	P						
018	01	94288024	6	6		PC LKG DEVICE, CONN TYP 4 W/TYP3	P						
018	02	18252501	4	6		PC SCR=LDCK, CONNECTOR CONF10-8	P		14453	14453		8051	8051
019	01	71493091	4	1		PC PLATE, I/O CONNECTOR	P						
020	01	24528645	5	375		FT T8G, NO. 4 1NS CLR UL PVC	B		15917			8337	
021	01	94277400	1	1		PC STRAP, CBL TIE TYP-1 TO S/8	B		15917			8337	

BUILD ARC 230

ASSEMBLY PARTS LIST

BUILD ARC 230					ASSEMBLY PARTS LIST			PRINT DATE		PAGE		P/LR CHANGE NO.			
								06-14-83		2		00015917			
DIV	ASSEMBLY NUMBER		CD	REV	DWG.	DESCRIPTION		MC	STATUS	STATUS DATE		ENG. RESP.		P/LR DATE	
0860	90446143		1	D	D	CO ASSY 98MO BACKPLANE		A	REL	07-16-80		FA501A		06-14-83	
ITEM NO	LI	PART NUMBER		CD	QUANTITY	U/M	PART DESCRIPTION		MC	YLB	ECO. NO. IN	ECO. NO. OUT	S/N	WK IN	WK OUT
							0022 TOTAL LINES								

No wire lists are contained in this manual. The following wire list document numbers are provided for reference purposes if needed.

<u>Title</u>	<u>Document Number</u>	
	<u>Preproduction Units</u>	<u>Production Units</u>
60-Hz AC Entry Panel Wiring	61408888	61409023
50-Hz AC Entry Panel Wiring	61408889	61409024
DC Cable Wiring (Backpanel)	61408890	61408890
AC Cable Wiring (Backpanel)	61408891	61408891
Signal Cable Wiring (Backpanel)	61408892	61408892